OPERATOR'S MANUAL

SKID-STEER LOADER L-325

42032514

SPERRY NEW HOLLAND



Reprinted

MidWestTech | Sperry New Holland L-325 Skid Steer Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

CONTENTS

ABOUT IMPROVEMENTS 2

A NOTE TO YOU, MR. OWNER 2

SAFETY INFORMATION 4

SAFETY DECALS 6

OPERATION 8
- PRE-STARTING CHECK LIST 13
- NEW LOADER RUN-IN 13
- STARTING THE LOADER 13
- STOPPING THE LOADER 14

LOADER OPERATION 15

FIELD OPERATION 18

SERVICE AND LUBRICATION CHARTS ..... 21 and 22

PERIODIC SERVICE 23

MAINTENANCE AND ADJUSTMENTS 30

STORING THE LOADER 38

SERVICE CHART 41

TROUBLESHOOTING 42
- TROUBLESHOOTING - HYDRAULIC SYSTEM 42

OPTIONAL EQUIPMENT AND REFERRAL ATTACHMENTS 43

SPECIFICATIONS 47

INDEX 49

DELIVERY REPORT ..... after INDEX



DANGER!

FASTEN SEAT BELT

BEFORE STARTING ENGINE!

THIS LOADER IS A VERY STABLE UNIT BUT IT CAN BE UPSET IF THE OPERATOR STOPS SUDDENLY WHEN BUCKET IS RAISED AND LOADED.

THEREFORE, DO NOT START ENGINE BEFORE SECURELY FASTENING THE SEAT BELT.

MidWestTech | Sperry New Holland L-325 Skid Steer Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >