OPERATOR'S MANUAL

LOADER BACKHOE GENERAL LB-620

ISSUE 4-86

(REPLACES ALL PREVIOUS ISSUES)

NEW HOLLAND



42062012

Reprinted

MidWestTech | New Holland General LB-620 Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >

CONTENTS

SAFETY 4
CONTROLS AND INSTRUMENT PANEL 10
PRESTARTING CHECKLIST 13
STARTING THE LOADER BACKHOE 14
STOPPING THE LOADER BACKHOE 15
OPERATION 16
LOADER FIELD OPERATION 20
BACKHOE OPERATION 23
HOURLY SERVICE AND LUBRICATION CHART 27
SERVICE AND LUBRICATION POINTS 28
PERIODIC SERVICE ADJUSTMENTS 38
STORING THE LOADER 42
TROUBLESHOOTING AND SERVICE PROBLEM EVALUATION 43
OPTIONAL EQUIPMENT 47
SPECIFICATIONS 48
INDEX 53
DELIVERY REPORT ..... after INDEX

DANGER

NEVER ENTER, OR ALLOW ANYONE ELSE TO ENTER, THE SWING JOINT AREA. DEATH OR SERIOUS INJURY COULD RESULT.



MidWestTech | New Holland General LB-620 Loader Backhoe Operator's Manual | Publicat... Order the manual at mid-west-tech.com >