OPERATOR'S MANUAL

Loader Backhoe
LB-620

Issue 3-88

Serial Number 735312 and Above

42062013



NEW HOLLAND

Ford

FORD

NEW HOLLAND

Reprinted

MidWestTech | New Holland LB-620 Loader Backhoe Operator's Manual | Publication 4206... Order the manual at mid-west-tech.com >

CONTENTS

SAFETY 5
CONTROLS AND INSTRUMENT PANEL 10
PRESTARTING CHECKLIST 14
STARTING THE LOADER BACKHOE 15
STOPPING THE LOADER BACKHOE 17
OPERATION 18
LOADER FIELD OPERATIONS 23
BACKHOE OPERATION 26
HOURLY SERVICE AND LUBRICATION CHART 30
SERVICE AND LUBRICATION POINTS 31
PERIODIC SERVICE ADJUSTMENTS 42
STORING THE LOADER 46
TROUBLESHOOTING 47
OPTIONAL EQUIPMENT 52
SPECIFICATIONS 53
INDEX 57
DELIVERY REPORT ..... after INDEX

DANGER

NEVER ENTER, OR ALLOW ANYONE ELSE TO ENTER, THE SWING JOINT AREA. DEATH OR SERIOUS INJURY COULD RESULT.



MidWestTech | New Holland LB-620 Loader Backhoe Operator's Manual | Publication 4206... Order the manual at mid-west-tech.com >