Narrow Tractors
3830
4030
4230
4430

OPERATOR'S MANUAL

NEW HOLLAND

42383041 7/95
603.64.900.00

MidWestTech | Ford New Holland 3830, 4030, 4230, 4430 Narrow Tractor Operator's Manual | Publication 42383041
Order the manual at mid-west-tech.com >

CONTENTS

SAFETY 0-5

- THE TRACTOR 0-6
- DIESEL FUEL 0-11
- ROLL BAR (LESS CAB MODELS ONLY) 0-12
- SAFETY CAB (WITH CAB MODELS ONLY) 0-13
- SAFETY DECALS 0-14

INTRODUCTION 0-17

ROLL BAR 0-19

SAFETY CAB/ROPS 0-22

PROTECTIVE SHIELDING 0-23

UNIVERSAL SYMBOLS 0-26

SECTION 1 – CONTROLS, INSTRUMENTS AND OPERATION 1-1

- OPERATOR'S SEAT AND SEAT BELT 1-1
- INSTRUMENT PANEL – GAUGES AND WARNING LAMPS 1-3
- INSTRUMENT PANEL – CONTROLS AND SWITCHES 1-5
- HAND AND FOOT CONTROLS 1-8
- TRANSMISSION 1-11
- FOUR WHEEL DRIVE (FWD) 1-14
- POWER TAKE-OFF (PTO) 1-15
- HYDRAULIC SYSTEM 1-21
- THREE-POINT LINKAGE 1-25
- ATTACHING AND DETACHING TRAILED EQUIPMENT 1-31
- REMOTE CONTROL VALVES 1-33
- TRACK WIDTH ADJUSTMENTS 1-37
- FRONT WHEEL TRACK SETTING 1-42
- REAR WHEEL TRACK SETTING 1-45
- TRACTOR WEIGHTING 1-50
- CAB CONTROLS AND OPERATION 1-53
- STARTING THE ENGINE 1-60
- BREAK-IN PROCEDURE 1-63
- DRIVING THE TRACTOR 1-64

SECTION 2 – LUBRICATION AND MAINTENANCE 2-1

- LUBRICATION AND MAINTENANCE CHARTS 2-2
- WHEN WARNING LAMP GLOWS 2-7
- ROUTINE SERVICING 2-8
- GENERAL MAINTENANCE – COOLING SYSTEM 2-46
- GENERAL MAINTENANCE – FUEL SYSTEM 2-48
- GENERAL MAINTENANCE – ELECTRICAL SYSTEM 2-50
- GENERAL MAINTENANCE – STORAGE 2-53
- ADDITIONAL MAINTENANCE – CAB TRACTORS 2-54

SECTION 3 – SPECIFICATIONS 3-1

INDEX 3-10

DELIVERY REPORT 3-11

FIRST 50-HOUR SERVICE 3-15

MidWestTech | Ford New Holland 3830, 4030, 4230, 4430 Narrow Tractor Operator's Manua... Order the manual at mid-west-tech.com >