OPERATOR'S MANUAL

SKID-STEER LOADER L-775

SPERRY NEW HOLLAND




REPRINTED

42657510

MidWestTech | Sperry New Holland L-775 Skid Steer Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >

DANGER!

FASTEN SEAT BELT
BEFORE STARTING ENGINE!



THIS LOADER IS A VERY STABLE UNIT BUT IT CAN BE UPSET IF THE OPERATOR STOPS SUDDENLY WHEN BUCKET IS RAISED AND LOADED.

THEREFORE, DO NOT START ENGINE BEFORE SECURELY FASTENING THE SEAT BELT.

CONTENTS

ATTACHMENTS
- Dirt Tooth Kit ... 46
- Drawbar Kit ... 44
- Front Blade ... 46
- Loader Buckets ... 44
- Pallet Fork ... 48
- SMV Sign ... 48
- Spill Guard Kit ... 46
- Utility Fork ... 46

DELIVERY REPORT ... 51

ELECTRICAL CIRCUIT DIAGRAMS ... 35-36

FUEL ... 15

HYDRAULIC CIRCUIT DIAGRAM ... 34

LUBRICATION ... 16

MAINTENANCE AND ADJUSTMENTS
- Attachment Quick Latch ... 29
- Boom Lock Linkage ... 30
- Bucket and Boom Control Pedals ... 29
- Bucket Position Indicator ... 28
- Engine Speeds and Governor Adjustments ... 30
- Final Drive Chains ... 32
- High-Low Range Control ... 27
- Hydraulic System ... 33
- Left Side Centering Spring ... 27
- Left Side Drive Control ... 23
- Left Side Drive Control Lever Stop ... 26
- Right Side Drive Control ... 27

OPERATION
- Controls and Instrument Panel ... 5
- Field Operation ... 43
- Free Wheeling Valve ... 10
- Pre-Starting Check List ... 9
- "Quick Switch" Attachment Mounting System ... 12
- Starting and Operating New Engine ... 9

OPTIONAL EQUIPMENT ... 41

PERIODIC SERVICE ... 18

SAFETY INFORMATION ... 4

SERVICE CHART ... 38

SPECIFICATIONS ... 50

STORING THE LOADER ... 37

TROUBLE SHOOTING HYDRAULIC PUMPS ... 39

MidWestTech | Sperry New Holland L-775 Skid Steer Loader Operator's Manual | Publicati... Order the manual at mid-west-tech.com >