A TEREX BRAND

Parts Manual

Serial Number Range

GS-2032

GS-2632

to SN 59999

Part No. 46325

Rev J3

November 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals and Paint

101.1 Decals with Words (to SN 51682)....10
101.2 Decals with Words (from SN 51683)....14
102.1 Decals with Symbols (from SN 51683)....16
103.1 Platform Control Box Decals....18

200 Drive Chassis Components

201.1 Steer Axle Linkage and Wheels (to SN 43386)....20
201.2 Steer Axle Linkage and Wheels (from SN 43387)....22
202.1 Ground Controls and Level Sensor Installation (to SN 1999)....24
202.2 Ground Controls and Level Sensor Installation (from SN 2000 to 18703)....26
202.3 Ground Controls and Level Sensor Installation (from SN 18704)....28
203.1 Battery Charger....30
204.1 Battery Charger, 110V AC, Asia....32
205.1 Battery Charger, 220V AC, European....34
206.1 Battery Charger, Worldwide....36
207.1 Battery Pack Module Tray Installation (to SN 36044)....38
207.2 Battery Pack Module Tray Installation (from SN 36045)....40
208.1 Battery Pack Module, GS-2032....42
209.1 Battery Pack Module, GS-2632....44
210.1 Non-steer Axle and Brake Release (to SN 50764)....46
210.2 Non-steer Axle and Brake Release (from SN 50765)....48
211.1 Pothole Protection Assembly and Counterweights....50
212.1 Power Unit Module Installation (to SN 36044)....54
212.2 Power Unit Module Installation (from SN 36045)....56
213.1 Power Unit Module, GS-2032....58
214.1 Power Unit Module, GS-2632....62
215.1 Hydraulic Power Unit....64
216.1 Ground Controls (to SN 28695)....66
216.2 Ground Controls (from SN 28696 to 45894)....68
216.3 Ground Controls (from SN 45895)....70
217.1 Function Manifold (to SN 36044)....72
217.2 Function Manifold (from SN 36045 to 49245)....74
217.3 Function Manifold (from SN 49246)....76
218.1 Function Manifold - Models with Traction Control....78
219.1 Hydraulic Hoses and Fittings, GS-2032 (to SN 36059)....80
219.2 Hydraulic Hoses and Fittings, GS-2032 (from SN 36060 to 50764)....82
219.3 Hydraulic Hoses and Fittings, GS-2032 (from SN 50765 to 52788)....84
219.4 Hydraulic Hoses and Fittings, GS-2032 (from SN 52789)....86
220.1 Hydraulic Hoses and Fittings, GS-2632 (to SN 50764)....88
220.2 Hydraulic Hoses and Fittings, GS-2632 (from SN 50765 to 52788)....90
220.3 Hydraulic Hoses and Fittings, GS-2632 (from SN 52789)....92
221.1 Power Cables - Drive Chassis, GS-2032 (models without contactor)....94
221.2 Power Cables - Drive Chassis, GS-2032 (models with contactor)....96
222.1 Power Cables - Drive Chassis, GS-2632 (models without contactor)....98
222.2 Power Cables - Drive Chassis, GS-2632 (models with contactor)....100

300 Scissor Components

301.1 Scissor Assembly, GS-2032, View 1....102
302.1 Scissor Assembly, GS-2032, View 2....104
303.1 Scissor Assembly, GS-2632, View 1....106
304.1 Scissor Assembly, GS-2632, View 2....108
305.1 Lift Cylinder Assembly (to SN 23567)....110
305.2 Lift Cylinder Assembly (from SN 23568)....112

400 Platform Components

401.1 Platform Installation....114
402.1 Main Platform and Railings with Entry Chain, Round Tube, GS-2032....116
403.1 Main Platform and Railings with Entry Gate, Round Tube, GS-2032....118
404.1 Platform Extension and Railings, Round Tube, GS-2032....120

MidWestTech | Terex Genie GS-2032, GS-2632 Scissor Lift Parts Manual | Publication 463... Order the manual at mid-west-tech.com >

405.1 Platform, Railings and Entry, Square Tube, Rigid Rails, GS-32.....122
406.1 Main Platform, Railings and Entry Gate, Square Tube, Fold-down, GS-32.....124
407.1 Platform Extension, Square Tube, Fold-down Rails, GS-32.....126
408.1 Power to Platform.....128
409.1 Control Cable - Chassis to Platform.....130
410.1 Platform Controls (to SN 17407).....132
410.2 Platform Controls (from SN 17408 to 42999).....134
410.3 Platform Controls (from SN 43000 to 48103).....136
410.4 Platform Controls (from SN 48104).....138
411.1 Joystick Controller (to SN 17407).....140
411.2 Joystick Controller (from SN 17408 to 48103).....142
411.3 Joystick Controller (from SN 48104).....144

500 Accessories
501.1 Alarm, Horn and Flashing Beacon.....146
502.1 Platform Overload Protection.....148
503.1 Air Line to Platform.....150
504.1 Voltage Inverter.....152
505.1 Work Light.....154
506.1 Battery - Maintenance Free.....156

Indices
Part Number Index.....158
Part Description Index.....162

Cross References
Fittings Cross Reference.....168


MidWestTech | Terex Genie GS-2032, GS-2632 Scissor Lift Parts Manual | Publication 463... Order the manual at mid-west-tech.com >

101.1 Decals with Words (to SN 51682) (continued)

Item	Part No.	Description	Qty.
50	72992GT	DECAL,NOTICE,SIDE FRC,2632ANSI...1 *GS-2632, ANSI and CSA models (100 lbs/445 N)*	
51	82307GT	DECAL,INSTR,INDOOR,AUS-26/3232 *GS-2632, AUS models (indoor, 90 lbs / 400 N)*	
52	82368GT	DECAL,LABEL,RYKON/FLUID LEVEL....1 *(from SN 48926)*	
53	82448GT	DECAL, GROUND CONTROL PANEL....1	
54	96472GT	SERIAL # LABEL,SCISSORS*****.....1 *ANSI and CSA models*	
55	39612GT	DECAL,JOYSTICK**.....1 *Gen II (to SN 17407)*	


MidWestTech | Terex Genie GS-2032, GS-2632 Scissor Lift Parts Manual | Publication 463... Order the manual at mid-west-tech.com >

410.2 Platform Controls (from SN 17408 to 42999)



MidWestTech | Terex Genie GS-2032, GS-2632 Scissor Lift Parts Manual | Publication 463... Order the manual at mid-west-tech.com >

411.2 Joystick Controller (from SN 17408 to 48103)



MidWestTech | Terex Genie GS-2032, GS-2632 Scissor Lift Parts Manual | Publication 463... Order the manual at mid-west-tech.com >