A TEREX BRAND

Parts Manual

Serial Number Range

GS-2046

GS-2646

GS-3246

to SN 59999

Part No. 48338

Rev G10

November 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 Decals....10
102.1 Platform Control Box Decals....14

200 Drive Chassis Components

201.1 Steer Axle Linkage and Wheels (to SN 43634)....16
201.2 Steer Axle Linkage and Wheels (from SN 43635)....18
202.1 Ground Controls and Level Sensor Installation (to SN 1999)....20
202.2 Ground Controls and Level Sensor Installation (from SN 2000)....22
203.1 Battery Charger....24
203.2 Battery Charger, 110V AC, Asia....26
203.3 Battery Charger, 220V AC, European....28
203.4 Battery Charger - Domestic and Worldwide....30
204.1 Battery Pack Module Tray Installation (to SN 36044)....32
204.2 Battery Pack Module Tray Installation (from SN 36045)....34
205.1 Battery Pack Module (to SN 35799)....36
205.2 Battery Pack Module (from SN 35800)....38
206.1 Non-steer Axle and Brake Release Hand Pump Installation....40
207.1 Pothole Protection Assembly and Counterweights (to SN 35799)....42
207.2 Pothole Protection Assembly and Counterweights (from SN 35800)....44
208.1 Power Unit Module Installation (to SN 35799)....46
208.2 Power Unit Module Installation (from SN 35800)....48
209.1 Power Unit Module Tray (to SN 36044)....50
209.2 Power Unit Module Tray (from SN 36045)....54
210.1 Hydraulic Power Unit....56
211.1 Function Manifold (to SN 36044)....58
211.2 Function Manifold (from 36045)....60
211.3 Function Manifold - Models with Traction Control....62
212.1 Ground Controls (to SN 28695)....64
212.2 Ground Controls (from SN 28696)....66
213.1 Hydraulic Hoses and Fittings (to SN 36044)....68
213.2 Hydraulic Hoses and Fittings (from 36045)....70
214.1 Power Cables - Drive Chassis (to SN 6899)....74
214.2 Power Cables - Drive Chassis (from SN 6900)....76

300 Scissor Components

301.1 Scissor Assembly, GS-2046, View 1 (to SN 23567)....78
301.2 Scissor Assembly, GS-2046, View 1 (from SN 23568)....80
302.1 Scissor Assembly, GS-2046, View 2 (to SN 23567)....82
302.2 Scissor Assembly, GS-2046, View 2 (from SN 23568)....84
303.1 Scissor Assembly, GS-2646, View 1 (to SN 23567)....86
303.2 Scissor Assembly, GS-2646, View 1 (from SN 23568)....88
304.1 Scissor Assembly, GS-2646, View 2 (to SN 23567)....90
304.2 Scissor Assembly, GS-2646, View 2 (from SN 23568)....92
305.1 Scissor Assembly, GS-3246, View 1 (to SN 23567)....94
305.2 Scissor Assembly, GS-3246, View 1 (from SN 23568)....96
306.1 Scissor Assembly, GS-3246, View 2 (to SN 23567)....98
306.2 Scissor Assembly, GS-3246, View 2 (from SN 23568)....100

400 Platform Components

401.1 Platform Installation....102
402.1 Platform Railings and Entry Gate - Rigid Rails (to SN 42999)....104
402.2 Platform Railings and Entry Gate - Fold Down Rails, Round Tube (to SN 42999)....106
402.3 Platform Railings and Entry Gate - Fold Down Rails, Square Tube (from SN 23568)....108
403.1 Platform Extension - Rigid Rails....110
403.2 Platform Extension - Fold Down Rails, Round Tube....112
403.3 Platform Extension - Fold Down Rails, Square Tube....114
404.1 Power to Platform - Rigid Rails....116
404.2 Power to Platform - Fold Down Rails....118
405.1 Control Cable - Chassis to Platform....120
406.1 Platform Controls (to SN 17407)....122
406.2 Platform Controls (from SN 17408 to 42999)....124
406.3 Platform Controls (from SN 43000 to 48054)....126
406.4 Platform Controls (from SN 48055)....128
407.1 Joystick Controller (to SN 17407)....130

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

407.2 Joystick Controller (from SN 17408 to 48054).....132
407.3 Joystick Controller (from SN 48055).....134

500 Accessories
501.1 Alarms - Horn and Flashing Beacon.....136
502.1 Air Line to Platform.....138
503.1 Platform Worklight.....140
504.1 Platform Overload Protection.....142
505.1 Voltage Inverter.....144
506.1 Battery - Maintenance Free.....146
507.1 Pipe Cradle Assembly.....148

Indices
Part Number Index.....150
Part Description Index.....154

Cross References
Fittings Cross Reference.....160

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	39612GT	DECAL,JOYSTICK** *(Gen I)*	1
2	52864GT	DECAL,JOYSTICK CONTROLLER *(Gen II)*	1
3	66157GT	OVERLAY,PLAT CONTROLLER SLAB *(Gen III)*	1
4	78673GT	OVERLAY, PLAT CONTRL BOX,GEN4~ *(Gen IV)*	1

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

This Page Intentionally Left Blank

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
--	66380GT	CHARGER,MAINT. FREE-GS	
1		Ref. Battery Charger *(refer to Figure 203.1, 203.2, 203.3 or 203.4)*	
2	105150GT	BATTERY, AGM, 6V, (TROJAN) ***	4
3	18503GT	NUT,LOCKING-LG.FLANGE,5/16-18	8
4	10107GT	SCREW,HHC,5/16-18 X .75	8

MidWestTech | Terex Genie GS-2046, GS-2646, GS-3246 Scissor Lift Parts Manual | Publi... Order the manual at mid-west-tech.com >