A TEREX BRAND

Parts Manual

Serial Number Range

GS-2668 RT

GS-3268 RT

to SN 41199

Part No. 52301

Rev G3

November 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals
101.1 Decals....10

200 Drive Chassis Components
201.1 Steer Axle Linkage, Wheels and Drive Motors....14
202.1 Non-Steer Axle and Drive Motors....16

300 Engine Components
301.1 Kubota DF-750 and DF-752 Engine, View 1....18
302.1 Kubota DF-750 and DF-752 Engine, View 2....20
303.1 Kubota DF-750 and DF-752 Engine, View 3....22
304.1 Kubota DF-750 and DF-752 Engine, View 4....24
305.1 Kubota D-905 Engine, View 1....26
306.1 Kubota D-905 Engine, View 2....28
307.1 Kubota D-905 Engine, View 3....30
308.1 Kubota D-905 Engine, View 4....32

400 Chassis Components
401.1 Engine Tray Components....34
402.1 Hydraulic Tank and Ground Controls Installation....36
403.1 Hydraulic Tray Components....38
404.1 Ground Controls....40
405.1 LPG Tank....42
406.1 Function Manifold....44
407.1 Chassis Covers....46
408.1 Hydraulic Hoses and Fittings (to SN 5849)....48
409.1 Hydraulic Hoses and Fittings (from SN 5850)....50

500 Scissor Components
501.1 Scissor Components, View 1....52
502.1 Scissor Components, View 2....54
503.1 Scissor Components, View 1....56
504.1 Scissor Components, View 2....58

600 Platform Components
601.1 Platform Installation....60
602.1 Platform Railing....62
603.1 Platform Entry Gate....64
604.1 Platform Extension....66
605.1 Platform Extension Deck Lock....68
606.1 Power to Platform....70
607.1 Platform Controls....72
608.1 Joystick Controller....74

700 Link Guard Components
701.1 Wire Mesh Link Guard Components, View 1....76
702.1 Wire Mesh Link Guard Components, View 2....78
703.1 Wire Mesh Link Guard Components, View 3....80
704.1 Wire Mesh Link Guard Components, View 4....82
705.1 Wire Mesh Link Guard Components, View 5....84
706.1 Rigid Link Guard Components, View 1....86
707.1 Rigid Link Guard Components, View 2....88
708.1 Rigid Link Guard Components, View 3....90
709.1 Steel Panel Link Guard Assembly....92

800 Accessories
801.1 Flashing Beacon....94
802.1 Generator....96
803.1 Hydraulic Hoses and Fittings - Generator....98
804.1 Spare LPG Tank....100
805.1 Vented Engine Door....102
806.1 Outrigger Cylinder and Footpad Installation....104
807.1 Outrigger Installation....106
808.1 Hydraulic Hoses and Fittings - Outriggers....108
809.1 Platform Work Light....110
810.1 Pipe Cradle Assembly....112
811.1 Platform Overload Sensor....114
812.1 Outrigger Manifold....116

Indices
Part Number Index....118
Part Description Index....122


Cross References
Fittings Cross Reference....128

MidWestTech | Terex Genie GS-2668 RT, GS-3268 RT Scissor Lift Parts Manual | Publicati... Order the manual at mid-west-tech.com >

101.1 Decals (continued)

Item	Part No.	Description	Qty.
41	28176GT	DECAL,LABEL,MANUAL NOT HERE	1

MidWestTech | Terex Genie GS-2668 RT, GS-3268 RT Scissor Lift Parts Manual | Publicati... Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie GS-2668 RT, GS-3268 RT Scissor Lift Parts Manual | Publicati... Order the manual at mid-west-tech.com >

Fitting Cross References (Continued)

Genie PN	Parker PN	Description
48892	6 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS
48893	6 F5OHAO-S	UNION,STRAIGHT THREAD
48894	6 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48895	DT-370-MSMO-5	VALVE,CHECK
48896	6 JLO-S	UNION,TEE,ORFS
48897	DT-750-MSMS-5	VALVE,CHECK
48898	DT-750-MOMS-5	VALVE,CHECK
48899	DT-620-MOMS-5	VALVE,CHECK
48900	4-6 F5OLO-SW.035	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.035 ORI
48902	16-1 ACE4G-S	ELBOW,90° LONG,FEMALE PIPE TO STRAIGHT THREAD
48903	1 FF-S	NIPPLE,PIPE
48904	4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48905	4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48906	4 R5OLO-S	RUN TEE,STRAIGHT THREAD
48907	4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48908	4 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48909	4 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48910	4 GTX-S W.030	CONNECTOR,FEMALE PIPE TO FLARE TUBE
48911	4-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48912	4-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48913	4-6 F5OLO-SW.030	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.030 ORI
48914	4-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48915	6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48916	6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48917	6 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48918	6 R5OLO-S	RUN TEE,STRAIGHT THREAD
48919	6 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48920	6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48921	6 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48922	6-6 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48923	6 P5ON-S	PLUG,STRAIGHT THREAD
48925	6 WELO-S	UNION,90° BULKHEAD,ORFS
48926	6-4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48927	6-4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48928	6-4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48929	6-8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48930	6-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48931	6-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48932	8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48933	8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48934	8 FF5OLD-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48935	8 R5OLO-S	RUN TEE,STRAIGHT THREAD
48936	8 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48937	8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48938	8 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48939	8 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS
48940	8 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48941	8-4 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
48942	8-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48943	8-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48944	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48945	8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
48946	8-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48947	8-12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48948	8-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48949	8-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48950	10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48951	10 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS
48952	10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48953	10 R5OLO-S	RUN TEE,STRAIGHT THREAD
48954	10 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48955	10 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48956	10-4 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48957	10-6 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48958	10-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48959	12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48960	12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48961	12 R5OLO-S	RUN TEE,STRAIGHT THREAD
48962	12 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48963	12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48964	12 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48965	12 CLO-S	ELBOW,90° MALE PIPE TO ORFS
48966	12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48967	12 JLO-S	UNION TEE,ORFS
48968	12 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48969	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48970	12 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS

MidWestTech | Terex Genie GS-2668 RT, GS-3268 RT Scissor Lift Parts Manual | Publicati... Order the manual at mid-west-tech.com >