865B AWD Motor Grader
Tier III

Parts Catalog

Print No. 542200126PC
Issued 6/2016

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-02	01	ENGINE AND SUPPORTS
02-04	01	CYLINDER BLOCK - MAIN BEARINGS
02-05	01	ENGINE - LIFT HOOKS
02-06	01	CYLINDER HEAD - COVERS
02-07	01	CYLINDER HEAD - VALVE MECHANISM
02-08	01	CYLINDER HEAD
02-09	01	FRONT GEAR COVER
02-10	01	CYLINDER BLOCK - PLUGS AND PISTONS
02-11	01	CAMSHAFT
02-12	01	PULLEY AND FLYWHEEL
02-12	02	PULLEY AND FLYWHEEL
02-13	01	ENGINE - PISTON
02-14	01	CONNECTING ROD AND BEARING
02-15	01	CRANKSHAFT
02-16	01	AIR CLEANER
02-17	01	AIR CLEANER (84187203)
02-18	01	INTAKE MANIFOLD
02-19	01	MANIFOLD - EXHAUST
02-20	01	MUFFLER AND EXHAUST PIPE
02-21	01	AFTER COOLER
02-23	01	TURBOCHARGER
02-24	01	TURBOCHARGER DRAIN LINE
02-25	01	OIL PUMP, RESERVOIR
02-26	01	DIPSTICK AND INTRODUCTION CAP
02-27	01	GEAR COVER - REAR HOUSING
02-28	01	FLYWHEEL HOUSING
02-29	01	GEAR COVER PLATE - POWER TAKE - OFF
02-30	01	PUMP DRIVE GEAR
02-31	01	BREATHER - ENGINE
02-32	01	OIL FILTER AND COOLER
02-33	01	WATER PUMP - CONTROL
02-34	01	ASSEMBLY RADIATOR
02-35	01	PIPING ENGINE OIL COOLER
02-36	01	WATER TANK AND PIPING

Order the manual at mid-west-tech.com >

02-37	01	FAN DRIVE
02-38	01	FAN DRIVE
02-39	01	FAN DRIVE
02-40	01	FAN DRIVE REVERSER SYSTEM
02-41	01	FAN DRIVE REVERSER SYSTEM
02-42	01	FAN DRIVE REVERSER SYSTEM
02-44	01	WATER PUMP
02-45	01	ENGINE - COOLING SYSTEM
02-46	01	THERMOSTAT - ENGINE COOLING SYSTEM
03-01	01	FUEL LINES
03-02	01	WATER SEPARATOR FILTER
03-03	01	FUEL TANK
03-04	01	FUEL TANK
03-05	01	THROTTLE CONTROL LINKAGE
03-07	01	FUEL FILTER
03-08	01	FUEL INJECTION PUMP
03-09	01	FUEL INJECTION TUBES
03-10	01	FUEL INJECTION SYSTEM - INJECTOR
03-11	01	FUEL PIPING
03-12	01	FUEL INJECTION SYSTEM - DRAIN LINE
03-13	01	HARNESS, ENGINE ELECTRONIC CONTROL MODULE
03-14	01	FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL
04-34	01	BLOCK HEATER
04-01	01	STARTER & ALTERNATOR
04-02	01	ALTENATOR COMPONENTS
04-03	01	STARTER
04-04	01	BATTERY AND HARNESS
04-05	01	HARNESS, ELECTRICAL SYSTEM
04-06	01	ELECTRICAL SYSTEM, REAR FRAME
04-07	01	ELECTRICAL SYSTEM, REAR FRAME
04-08	01	ELECTRICAL SYSTEM, REAR FRAME
04-09	01	ELECTRICAL SYSTEM, REAR FRAME
04-10	01	ELECTRICAL SYSTEM, FRONT FRAME
04-11	01	ELECTRICAL SYSTEM, FLOOR - (DIRECT DRIVE)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-12	01	ELECTRICAL SYSTEM, FPT ENGINE
04-13	01	ELECTRICAL SYSTEM, FPT ENGINE
04-14	01	ELECTRICAL SYSTEM, FPT ENGINE
04-15	01	ELECTRICAL SYSTEM, FPT ENGINE
04-17	01	ELECTRICAL SYSTEM, LATERAL CONSOLE
04-18	01	ELECTRICAL SYSTEM
04-19	01	ELECTRICAL SYSTEM - TRANSMISSION
04-20	01	ELECTRICAL SYSTEM - HYDRAULIC ACCUMULATOR (AUX. EQUIPMENT OPCIONAL)
04-21	01	ELECTRICAL SYSTEM, LATERAL CONSOLE
04-22	01	ELECTRICAL SYSTEM, LATERAL CONSOLE - FUSES
04-23	01	ELECTRICAL SYSTEM, LATERAL CONSOLE
04-24	01	INSTRUMENT PANEL, STD - (DIRECT DRIVE)
04-25	01	INSTRUMENT PANEL, OPTIONALS
04-26	01	INSTRUMENT PANEL, FRONT CONSOLES
04-27	01	INSTRUMENT PANEL, FRONT CONSOLES
04-28	01	INSTRUMENT PANEL, FRONT CONSOLES
04-29	01	VOLTAGE CONVERTER 24V/12V
04-30	01	AIR CONDITIONER ELECTRICAL SYSTEM
04-31	01	BEACON LIGHT - COMPONENTS
04-32	01	WORK LIGHTING SYSTEM
04-33	01	FAN, CAB
04-35	01	TELEMATICS SYSTEM
04-35	02	TELEMATICS SYSTEM
00.01	01	DEALER INITIAL STOCK LIST (ISL)
05-01	01	OPERATOR'S CONSOLE - STEERING HYDRAULIC SYSTEM
05-02	01	OPERATOR'S CONSOLE - CLAMPS
05-03	01	OPERATOR'S CONSOLE
05-04	01	OPERATOR'S CONSOLE
05-05	01	OPERATOR'S CONSOLE
05-06	01	OPERATOR'S CONSOLE
05-07	01	OPERATOR'S CONSOLE
06-01	00	TRANSMISSION, SUPPORTS - (DIRECT DRIVE)
06-01	01	TRANSMISSION AND COUPLING
06-01	02	TRANSMISSION - HOUSING AND INPUT SHAFT

Order the manual at mid-west-tech.com >