"S" Series Tractors

Service Manual

5630

CASE IH AGRICULTURE

MidWestTech | Case S, SO, SC, SE Tractor Service Manual | Publication 5630

Order the manual at mid-west-tech.com >

INDEX

	PAGE NO.
Adding Weight to Tractor	62
Air Cleaner	26
Belt Pulley, SE Engine Unit	47
Belt Work	68
Brakes, Assisting	56
Brake, Belt Pulley	59
Camshaft	41
Carburetor	25
Clutch, Adjusting Tractor	42
Clutch Assembly, Removing	35
Clutch Housing	11
Clutch, SE Engine Unit	46
Cold Weather Operation	15
Connecting Rods	33
Cooling System	14
Crankcase Breather	11
Crankcase Oil	10
Crankshaft	39
Cylinder Head	32
Cylinder Sleeves	35
Differential	54
Drawbar	68
Drive Chains	53
Engine, Removing	38
Engine Unit, Model SE	46
Fan Belt	15
Front Wheels	59
Fuel Filter	26
Gasoline Manifold	27
Generator	21
Governor	22
Hydraulic Control Lubrication	13
Hydraulic Control Unit	68
Ignition	17
Low Cost Fuel Manifold	28
Lubrication	7
Magneto	18
Motor Lift	66
Motor Lift Lubrication	14
Oil Filter	12

	PAGE NO.
Oil Pan, Engine	32
Oil Pressure	10
Oil Pump	42
Oil Pump Screen	11
Pistons	33
Piston Rings	34
Power Take-Off	63
Radiator	15
Radiator Shutter	29
Rear Axle Bearing Adjustment	54
Rear Wheel Spacing	59
Rubber Tires	61
Running In a New Engine	7
Seat	69
Serial Number	69
Service Suggestions	48
Spark Plugs	20
Specifications	4
Speeds, Travel	5
Spiral Bevel Gears, Adjusting	50
Splitting Tractor	35
Starting Motor	21
Starting the Engine	6
Static Electricity	68
Steering Gear	55
Stopping Engine	7
Storage Battery	17
Thermostat	17
Timing Gears	40
Tires, Removing and Installing	63
Tractor and Engine Operation	6
Transmission Breather	13
Transmission Case Top Cover	50
Transmission and Differential	50
Transmission Oil	12
Use of Different Fuels	27
Valves	30
Warranty	71
Water Pump	15

MidWestTech | Case S, SO, SC, SE Tractor Service Manual | Publication 5630 Order the manual at mid-west-tech.com >