400
Tractor

Service Manual

5692

MidWestTech | Case 400, 441 Tractor Service Manual | Publication 5692

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

PAGE

I. SERVICE SHOP PROFIT THROUGH SEASONAL TUNE UP ..... A-3 thru A-10

II. PROCEDURE FOR USING A TUNE-UP TESTER ON 400 SERIES DISTRIBUTOR IGNITION ENGINES ..... A-11 thru A-28

Volts Ignition Tester ..... A-12 thru A-18
- Cranking Voltage Test A-12
- Charging Voltage Test A-14
- Secondary Resistance and Polarity Test A-16
- Ignition Output and Leakage Test A-18

Tach-Dwell Tester ..... A-20 thru A-22
- Measuring Engine Speed A-20
- Dwell and Dwell Variation Tests A-22

Vacuum — Pressure Tester A-24
- Manifold Vacuum Test A-24

Electronic Distributor Tester ..... A-26 thru A-28
- Distributor Advance Test A-26
- Ignition Timing Test ..... A-27 and A-28

III. TEST PROCEDURE FOR THE STARTING CIRCUIT AND CHARGING CIRCUIT ..... A-29 thru A-42

The Starting Circuit ..... A-30 thru A-38
- Battery Visual Inspection A-30
- Battery Specific Gravity Test A-31
- Battery Capacity Test A-32
- Cranking Voltage Test A-35
- Cable and Switch Tests A-36
- Ground Cable Test A-37
- Starting Motor Amperage Draw Test A-38

The Charging Circuit ..... A-39 thru A-42
- Introduction A-39
- Generator A-40
- Circuit Breaker A-41
- Voltage Control A-42

IV. SERVICING THE SPARK PLUGS AND DISTRIBUTOR ..... A-43 thru A-57

Spark Plugs ..... A-44 thru A-48
- Introduction A-44
- Removal and Inspection A-45
- Spark Plug Heat Range A-46
- Cleaning and Installation A-48

Distributor ..... A-49 thru A-57
- Introduction A-49
- Contact Point and Condenser Removal and Installation ..... A-50 thru A-53
- Inspection of Distributor Cap, Rotor and Cam A-54
- Checking and Setting Ignition Timing A-56

MidWestTech | Case 400, 441 Tractor Service Manual | Publication 5692 Order the manual at mid-west-tech.com >