A TEREX BRAND

Parts Manual

Serial Number Range

GTH-4014 IIIA	from SN GTH401415B-146 to GTH401416B-150
GTH-4014 IIIB	from SN GTH401416M-151 to SN GTH401419M-232
GTH-4018 IIIA	from SN GTH401815B-153 to GTH401816B-158
GTH-4018 IIIB	from GTH401816M-159 to SN GTH401819M-319

Part No. 57.0411.0047

Rev H

October 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List
001.1 Parts Stocking List....10

100 Decals
101.1 609560 Decals....12
102.1 609561 Load Charts....14

200 Drive Chassis Components
201.1 609562 Boom Movement And Steering Main Valve....18
202.1 609563 Outriggers And Axle Levelling Main Valve....20
203.1 609564 Rear Frame....22
204.1 609565 Left Frame....24
205.1 609566 Right Frame....26
206.1 609567 Outriggers....28
207.1 609568 Hydraulic Oil Tank....30
208.1 609569 Driveline And Wheels....32
209.1 609570 Front Axle - Housing....34
210.1 609571 Rear Axle - Housing....36
211.1 609572 Front And Rear Axle - Differential....38
212.1 609573 Front And Rear Axle - Brakes....40
213.1 609574 Front And Rear Axle - Bevel Gear Set....42
214.1 609575 Front And Rear Axle - Swivel Housings And Steering Cylinder....44
215.1 609576 Front And Rear Axle - Double U-Joint Wheel Hub Final Reduction....46
216.1 609577 Transmission Housing....48
217.1 609578 Transmission Gear And Shafts....50
218.1 609579 Transmission Rear Support....52

300 Engine Components
301.1 609581 Diesel Engine And Accessories - Stage IIIA Engine....54
301.2 609582 Diesel Engine And Accessories - Stage IIIB Engine....56
302.1 609583 Fuel Circuit - Stage IIIA Engine....58
302.2 609584 Fuel Circuit - Stage IIIB Engine....60
303.1 609585 Cooling System - Radiator - Stage IIIA....62
303.2 609586 Cooling System Circuit - Radiator - Stage IIIB....64
304.1 609587 Cooling System - Hoses - Stage IIIA....66
304.2 609588 Cooling System - Hoses - Stage IIIB....68
305.1 609589 Exhaust System - Stage IIIA Engine....70
305.2 609590 Exhaust System - Stage IIIB Engine (For GTH4014 to SN 401416M-185, for GTH401416M-189, 191-195; for GTH4018 to SN GTH401816M-173, for GTH401816M-176-206, 215, 217-227)....72
305.4 609668 Exhaust System - Stage IIIB Engine (for GTH4014 from SN GTH401416M-186-188, for GTH401416M-190, from GTH401416M-196; for GTH4018 for SN GTH401816M-174-175, 207-214, 216, from SN GTH401816M-228)....74
306.1 609591 Air Filter - Stage IIIA Engine (For GTH4014 to SN GTH401416M-197; For GTH4018 to SN GTH401816M-224)....76
306.2 609592 Air Filter - Stage IIIB Engine (For GTH4014 to SN 401416M-185, for GTH401416M-189, 191-195; for GTH4018 to SN GTH401816M-173, for GTH401816M-176-206, 215, 217-227)....78
306.3 609670 Air Filter - Stage IIIA Engine (For GTH4014 from SN GTH401416M-198; For GTH4018 from SN GTH401816M-225)....80
306.4 609669 Air Filter - Stage IIIB Engine (for GTH4014 from SN GTH401416M-186-188, for GTH401416M-190, from GTH401416M-196; for GTH4018 for SN GTH401816M-174-175, 207-214, 216, from SN GTH401816M-228)....82
307.1 609593 Hydraulic Pumps....84

400 Cab Components
401.1 609595 Cab - View 1....86
402.1 609596 Cab - View 2....88
403.1 609597 Cab - View 3....90
404.1 609598 Cab - View 4....92
405.1 609599 Seat Assembly....94
406.1 609600 Dashboard....96
407.1 609601 Cab Heater....98

500 Boom Components
501.1 609604 Boom 1st Section - GTH-4014....100
502.1 609605 Boom 2nd And 3rd Section - GTH-4014....102
503.1 609606 Boom 1st And 2nd Section - GTH-4018....104
504.1 609607 Boom 3rd And 4th Section - GTH-4018....106
505.1 609608 1st Boom Section Chain Unit - GTH-4018....108

MidWestTech | Terex Genie GTH-4014 IIIA, GTH-4014 IIIB, GTH-4018 MA, GTH-4018 MB... Order the manual at mid-west-tech.com >

506.1 609609 2nd Boom Section Chain Unit - GTH-4018.110
507.1 609610 3rd Boom Section Chain Unit - GTH-4018..112
508.1 609611 4th Boom Section Chain Unit - GTH-4018..114
509.1 609612 Coupling Unit....116
510.1 609613 Lift, Tilt And Forks Levelling Cylinders....118
511.1 609614 Boom Extension Cylinders - GTH-4014....120
512.1 609615 Boom Extension Cylinder - GTH-4018....122
513.1 609616 Axle Levelling, Outriggers Cylinders....124
514.1 609617 Forks....126

600 Hydraulic System
601.1 609620 Axle Levelling, Outriggers....128
602.1 609621 Lifting....130
603.1 609622 Fork Balancing - GTH-4014....132
604.1 609623 Auxiliary Hydraulic Line - GTH-4014....134
605.1 609624 Boom Extension - GTH-4014....136
606.1 609625 Fork Balancing - GTH-4018....138
607.1 609626 Auxiliary Hydraulic Line - GTH-4018....140
608.1 609627 Boom Extension - GTH-4018....142
609.1 609628 Power Steering....144
610.1 609629 Oil Cooler - Stage IIIA Engine....146
610.2 609630 Oil Cooler - Stage IIIB Engine....148
611.1 609631 Hydraulic Pumps....150
612.1 609632 Service Brake....152
613.1 609633 Parking Brake....154
614.1 609634 Hydrostatic Transmission Part 1....156
615.1 609635 Hydrostatic Transmission Part 2....158
616.1 609636 Auxiliary Manifold Tank Line....160
617.1 609637 Gear Box....162

700 Electric Installation
701.1 609638 Instruments And Light Panel....164
702.1 609639 Relay-Fuse Box....166
703.1 609640 Engine Line....168
704.1 609641 Chassis Line....170
705.1 609642 Rear Chassis....172
706.1 609643 Dashboard Line....174
707.1 609644 Upper Cabin Line....176
708.1 609645 Overload Warning System....178

800 Optionals
801.1 609646 Agricolture Towing Hook....180
802.1 609647 Windshield Protection....182
803.1 609648 Boom Electric Line - GTH-4014....184
804.1 609649 Boom Electric Line - GTH-4018....186
805.1 609650 Hydraulic Quick Coupling And 1 Aux Circuit.188
805.2 609666 1 Aux Circuit....190
806.1 609651 Hydraulic Quick Coupling And 2 Aux Circuits....192
806.2 609667 2 Aux Circuit....194
807.1 609652 Rear Video Camera and Power Pack....196
808.1 609653 Air Conditioning, Cabin Part....198
809.1 609654 Air Conditioning, Engine Part....200
810.1 609655 Wiper On Cab Roof....202
811.1 609656 T.U.V. Dotation....204
812.1 609657 Manplatform Predisposition - View 1....206
813.1 609658 Manplatform Predisposition - View 2....208
814.1 609659 GM-1 Articulation....210
815.1 609660 Italian Road Homologation Kit....212
816.1 609661 Boom Work Light....214
817.1 609662 Cabin Work Lights....216
818.1 609663 LMI Tower Lights....218
819.1 609664 Fem 3 Forks....220
820.1 609665 Fork Side Shift....222


Indices
Part Number Index....224
Part Description Index....231

Cross References
Fittings Cross Reference....240

MidWestTech | Terex Genie GTH-4014 IIIA, GTH-4014 IIIB, GTH-4018 MA, GTH-4018 MB... Order the manual at mid-west-tech.com >

306.2 609592 Air Filter - Stage IIIB Engine (For GTH4014 to SN 401416M-185, for GTH401416M-189, 191-195; for GTH4018 to SN GTH401816M-173, for GTH401816M-176-206, 215, 217-227)

STAGE III B




MidWestTech | Terex Genie GTH-4014 IIIA, GTH-4014 IIIB, GTH-4018 MA, GTH-4018 MB... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	55.0602.1015GT	Upper Cabin Line	1
2	56.0010.0005GT	Flashing Beacon	1
3	07.0703.0384GT	BULB	1

MidWestTech | Terex Genie GTH-4014 IIIA, GTH-4014 IIIB, GTH-4018 MA, GTH-4018 MB... Order the manual at mid-west-tech.com >

820.1 609665 Fork Side Shift



MidWestTech | Terex Genie GTH-4014 IIIA, GTH-4014 IIIB, GTH-4018 MA, GTH-4018 MB... Order the manual at mid-west-tech.com >