A TEREX BRAND

Parts Manual

Serial Number Range

GTH-4016R IIIB from SN GTH4016R15M-101 to SN GTH4016R17M-113

GTH-4018R IIIB from SN GTH4018R15M-101 to SN GTH4018R17M-122

Part No. 57.0411.0048

Rev D

June 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals

101.1 609240 Decals - View 1....10
102.1 609241 Decals - View 2....12
103.1 609242 Decals - View 3....14
104.1 609372 Load Charts....18

200 Drive Chassis Components

201.1 609243 Basic Frame Chassis....22
202.1 609244 Engine Casing Unit....24
203.1 609245 Slewing Upper Structure - View 1....26
204.1 609246 Slewing Upper Structure - View 2....28
205.1 609247 Transmission And Wheels....30
206.1 609248 Hydraulic Oil And Diesel Tanks....32
207.1 609249 Outriggers - Only For GTH-4016 R....34
208.1 609250 Outriggers - Only For GTH-4018 R....36
209.1 609251 Outriggers - Only For GTH-4018 R....38
210.1 609253 Front Axle - Housing....40
211.1 609254 Front And Rear Axle - Differential....42
212.1 609255 Front And Rear Axle - Bevel Gear Set....44
213.1 609256 Front And Rear Axle - Double U Joint - Hub And Final Reduction....46
214.1 609257 Front And Rear Axle - Steering Cylinder And Swivel Housing....48
215.1 609258 Front And Rear Axle - Brakes....50
216.1 609259 Rear Axle - Housing....52
217.1 609260 Transmission Housing....54
218.1 609261 Transmission Gear And Shafts....56
219.1 609262 Transmission Rear Support....58
220.1 609263 Turret Rotation - Reduction Gear....60
221.1 609264 Hydraulic Oil Cooler....62

300 Engine Components

301.1 609265 Diesel Engine....64
302.1 609266 Engine Cooling System - Air Filter....66
303.1 609267 Engine Heatsink....68
304.1 609268 Exhaust System And Accelerator....70
305.1 609269 Hydraulic Pumps....72

400 Cab Components

401.1 609271 Cab - View 1....74
402.1 609272 Cab - View 2....76
403.1 609273 Cab - View 3....78
404.1 609274 Cab - View 4....80
405.1 609275 Seat Assembly....82
406.1 609276 Dashboard....84
407.1 609277 Heater, Cab Part....86
408.1 609278 Heater, Engine Part....88
409.1 609279 Heater, Fan And Element....90

500 Boom Components

501.1 609282 1st Telescopic Element GTH-4016 R....92
502.1 609283 2nd And 3rd Telescopic Element GTH-4016 R....94
503.1 609284 1st And 2nd Telescopic Element GTH-4018 R....96
504.1 609285 3rd And 4th Telescopic Element GTH-4018 R....98
505.1 609286 Chain Unit 1st Boom Section GTH-4018 R.100
506.1 609287 Chain Unit 2nd Boom Section GTH-4018 R.102
507.1 609288 Chain Unit 3rd Boom Section GTH-4018 R.104
508.1 609289 Chain Unit 4th Boom Section GTH-4018 R.106
509.1 609290 Coupling Unit....108
510.1 609291 Forks....110
511.1 609292 Lifting Cylinder - Slave Cylinder - Tilting Cylinder....112
512.1 609293 Boom Extension Cylinder GTH-4016 R....114
513.1 609294 Boom Extension Cylinder GTH-4018 R....116

600 Hydraulic System

601.1 609296 Boom Extension Cylinder - Only For GTH-4016 R....118
602.1 609297 Boom Extension Cylinder - Only For GTH-4018 R....120
603.1 609298 Fork Balancing Cylinders - Only For GTH-4016 R....122
604.1 609299 Fork Balancing Cylinders - Only For GTH-4018 R....124
605.1 609300 Attachment - Only For GTH-4016 R....126
606.1 609301 Attachment - Only For GTH-4018 R....128
607.1 609302 Rear Axle Pivoting Cylinders....130

MidWestTech | Terex Genie GTH-4016R MB, GTH-4018R MB Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

608.1 609303 Front Outriggers - Only For GTH-4016 R....132
609.1 609304 Rear Outriggers - Only For GTH-4016 R....134
610.1 609305 Front Outriggers - Only For GTH-4018 R....136
611.1 609306 Rear Outriggers - Only For GTH-4018 R....138
612.1 609307 Hoses Fittings Holder Plate....140
613.1 609308 Lift Cylinder....142
614.1 609309 Slewing Upper Structure Rotation....144
615.1 609310 Service Brake, Parking Brake, Differential Lock Solenoid Valve - Part 1....146
616.1 609311 Service Brake, Parking Brake, Differential Lock Solenoid Valve - Part 2....148
617.1 609312 Brakes Max Pressure Valve....150
618.1 609313 Power Steering....152
619.1 609314 Hydraulic Oil Cooling Circuit....154
620.1 609315 Suction System Hydraulic Pumps....156
621.1 609316 Hydraulic Transmission....158
622.1 609317 Shift Gear Solenoid Valve....160
623.1 609318 Pressure Plugs....162
624.1 609319 Slewing Upper Structure Hoses Locking System....164
625.1 609320 Main Valve Locking And Outriggers Solenoid Valve Block....166
626.1 609321 Main Valve - Elements - For GTH 4018R to SN GTH4018R16M-104....168
626.2 609362 Main Valve - Elements - For GTH 4016R; For GTH 4018R From SN GTH4018R16M-105....170

700 Electric Installation

701.1 609324 Cabine Fuse - Relay Box....172
702.1 609325 Engine Line....174
703.1 609326 Base Frame Line....176
704.1 609327 Slewing Upper Structure Line - Part 1....178
705.1 609328 Slewing Upper Structure Line - Part 2....180
706.1 609329 Auxiliary Hydraulic Circuit And Attachment - Only For GTH-4016 R....182
707.1 609330 Auxiliary Hydraulic Circuit And Attachment - Only For GTH-4018 R....184
708.1 609331 Dashboard Line....186
709.1 609332 Side Cab Line....188
710.1 609333 Dashboard....190
711.1 609334 Connectors....192
712.1 609335 Connectors....194
713.1 609336 Connectors....196
714.1 609337 Connectors....198
715.1 609338 Connectors....200
716.1 609339 Connectors....202
717.1 609340 Connectors....204

800 Optionals

801.1 609350 Man Platform Predisposition - Emergency Pump - View 1....206
801.2 609351 Man Platform Predisposition - Emergency Pump - View 2....208
802.1 609345 Transport Locking Device....210
803.1 609346 Hydraulic Jack....212
804.1 609347 Air Conditioning - View 1....214
804.2 609348 Air Conditioning - View 2....216
804.3 609349 Air Conditioning - View 3....218
805.1 609352 Mixing Bucket Predisposition....220
806.1 609353 Windscreen Protection and Power Pack....222
807.1 609354 Windscreen Wiper....224
808.1 609355 Boom Work Light....226
809.1 609356 Cabin Work Light....228
810.1 609357 Twing Hitch....230
811.1 609358 Remote Radio Control And Green Light....232
812.1 609360 Fem 3 Forks....234
815.1 609359 GM-1 Articulation....236
816.1 609361 LMI Tower Lights....238
817.1 609363 Chassis Levelling - View 1....240
818.1 609364 Chassis Levelling - View 2....242
819.1 609365 Continous Rotating 360° - Joint....244
820.1 609366 Continous Rotating 360° - Cab Heater Hoses....246
821.1 609367 Continous Rotating 360° - Outriggers....248
822.1 609368 Continous Rotating 360° - Service Brake....250
823.1 609369 Continous Rotating 360° - Power Steering..252
824.1 609370 Continous Rotating 360° - Hydraulic Oil Radiator....254
825.1 609371 Continous Rotating 360° - Chassis Levelling....256
826.1 609373 Auxiliary Hydraulic Circuit....258
827.1 609374 Hydraulic Quick Coupling And 1 Aux Circuit.260
828.1 609375 Hydraulic Quick Coupling And 2 Aux Circuits....262

Indices


Part Number Index....264
Part Description Index....271

Cross References

Fittings Cross Reference....282


MidWestTech | Terex Genie GTH-4016R MB, GTH-4018R MB Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

816.1 609361 LMI Tower Lights




MidWestTech | Terex Genie GTH-4016R MB, GTH-4018R MB Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

822.1 609368 Continous Rotating 360° - Service Brake



MidWestTech | Terex Genie GTH-4016R MB, GTH-4018R MB Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

828.1 609375 Hydraulic Quick Coupling And 2 Aux Circuits



MidWestTech | Terex Genie GTH-4016R MB, GTH-4018R MB Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >