A TEREX BRAND

Parts Manual

Serial Number Range

GTH-4016R_IIIA from SN GTH4016R15M-101 to SN GTH4016R17M-113

GTH-4018R_IIIA from SN GTH4018R15M-101 to GTH4018R17M-122

Part No. 57.0411.0056GT

Rev B

June 2018

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

001 Parts Stocking List
001.1 Parts Stocking List....10

100 Decals
101.1 610570 Decals, View 1....12
102.1 610571 Decals, View 2....14
103.1 610572 Decals, View 3....16
104.1 610573 Load Charts....18

200 Drive Chassis Components
201.1 610576 Basic Frame Chassis....22
202.1 610577 Engine Casing Unit....24
203.1 610578 Slewing Upper Structure - View 1....26
204.1 610579 Slewing Upper Structure - View 2....28
205.1 610580 Transmission And Wheels....30
206.1 610581 Hydraulic Oil And Diesel Tanks....32
207.1 610582 Outriggers - Only For GTH-4016 R....34
208.1 610583 Outriggers - Only For GTH-4018 R....36
209.1 610584 Outriggers - Only For GTH-4018 R....38
210.1 610585 Front Axle - Housing....40
211.1 610586 Front And Rear Axle - Differential....42
212.1 610587 Front And Rear Axle - Bevel Gear Set....44
213.1 610588 Front And Rear Axle - Double U Joint - Hub And Final Reduction....46
214.1 610589 Front And Rear Axle - Steering Cylinder And Swivel Housing....48
215.1 610590 Front And Rear Axle - Brakes....50
216.1 610591 Rear Axle - Housing....52
217.1 610592 Transmission Housing....54
218.1 610593 Transmission Gear And Shafts....56
219.1 610594 Transmission Rear Support....58
220.1 610595 Turret Rotation - Reduction Gear....60

300 Engine Components
301.1 610601 Diesel Engine....62
302.1 610602 Engine Cooling System - Air Filter....64
303.1 610603 Engine Heatsink....66
304.1 610604 Exhaust System And Accelerator....68
305.1 610605 Hydraulic Pumps....70

400 Cab Components
401.1 610610 Cab - View 1....72
402.1 610611 Cab - View 2....74
403.1 610612 Cab - View 3....76
404.1 610613 Cab - View 4....78
405.1 610614 Seat Assembly....80
406.1 610615 Dashboard....82
407.1 610616 Heater, Cab Part....84
408.1 610617 Heater, Engine Part....86
409.1 610618 Heater, Fan And Element....88

500 Boom Components
501.1 610621 1st Telescopic Element GTH-4016 R....90
502.1 610622 2nd And 3rd Telescopic Element GTH-4016 R....92
503.1 610623 1st And 2nd Telescopic Element GTH-4018 R....94
504.1 610624 3rd And 4th Telescopic Element GTH-4018 R....96
505.1 610625 Chain Unit 1st Boom Section GTH-4018 R....98
506.1 610626 Chain Unit 2nd Boom Section GTH-4018 R.100
507.1 610627 Chain Unit 3rd Boom Section GTH-4018 R.102
508.1 610628 Chain Unit 4th Boom Section GTH-4018 R.104
509.1 610629 Coupling Unit....106
510.1 610630 Forks....108
511.1 610631 Lifting Cylinder - Slave Cylinder - Tilting Cylinder....110
512.1 610632 Boom Extension Cylinder GTH-4016 R....112
513.1 610633 Boom Extension Cylinder GTH-4018 R....114

600 Hydraulic System
601.1 610641 Boom Extension Cylinder - Only For GTH-4016 R....116
602.1 610642 Boom Extension Cylinder - Only For GTH-4018 R....118
603.1 610643 Fork Balancing Cylinders - Only For GTH-4016 R....120
604.1 610644 Fork Balancing Cylinders - Only For GTH-4018 R....122
605.1 610645 Attachment - Only For GTH-4016 R....124
606.1 610646 Attachment - Only For GTH-4018 R....126

MidWestTech | Terex Genie GTH-4016RJIIA, GTH-4018R IIIA Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

607.1 610647 Rear Axle Pivoting Cylinders....128
608.1 610648 Front Outriggers - Only For GTH-4016 R....130
609.1 610649 Rear Outriggers - Only For GTH-4016 R....132
610.1 610650 Front Outriggers - Only For GTH-4018 R....134
611.1 610651 Rear Outriggers - Only For GTH-4018 R....136
612.1 610652 Hoses Fittings Holder Plate....138
613.1 610653 Lift Cylinder....140
614.1 610654 Slewing Upper Structure Rotation....142
615.1 610655 Service Brake, Parking Brake, Differential Lock Solenoid Valve - Part 1....144
616.1 610656 Service Brake, Parking Brake, Differential Lock Solenoid Valve - Part 2....146
617.1 610657 Brakes Max Pressure Valve - Only GTH-4016 R....148
618.1 610658 Brakes Max Pressure Valve - Only GTH-4018 R....150
619.1 610659 Power Steering....152
620.1 610660 Hydraulic Oil Cooling Circuit....154
621.1 610661 Suction System Hydraulic Pumps....156
622.1 610662 Hydraulic Transmission....158
623.1 610663 Shift Gear Solenoid Valve....160
624.1 610664 Pressure Plugs....162
625.1 610665 Slewing Upper Structure Hoses Locking System....164
626.1 610666 Main Valve Locking And Outriggers Solenoid Valve Block....166
627.1 610667 Main Valve - Elements - For GTH-4018 R To SN GTH4018R16M-104....168
627.2 610668 Main Valve - Elements - For GTH-4016 R; For GTH-4018 R From SN GTH4018R16M-105....170

700 Electric Installation

701.1 610671 Cabine Fuse - Relay Box....172
702.1 610672 Engine Line....174
703.1 610673 Base Frame Line....176
704.1 610674 Slewing Upper Structure Line - Part 1....178
705.1 610675 Slewing Upper Structure Line - Part 2....180
706.1 610676 Auxiliary Hydraulic Circuit And Attachment - Only For GTH-4016 R....182
707.1 610677 Auxiliary Hydraulic Circuit And Attachment - Only For GTH-4018 R....184
708.1 610678 Dashboard Line....186
709.1 610679 Side Cab Line....188
710.1 610680 Dashboard....190
711.1 610681 Connectors....192
712.1 610682 Connectors....194
713.1 610683 Connectors....196
714.1 610684 Connectors....198
715.1 610685 Connectors....200
716.1 610686 Connectors....202
717.1 610687 Connectors....204

800 Optionals

801.1 610691 Transport Locking Devices....206
802.1 610692 Plate For Swiss Market....208
803.1 610693 Hydraulic Jack....210
804.1 610694 Auxiliary Hydraulic Circuit....212
805.1 610695 Hydraulic Quick Coupling And 1 Aux Circuit.214
806.1 610696 Hydraulic Quick Coupling And 2 Aux Circuit.216
807.1 610697 Air Conditioning, View 1....218
808.1 610698 Air Conditioning, View 2....220
809.1 610699 Air Conditioning, View 3....222
810.1 610700 Man Platform Predisposition - Emergency Pump, View 1....224
811.1 610706 Man Platform Predisposition - Emergency Pump, View 2....226
812.1 610701 Mixing Bucket Predisposition....228
813.1 610702 Windscreen Protection and Power Pack....230
814.1 610703 Windscreen Wiper....232
815.1 610704 Boom Work Light....234
816.1 610705 Cabin Work Light....236
817.1 610707 Chassis Levelling, View 1....238
818.1 610708 Chassis Levelling, View 2....240
819.1 610709 Twing Hitch....242
820.1 610710 Fem 3 Forks....244
821.1 610711 Remote Radio Control and Green Light....246
822.1 610712 GM-1 Articulation....248
823.1 610713 LMI Tower Lights....250

Indices


Part Number Index....252
Part Description Index....259

Cross References

Fittings Cross Reference....270


MidWestTech | Terex Genie GTH-4016RJIIA, GTH-4018R IIIA Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

811.1 610706 Man Platform Predisposition - Emergency Pump, View 2




MidWestTech | Terex Genie GTH-4016RJIIA, GTH-4018R IIIA Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

817.1 610707 Chassis Levelling, View 1



MidWestTech | Terex Genie GTH-4016RJIIA, GTH-4018R IIIA Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >

823.1 610713 LMI Tower Lights



MidWestTech | Terex Genie GTH-4016RJIIA, GTH-4018R IIIA Articulated Boom Lift Parts M... Order the manual at mid-west-tech.com >