PARTS CATALOG

LB75.B
BACKHOE LOADER

Serial Number 031044851 and After

6036803200NA

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

MAIN	00	SECTIONS
MPARTS	00	MAINTENANCE PARTS
SEC. 01	00	ENGINE 1/2
SEC. 01	01	ENGINE 2/2
0.021	01	ENGINE
0.040	01	CYLINDER BLOCK
0.040	02	CYLINDER BLOCK
0.042	01	OIL PUMP, PAN
0.043	01	CYLINDER BLOCK - COVERS
0.043	02	CYLINDER BLOCK - COVERS
0.043	03	CYLINDER BLOCK - COVERS
0.045	01	BREATHER - ENGINE
0.060	01	CYLINDER HEAD
0.063	01	CYLINDER HEAD - COVERS
0.066	01	CYLINDER HEAD - VALVE MECHANISM
0.071	01	MANIFOLD - INTAKE
0.077	01	MANIFOLD - EXHAUST
0.080	01	CRANKSHAFT
0.081	01	PISTONS - CONNECTING ROD
0.082	01	PISTONS - CONNECTING ROD
0.083	01	FLYWHEEL - ENGINE
0.084	01	PULLEY - CRANKSHAFT
0.105	01	DYNAMIC BALANCER, GEARS & SHAFTS
0.105	02	DYNAMIC BALANCER, GEARS & SHAFTS (2830952)
0.120	01	CAMSHAFT
0.140	01	FUEL INJECTION PUMP
0.140	02	FUEL INJECTION SYSTEM
0.142	01	FUEL INJECTION SYSTEM
0.149	01	FUEL INJECTION SYSTEM
0.200	01	FUEL FILTER
0.201	01	FUEL PUMP
0.203	01	FUEL INJECTION SYSTEM
0.204	01	FUEL INJECTION SYSTEM
0.240	01	TURBOCHARGER
0.270	01	ENGINE, OIL
0.300	01	OIL PUMP - ENGINE
0.302	01	OIL FILTERS - ENGINE
0.305	01	PIPING - ENGINE OIL
0.315	01	OIL FILTER AND COOLER
0.320	01	WATER PUMP
0.323	01	COOLING SYSTEM - ENGINE
0.326	01	THERMOSTAT - ENGINE COOLING SYSTEM
0.340	01	WATER PUMP - CONTROL
0.345	01	FAN DRIVE
0.350	01	POWER TAKE-OFF
0.360	01	STARTER MOTOR
0.400	01	ALTERNATOR
0.450	01	ENGINE - LIFT HOOK
636A	01	ACCESSORY ENGINE
636A	02	ACCESSORY ENGINE - VENTILATOR
636A	03	ACCESSORY ENGINE - STARTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

636A	04	ACCESSORY ENGINE- ALTERNATOR
636A	05	ACCESSORY ENGINE - BRACKET MUFFLER
SEC. 02	00	FUEL TANK - MUFFLER - RADIATOR - AIR CLEANER - CHASSIS
1.14.0	01	FUEL TANK & RELATED PARTS
1.15.0	01	MUFFLER & EXTENSIONS
1.15.0	02	MUFFLER & EXTENSIONS
1.17.2	01	EXPANSION TANK
1.19.1	01	AIR CLEANER & HOSES
1.21.5/ 1	01	FRAME (CENTER PIVOT)
175	01	AIR INTAKE CAP & PRE-CLEANER
176	01	AIR INTAKE CAP & PRE-CLEANER
203	01	FRONT WEIGHTS
215	01	FRONT WEIGHTS
636	01	RADIATOR
636	02	RADIATOR
637	01	RADIATOR
SEC. 03	00	TRANSMISSION 1/2
SEC. 03	01	TRANSMISSION 2/2
1.28.0	01	GEARING SPEED GEAR
1.28.0/ A	01	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	02	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	03	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	04	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	05	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	06	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ A	07	TRANSMISSIONGEARING SPEED GEAR (2WD POWER-SHUTTLE)
1.28.0/ B	01	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	02	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	03	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	04	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	05	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	06	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	07	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.0/ B	08	TRANSMISSIONGEARING SPEED GEAR (4WD POWER-SHUTTLE)
1.28.6	01	GEAR FILTER PIPES (POWER-SHUTTLE)
1.29.1	01	TRANSMISSION ESTERNALSHIFTING CONTROLS (POWER-SHUTTLE)
1.38.1	01	FRONT & REAR DRIVESHAFT, POWER-SHUTTLE
1.39.8	01	TRANSMISSION OIL COOLING PIPES (POWER-SHUTTLE)
SEC. 04	01	FRONT AXLE
1.40.0	01	FRONT AXLE (2WD)
1.40.0	02	FRONT AXLE (2WD)
1.42.0	01	POWER STEERING HYDRAULIC SYSTEM
1.42.0/ A	01	POWER STEERING HYDRAULIC SYSTEM
402	01	4WD FRONT AXLE, HOUSING, BUSHINGS & SUPPORTS
402	02	4WD FRONT AXLE, SWIVEL HOUSING & STEERING CYLINDER
402	03	4WD FRONT AXLE, HUBS
402	04	4WD FRONT AXLE, RING GEAR & PINION ASSEMBLY
402	05	4WD FRONT AXLE, DIFFERENTIAL
402	06	4WD FRONT AXLE, DRIVE SHAFT
415	01	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	02	FRONT AXLE - (4WD) W/GEAR,BEVEL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

415	03	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	04	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	05	FRONT AXLE - (4WD) W/GEAR,BEVEL
415	06	FRONT AXLE - (4WD) W/GEAR,BEVEL
SEC. 05	00	REAR AXLE
1.44.0A	01	REAR AXLE (POWER-SHUTTLE)
1.44.0A	02	REAR AXLE (POWER-SHUTTLE)
1.44.0A	03	REAR AXLE (POWER-SHUTTLE)
1.44.0A	04	REAR AXLE (POWER-SHUTTLE)
SEC. 06	00	ELECTRICAL
1.75.2	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2	03	ENGINE HARNESS (POWER SHUTTLE)
1.75.2/ 3	01	CHASSIS HARNESS & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	02	BATTERY LOCK-OUT SWITCH & GROUND WIRE (POWER SHUTTLE)
1.75.2/ 3	03	ENGINE HARNESS (POWER SHUTTLE)
131	01	SINGLE BATTERY
321	01	DOUBLE BATTERY
995	01	COLD START
995	02	COLD START
SEC. 07	00	SLIDES VALVES
1.82.0	01	HYDRAULIC OIL RESERVOIR
1.82.3	01	HYDRAULIC PUMP (35+35-154L/MM)
1.82.6	01A	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	01B	FRONT HYDRAULIC PUMP INTAKE & OUTLET HOSES (CENTER PIVOT)
1.82.6	02A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	02B	REAR HYDRAULIC PUMP STABILIZER, LOADER & BACKHOE VALVE HOSES (CENTER PIVOT)
1.82.6	03A	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	03B	QUICK RELEASE COUPLERS & HOSES (CENTER PIVOT)
1.82.6	04A	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	04B	RETURN MANIFOLD HOSES (CENTER PIVOT)
1.82.6	05F	OIL COOLER & FILTER HOSES (CENTER PIVOT)
1.82.6	05G	HYDRAULIC SYSTEM PIPING (CENTER PIVOT)
1.82.6	06A	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	06B	FILTER ASSEMBLY & HOSE TO RETURN MANIFOLD (CENTER PIVOT)
1.82.6	07	HYDRAULIC SYSTEM PIPING
1.82.6	08A	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	08C	LOADER LIFT CYLINDER HOSES (CENTER PIVOT)
1.82.6	09A	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	09B	LOADER BUCKET CYLINDER HOSES (CENTER PIVOT)
1.82.6	09C	BACKHOE SWING CYLINDER HOSES (CENTER PIVOT)
1.82.6	11A	BACKHOE CONTROL VALVE HOSES (CENTER PIVOT)
1.82.6	11B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	12B	HYDRAULIC SYSTEM PIPING(CENTER PIVOT)
1.82.6	13A	ROTATION PLATE HOSE CLAMPS (CENTER PIVOT)
1.82.6	16	BACKHOE CONTROL VALVE(CENTER PIVOT)
1.82.6	17	DIPPER VALVE SECTION (CENTER PIVOT)
1.82.6	18	BUCKET, SWING, & BOOM VALVE SECTION (CENTER PIVOT)
302	01	TWO-SECTION CONTROL VALVE FOR LOADER
302	02	TWO-SECTION CONTROL VALVE FOR LOADER

MidWestTech | New Holland LB75.B Backhoe Loader Parts Catalog | Publication 60368032... Order the manual at mid-west-tech.com >

COLD START

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		87410603		1	PLATE
2		85825169		3	SPACER
3		(47049164)		3	SCREW THD TO HD M8x40 CL8.8 ZND
4		87409046		1	ELECTRONIC UNIT, CONTROL
5		86619908		1	RELAY
6		76088638		1	CONNECTOR
7		87410602		1	FUSE 300 AMP
8		85801492		3	INSERT, THREADED
9		47049195		1	COLLAR M8
10		47048961		15	WASHER
11		47054518		8	NUT M6
12		47049157		5	BOLT M6x20
13		47120207		2	SCREW M6x35
14		85821538		1	SCREW M6x16
15		47049029		4	NUT M6
16		322357		2	SPRING, BELLEVILLE LW BV 6
17		47048992		5	WASHER 8mm Spring Lock
18		47049030		2	NUT M8
19		87411092		1	COVER
20		87411090		1	PLATE, COVER
21		47048702		5	COLLAR, RETAINER
22		85821539		3	O-RING
23		87414237		1	PLATE M14

MidWestTech | New Holland LB75.B Backhoe Loader Parts Catalog | Publication 60368032... Order the manual at mid-west-tech.com >

LOADER CONTROL VALVE, TWO SECTION, LOADER, BUCKET & DUMP VALVES (CENTER PIVOT)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		85819649		1	DISTRIBUTOR ASSY
2		11190579		3	WASHER, LOCK
3		14308221		3	SCREW M10X1,25X65
4		9968455		1	SUPPORT
5		9968457		1	SPACER
6		9968456		2	SCREW
7		9968458		3	PLATE, COVER
8		9968460		2	SCREW
9		85999136		4	O-RING
10		85999138		2	O-RING
11		85808403		1	STOP
12		9968451		2	SCREW
13		85817025		1	VALVE, FLOAT
14		9968454		2	SCREW
15		85816804		1	HOSE, FLEXIBLE
16	1	85817531		1	CONNECTOR, HYD.
17		9825770		1	O-RING 90 Duro, .301" ID x .070" Thk
18		9824050		1	O-RING 90 Duro, .926" ID x .070" Thk
19		9968513		1	COVER
20		89626929		1	GASKET 90 Duro, 1.048" ID x .116" Thk

(1) Includes 17,18,20

MidWestTech | New Holland LB75.B Backhoe Loader Parts Catalog | Publication 60368032... Order the manual at mid-west-tech.com >

BUCKET 6X1 (1 M3) WITH TINE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		85820032		1	BUCKET
2		85820033		1	BUCKET
3		85820018		4	SCREW M10X90
4		85820035		4	NUT M10X1,5
5		85820021		1	SCREW M8X120
6		85820031		1	NUT M8
7		85820034		12	SCREW M6X30
8		85820026		2	PLATE
9		85820028		12	CLAMP
10		85820066		2	PIN
11		85820063		2	SUPPORT
12		85820014		8	NIPPLE, LUBE M10X1
13		85820062		2	FORK, BUCKET
14		85820067		2	PIN
15		85820068		2	PIN, SPLIT (COTTER)
16		85820016		2	PIN, ROLL 10X80
17		85820017		2	PIN
18		85820005		2	CYLINDER
19		85820013		4	BUSHING
20		85820015		2	PIN
21		85820007		8	SCREW M14X35
22		85820009		8	WASHER, SEALING
23		85820008		10	NUT M14X2
24		85820006		1	BLADE, KNIFE
25		85820025		4	CONNECTOR, HYD.
26		85825177		2	PIN, SPLIT (COTTER)
27		85824364		2	HOSE, FLEXIBLE
28		85824363		2	HOSE, FLEXIBLE
29		85820039		2	TUBE, RIGID
30		85820040		2	CONNECTOR, HYD.
31		85820038		2	TUBE, RIGID
32		85820064		2	PIN
33		85820069		2	PLUG
34		85820065		2	BRACKET
35		85820027		4	CLAMP
36		85820019		2	PIN

MidWestTech | New Holland LB75.B Backhoe Loader Parts Catalog | Publication 60368032... Order the manual at mid-west-tech.com >