PARTS CATALOG

LB90.B
Backhoe Loader

S/N 031044887 and After

Print No. 6036803300NA
11/2010

NEW HOLLAND CONSTRUCTION

MidWestTech | New Holland LB90.B Backhoe Loader Parts Catalog | Publication 6036803300

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
HYDRAULIC PUMP (40+35-165L/MM)	1.82.3/ 1	01
0.88 M3 BUCKET AND EXTRA REVERSIBLE BLADE	527-1	01
0.88 M3 BUCKET WITHOUT TINES	520	01
1 M3 BUCKET	522-B	01
1.15 M3 BUCKET WITH FORKS AND CUTTER BLADE	533/ 1	01
1.15 M3 BUCKET WITH FORKS AND CUTTER BLADE	533/ 1	02
12" (305MM) BACKHOE BUCKET WITH BOLT-ON TEETH	515	02
12" (305MM) BACKHOE BUCKET WITH PIN TEETH	515	01
18" (457MM) BACKHOE BUCKET WITH BOLT-ON TEETH	516	02
18" (457MM) BACKHOE BUCKET WITH PIN TEETH	516	01
2 LEVER BACKHOE CONTROLS, LEVER TIE-ROD ASSEMBLY (SIDE SHIFT & LB115)	350	02
2 LEVER BACKHOE CONTROLS, LEVER, BOOT & DECALS (CENTER PIVOT)	390/ 1	01
2 LEVER BACKHOE CONTROLS, LEVER, BOOT & DECALS (SIDE SHIFT & LB115)	350	01
2 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/A	02
24" (610MM) BACKHOE BUCKET WITH BOLT-ON TEETH	517	02
24" (610MM) BACKHOE BUCKET WITH PIN TEETH	517	01
30" (762MM) BACKHOE BUCKET WITH BOLT-ON TEETH	518	02
30" (762MM) BACKHOE BUCKET WITH PIN TEETH	518	01
36" (914MM) BACKHOE BUCKET WITH BOLT-ON TEETH	519	02
36" (914MM) BACKHOE BUCKET WITH PIN TEETH	519	01
4 LEVER BACKHOE CONTROLS, CONSOLE, LEVERS & BELLCRANK (CENTER PIVOT)	394/ 1	01
4 LEVER BACKHOE CONTROLS, CONSOLE, LEVERS & BELLCRANK (SIDE SHIFT & LB115)	353	01
4 LEVER BACKHOE CONTROLS, LOWER TIE-ROD ASSEMBLY (CENTER PIVOT)	394/ 1	03
4 LEVER BACKHOE CONTROLS, LOWER TIE-ROD ASSEMBLY (SIDE SHIFT)	353	03
4 LEVER BACKHOE CONTROLS, UPPER TIE-ROD ASSEMBLY (SIDE SHIFT)	353	02
4 LEVER BACKHOE CONTROLS, UPPER TIE-ROD ASSEMBLY, CENTER PIVOT	394/ 1	02
4WD FRONT AXLE, 13.7 RATIO, DIFFERENTIAL (CENTER PIVOT, POWER SHUTTLE)	403	05
4WD FRONT AXLE, 13.7 RATIO, DRIVE SHAFT (CENTER PIVOT, POWER SHUTTLE)	403	06
4WD FRONT AXLE, 13.7 RATIO, HOUSING, BUSHINGS & SUPPORTS (CENTER PIVOT, POWER SHUTTLE)	403	01
4WD FRONT AXLE, 13.7 RATIO, HUBS (CENTER PIVOT, POWER SHUTTLE)	403	03
4WD FRONT AXLE, 13.7 RATIO, RING GEAR & PINION ASSEMBLY (CENTER PIVOT, POWER SHUTTLE)	403	04
4WD FRONT AXLE, 13.7 RATIO, SWIVEL HOUSING & STEERING CYLINDER (CENTER PIVOT, POWER SHUTTLE)	403	02
4WD FRONT AXLE, 14.308 RATIO, DIFFERENTIAL	402	05
4WD FRONT AXLE, 14.308 RATIO, DRIVE SHAFT	402	06
4WD FRONT AXLE, 14.308 RATIO, HOUSING, BUSHINGS & SUPPORTS	402	01
4WD FRONT AXLE, 14.308 RATIO, HUBS	402	03
4WD FRONT AXLE, 14.308 RATIO, RING GEAR & PINION ASSEMBLY	402	04
4WD FRONT AXLE, 14.308 RATIO, SWIVEL HOUSING & STEERING CYLINDER	402	02
4WD STEERING LOCK	628	01
4X1 & 6X1 BUCKET CONTROL LEVER, CABLE & DECALS	700	01

MidWestTech | New Holland LB90.B Backhoe Loader Parts Catalog | Publication 60368033... Order the manual at mid-west-tech.com >

4X1 & 6X1 BUCKET CONTROL LEVER, CABLE & DECALS(CENTER PIVOT)	725/ 1	01
4X1 & 6X1 BUCKET HYDRAULIC LINES	700/ 2	01
4X1 & 6X1 BUCKET HYDRAULIC LINES	700/ 2	02
4X1 & 6X1 BUCKET HYDRAULIC LINES	700	02
4X1 & 6X1 BUCKET HYDRAULIC LINES (P. SHUTTLE)	340/ 1	01
4X1 & 6X1 BUCKET HYDRAULIC LINES (P. SHUTTLE)	741/ 1	01
4X1 & 6X1 BUCKET HYDRAULIC LINES (P. SHUTTLE)	741/ 1	02
4X1 & 6X1 BUCKET HYDRAULIC LINES(CENTER PIVOT)	725/ 1	02
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/C	01
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/C	02
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/C	05
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/A	01
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/C	04
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	331/C	03
6 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE (CENTER PIVOT)	331/C	06
6 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	333/B	11
6 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	333/B	10
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/B	08
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/B	01
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/A	03
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/A	02
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/A	01
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/B	04
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/B	03
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE	333/B	05
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE (CENTER PIVOT) EUROPE	333/B	02
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE (CENTER PIVOT) EUROPE	333/B	06
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE (CENTER PIVOT) EUROPE	333/B	09
7 SECTION PILOT CONTROL VALVE SUPPORT, COMPLETE (CENTER PIVOT) EUROPE	333/B	07
7-SECTIONS EXCAVATOR CONTROL VALVE	334	11
7-SECTIONS EXCAVATOR CONTROL VALVE	334	09
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	02
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	03
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	04
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	05
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	06
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	07
7-SECTIONS EXCAVATOR CONTROL VALVE (CENTER PIVOT) NORTH AMERICA	333/1	01
7-SECTIONS EXCAVATOR CONTROL VALVE (SIDE SHIFT) EUROPE	334	02
7-SECTIONS EXCAVATOR CONTROL VALVE (SIDE SHIFT) EUROPE	334	01
7-SECTIONS EXCAVATOR CONTROL VALVE (SIDE SHIFT) EUROPE	334	08
8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	341/B	01
8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	341/B--	01
8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	341/A	01
8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE	341/B	03

Order the manual at mid-west-tech.com >

8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE(	341/B	08
8 SECTION PILOT CONTROL VALVE SUPPORT,COMPLETE(CENTER PIVOT)EUROPE	341/B	07
8-SECTIONS EXCAVATOR CONTROL VALVE(CENTER PIVOT) EUROPE	341	01
A/C & HEATER CAB ROOF DUCTS	644	09
A/C & HEATER CONSOLE DUCTS	346	05
A/C & HEATER CONSOLE DUCTS	347	05
A/C & HEATER CONSOLE DUCTS	644	05A
A/C & HEATER CONSOLE DUCTS	644	05
A/C & HEATER CONTROL PANEL	644	04
A/C & HEATER CONTROL PANEL	347	04
A/C & HEATER CONTROL PANEL	346	04
A/C & HEATER CONVEYOR	644	06
A/C BLOWER & COILS	644	02
A/C BLOWER & COILS	346	02
A/C COMPRESSOR	646/1	03
A/C COMPRESSOR ATTACHING GROUP	646A	01
A/C COMPRESSOR ATTACHING GROUP	646/1	02
A/C DRYER FILTER HOSES	646	01
A/C FILTER & CONDENSER ATTACHING GROUP	646/1	04
A/C HOUSING & FILTERS	644	01
A/C HOUSING & FILTERS	346	01
A/C HOUSING SIDE PANELS	644	07
ACCESSORY ENGINE	636A	01
ACCESSORY ENGINE - BRACKET MUFFLER	636A	05
ACCESSORY ENGINE - STARTER	636A	03
ACCESSORY ENGINE - VENTILATOR	636A	02
ACCESSORY ENGINE - VENTILATOR	639A	01
ACCESSORY ENGINE- ALTERNATOR	636A	04
AIR CLEANER & HOSES	1.19.1	01
AIR DUCTS & VENTS	1.94.2	04
AIR DUCTS & VENTS	1.94.2/ 1	04
AIR INTAKE CAP & PRE-CLEANER	175	01
AIR INTAKE CAP & PRE-CLEANER	176	01
AIR RIDE CLOTH SEAT & ATTACHING HARDWARE	855	01
AIR RIDE CLOTH SEAT COMPRESSOR & TUBING	855/ 1	05
AIR RIDE CLOTH SEAT CUSHIONS, ARMRESTS & RELATED PARTS	855/ 1	01
AIR RIDE CLOTH SEAT LOWER SUSPENSION PARTS	855/ 1	04
AIR RIDE CLOTH SEAT MOUNTING PLATE, ADJUSTING RAILS & SEAT BELT	855/ 1	02
AIR RIDE CLOTH SEAT UPPER SUSPENSION PARTS	855/ 1	03
ALTERNATOR	0.400	01
ANTITHEFT	796	01
ARMS AND JOINTS	1.88.11	01
BACKHOE 1/2	SEC. 09	01
BACKHOE 2/2	SEC. 09	02
BACKHOE CONTROL VALVE HOSES (CENTER PIVOT)	1.82.6	11A
BACKHOE CONTROL VALVE(CENTER PIVOT)	1.82.6	16
BACKHOE CONTROL VALVE, 6 SECTIONS (CENTER PIVOT) EUROPE	331/ 1	01
BACKHOE CONTROL VALVE, 6 SECTIONS (CENTER PIVOT) NORTH AMERICA	331	01
BACKHOE CONTROL VALVE, BOOM SECTION (CENTER PIVOT) EUROPE	331/ 1	03
BACKHOE CONTROL VALVE, BUCKET SECTION (CENTER PIVOT) EUROPE	331/ 1	05
BACKHOE CONTROL VALVE, DIPPERSTICK SECTION (CENTER PIVOT) EUROPE	331/ 1	06
BACKHOE CONTROL VALVE, INLET SECTION (CENTER PIVOT)	331/ 1	02

Order the manual at mid-west-tech.com >