
SERVICE MANUAL

Compactors CV1100 - CV1500



NEW HOLLAND
CONSTRUCTION

MidWestTech | New Holland CV1100, CV1500 Compactor Service Manual | Publication 60...

Order the manual at mid-west-tech.com >

CONTENTS

SECTION 00 - MAINTENANCE

CHAPTER 1 - General Instructions

Description	Page
Introduction	1
Safety instructions	3
Environmental measures and health precautions	6
Product identification	8
Torque specifications	9

CHAPTER 2 - General Specifications

Description	Page
Description of the machine	1
Fluids and lubricants	2
Specifications	5
Overall machine dimensions	9

CHAPTER 3 - Troubleshooting

Description	Page
Troubleshooting - Engine	2
Troubleshooting - Hydraulic system oil overheating - emulsifying	3
Troubleshooting - Vibration	3
Troubleshooting - Travel	5
Troubleshooting - Brakes	6
Troubleshooting - Steering	6

SECTION 10 - ENGINE

CHAPTER 1 - Removal and installation

Description	Page
Specifications	1
Description	2
Torque specifications	4
Special tools	4
Removal	6
Installation	13
Accelerator cable assembly removal and installation	13

MidWestTech | New Holland CV1100, CV1500 Compactor Service Manual | Publication 60... Order the manual at mid-west-tech.com >

SECTION 21 - TRANSMISSION

CHAPTER 1 - Hydraulic motor

Description	Page
Description	2
Specifications	3
Torque specifications	3
Disassembly	3
Reconditioning and replacement	5
Assembly	8

CHAPTER 2 - Travel reduction gear

Description	Page
Specification	1
Torque specifications	2
Special tools	2
Exploded view of travel brake	6
Disassembly and assembly	7
Brake test	9
Exploded view	10
Disassembly and assembly	11

SECTION 29 - HYDROSTATIC DRIVE

CHAPTER 1 - Pumps - Cento drive coupling

Description	Page
Specifications	1
Tightening torque	1
Description	2
Special tools	3
Removal of pumps, Cento clutch	3
Cento drive coupling	7

SECTION 35 - HYDRAULIC SYSTEM

CHAPTER 1 - Hydraulic cylinders

Description	Page
Torque Specifications	1
Description	2
Special tools	3
Hood hydraulic cylinders	5
Cab hydraulic cylinder	7
Hydraulic cylinders	7

MidWestTech | New Holland CV1100, CV1500 Compactor Service Manual | Publication 60... Order the manual at mid-west-tech.com >

CHAPTER 2 - Vibration Motor

Description	Page
Description	2
Specifications	3
Torque specifications	3
Disassembly	3
Assembly	9
Supply pressure relief valve adjustment	13


CHAPTER 3 - Hydraulic circuit

Description	Page
Hydraulic installation	2
Functional description	2
Travel without activation	3
Travel activated, moving forward	4
The multi-function valve	5
The idler-wheel lock-block on the flow divider	6
ASC valve	7
Vibration hydraulics	8
Vibration without activation	8
Vibration activated	9
Steering hydraulics	10
Steering without activation	11
Steering to the right	12
Lifting hydraulics	13
Lifting of the cab or hood	14
Lowering the cab and hood	15
Reservoir hydraulics	16
Hydraulic reservoir	16
Discharging of closed circuits	17
Brake release - emergency towing	18
Test points	19
Releasing transmission and wheel hydraulic motor brakes	20
Hydraulic diagram	22

CHAPTER 4 - Hydraulic pump

Description	Page
Specifications	1
Torque specifications	1
Description	2
Disassembly	3
Reconditioning and replacement of parts	8
Assembly	14
Inspection and adjustments	26

MidWestTech | New Holland CV1100, CV1500 Compactor Service Manual | Publication 60... Order the manual at mid-west-tech.com >



MidWestTech | New Holland CV1100, CV1500 Compactor Service Manual | Publication 6045613100 Order the manual at mid-west-tech.com >