580M
580M Turbo
580 Super M
590 Super M
Series Loader Backhoes
Operators Manual

Bur 6-20601

CASE
CONSTRUCTION

MidWestTech | Case 580M, Turbo, Super M, 590 Super M Loader Backhoe Operator's Man... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER 1
M SERIES LOADER BACKHOES 1
AFTER DELIVERY CHECK 3
RIGHT, LEFT, FRONT AND REAR OF MACHINE 3
IDENTIFICATION NUMBERS 4
MACHINE COMPONENTS 7, 8

SAFETY 9
"M" SERIES SAFETY FEATURES 9, 10
SAFETY RULES 11
UTILITY SAFETY 12
PERSONAL SAFETY 13
BEFORE OPERATION 14
MACHINE OPERATION 15
PARKING THE MACHINE 17
BURN PREVENTION 17
FIRE EXTINGUISHER 18
FIRE OR EXPLOSION PREVENTION 19
MAINTENANCE 20
WHEEL AND TIRE MAINTENANCE 21
ROLL-OVER PROTECTIVE STRUCTURE 21
CAST DUCTILE IRON 22
READ OPERATORS MANUAL 23
SAFETY DECALS 23
HAND SIGNALS 35

INSTRUMENTS/CONTROLS 41
FRONT CONSOLE CONTROLS . . . . . 41 - 43
STANDARD TRANSMISSION CONTROLS 44, 45
POWERSHIFT TRANSMISSION CONTROLS
(OPTIONAL ON 580 SUPER M AND 590 SUPER M) 46, 47
FOOT PEDALS 49
PARKING BRAKE 50
LOADER CONTROL LEVER 51
CONSOLE CONTROLS - RIGHT SIDE . . . . . 54 - 57
INSTRUMENT PANEL . . . . . 58 - 63
AUDIBLE ALARM - NOT SHOWN 63
SEAT SWITCH ALARM SYSTEM - NOT SHOWN 64
CONSOLE CONTROLS - LEFT REAR 65, 66
BACKHOE CONTROLS 67
BACKHOE CONTROLS WITH FOOT SWING 68
EXTENDAHOE CONTROLS WITH FOOT SWING 69
BACKHOE CONTROLS 70
BACKHOE CONTROLS WITH HAND SWING 71

TRIM THIS EDGE

MidWestTech | Case 580M, Turbo, Super M, 590 Super M Loader Backhoe Operator's Man... Order the manual at mid-west-tech.com >

BACKHOE CONTROLS WITH HAND SWING AND EXTENDABLE DIPPER 72
AUXILIARY HYDRAULIC ATTACHMENT CONTROL FOR BACKHOES .. 73
SEAT BELTS 75
STANDARD SEAT 76
SUSPENSION SEAT 77
AIR SUSPENSION SEAT 79
CAB AIR LOUVERS 81
CAB AND CANOPY OPTIONS 85
STORAGE AND CONVENIENCE OPTIONS 86

OPERATING INSTRUCTIONS 87
RUN-IN PERIOD FOR A NEW MACHINE 87
ENGINE OPERATION 88
ENGINE STARTING AIDS 91
MACHINE OPERATION 95
POWERSHIFT TRANSMISSION CONTROL MODULE (IF EQUIPPED) 98
TOWING A DISABLED MACHINE 101
TRANSPORTING THE MACHINE ON A TRAILER 102
OPERATING IN COLD WEATHER 104
OPERATING IN HOT WEATHER 105
LOADER OPERATION 106
LOADER HYDRAULIC COUPLER (OPTIONAL) 112
BACKHOE OPERATION 114
VANDAL LOCKUP KIT 135

WHEELS/TIRES 137

LUBRICATION 143
GENERAL SAFETY BEFORE YOU SERVICE 143
ENGINE HOURMETER 143
SUPPORT STRUT FOR LOADER LIFT ARMS 144
FLUIDS AND LUBRICANTS 146, 147
LUBRICATION/MAINTENANCE CHART 148
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 150
THE ENGINE HOOD 151
LOADER GREASE FITTINGS 152
BACKHOE GREASE FITTINGS ..... 154 - 160
FLUID LEVELS 162
ENGINE OIL RECOMMENDATIONS 164
ENGINE SERVICE SPECIFICATIONS 165
AIR FILTER SYSTEM 168
ENGINE COOLING SYSTEM 172
DIESEL FUEL SYSTEM 175
HYDRAULIC SYSTEM 179
TRANSMISSION 182

TRIM THIS EDGE

MidWestTech | Case 580M, Turbo, Super M, 590 Super M Loader Backhoe Operator's Man... Order the manual at mid-west-tech.com >

REAR AXLE 185
FOUR WHEEL DRIVE FRONT AXLE 187
CAB AIR FILTER 189

MAINTENANCE/ADJUSTMENTS 193
LOADER RETURN-TO-DIG ADJUSTMENT 193
ETHER STARTING AID 194
FAN DRIVE BELT REPLACEMENT 195
PLASTIC AND RESIN PARTS 195
SPARK ARRESTER MUFFLER (IF EQUIPPED) 196
RIDE CONTROL ACCUMULATOR 197
CAB AIR CONDITIONING 198
ROLL-OVER PROTECTIVE STRUCTURE 199
FIRE EXTINGUISHER 203

ELECTRICAL 205
BATTERIES 205
LAMP REPLACEMENT 207
INSTRUMENT CLUSTER 211
FUSES 212
RELAYS 213
ACCESSORY OUTLETS 214

MACHINE STORAGE 215
STORAGE PREPARATION 215
REMOVAL FROM STORAGE 216

SPECIFICATIONS - 580M 217
ENGINE DATA (NATURALLY ASPIRATED) 217
ENGINE DATA (TURBOCHARGED) 218
BOLT TORQUES 219
MAIN RELIEF VALVE PRESSURES 219
TRAVEL SPEEDS 219
OPERATING WEIGHTS 220
LOADER BUCKETS 220
BACKHOE BUCKETS - 580M 220
BASIC MACHINE DIMENSIONS 221
LOADER OPERATING DATA AND DIMENSIONS 222
BACKHOE OPERATING DATA AND DIMENSIONS - STANDARD DIPER 224
BACKHOE LIFT CAPACITY - 2WD ..... 226 - 228
EXTENDAHOE OPERATING DATA AND DIMENSIONS 230
EXTENDAHOE LIFT CAPACITY - RETRACTED 232
EXTENDAHOE LIFT CAPACITY - EXTENDED 234
EXTENDAHOE LIFT CAPACITY - 2WD ..... 236 - 238

TRIM THIS EDGE

MidWestTech | Case 580M, Turbo, Super M, 590 Super M Loader Backhoe Operator's Man... Order the manual at mid-west-tech.com >