650H Crawler

Operators Manual

Bur 6-21880

CASE
CONSTRUCTION

MidWestTech | Case 650H Crawler Operator's Manual | Publication 6-21880

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
REGULATIONS 2
AFTER DELIVERY CHECK 2
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 4
MACHINE COMPONENTS 6
MACHINE COMPONENTS 7

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY RULES 9
UTILITY SAFETY 10
BEFORE OPERATION 11
MACHINE OPERATION 12
PARKING THE MACHINE 13
FIRE EXTINGUISHER 13
BURN PREVENTION 14
HAZARDOUS CHEMICALS 14
FIRE OR EXPLOSION PREVENTION 15
MAINTENANCE 16
DUCTILE IRON 16
INFORMATION DECALS 17
SAFETY DECALS 18
HAND SIGNALS 24

INSTRUMENTS/CONTROLS **27**
INSTRUMENT PANEL 27, 28, 29, 30, 31, 32, 33, 34
CONTROL LEVERS 35, 36, 37
OPTIONAL DIRECTION CONTROL LEVER 38
BACK-UP ALARM 38
FOOT THROTTLE, STEERING AND BRAKE PEDAL 39
DECELERATOR 40
DOZER BLADE CONTROL LEVER 41
DOZER BLADE CONTROL LEVER 42
CONTROL HANDLE POSITIONS 43
RIPPER CONTROL LEVER 44
CAB CONTROLS 45
BATTERY DISCONNECT SWITCH 48
OPERATORS SEAT 49
OPERATORS SEAT BELT 51

TRIM THIS EDGE

MidWestTech | Case 650H Crawler Operator's Manual | Publication 6-21880 Order the manual at mid-west-tech.com >

OPERATING INSTRUCTIONS **53**
RUN-IN PERIOD OF A NEW MACHINE 53
ENGINE OPERATION 54
CRAWLER OPERATION 57
TOWING A DISABLED CRAWLER 62
TRANSPORTING THE MACHINE 64
OPERATING IN HOT WEATHER 65
OPERATING IN COLD WEATHER 65
DOZER OPERATION 70
RIPPER OPERATING TIPS 76
TRACK SYSTEMS 77
VANDAL LOCKUP 92
BLADE LIFT EYE 92

LUBRICATON/FILTERS/FLUIDS **93**
GENERAL SAFETY BEFORE YOU SERVICE 93
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 94
ENGINE HOURMETER 95
Fluids and Lubricants 96
LUBRICATION/MAINTENANCE CHART 97
LUBRICATION/MAINTENANCE CHART 98
GREASE FITTINGS 99
ACCESS DOORS 101
ENGINE LUBRICATION 102
ENGINE SERVICE 103
AIR FILTER SYSTEM 106
ENGINE COOLING SYSTEM 110
DIESEL FUEL SYSTEM 113
HYDRAULIC SYSTEM 118
TRANSMISSION 121
FINAL DRIVES 125

MAINTENANCE/ADJUSTMENTS **127**
ETHER STARTING FLUID 127
TRANSMISSION CONTROL LEVER ADJUSTMENT 128
REVERSIBLE FAN POSITIONS (If Equipped) 129
AIR CONDITIONER DRIVE BELT 130
ROLL-OVER PROTECTIVE STRUCTURE 131
BRAKE WEAR CHECK 134
MACHINE CLEANING 134

TRIM THIS EDGE

MidWestTech | Case 650H Crawler Operator's Manual | Publication 6-21880 Order the manual at mid-west-tech.com >

ELECTRICAL SYSTEM **135**
BATTERY SERVICE 135
WORK LAMPS 136
ALTERNATOR WARNING LAMP 137
FUSES 138
ACCESSORY OUTLET 138
BATTERY DISCONNECT SWITCH 139

STORAGE **141**
MACHINE STORAGE 141
REMOVAL FROM STORAGE 142

SPECIFICATIONS **143**
ENGINE SPECIFICATIONS 143
TRAVEL SPEEDS 144
HYDRAULIC SYSTEM 144
TRACK SYSTEM 145
OPERATING DATA AND DIMENSIONS - LONG TRACK (LT) AND RUBBER TRACK CRAWLERS 146
OPERATING DATA AND DIMENSIONS - WIDE TRACK (WT) OR LOW GROUND PRESSURE (LGP) CRAWLERS 148
OPERATING DATA AND DIMENSIONS - RIPPER 149
WEIGHTS 150
AFTER DELIVERY CHECK 161
AFTER DELIVERY CHECK 163

TRIM THIS EDGE

MidWestTech | Case 650H Crawler Operator's Manual | Publication 6-21880 Order the manual at mid-west-tech.com >