AFS Universal Display and Display Plus

Operators Manual

Concord Seeding Operations

Rac 6-25590

Rev. 3.*.*.*

AFS

CASE IH AGRICULTURE

MidWestTech | Case Display Plus, Concord Seeding Operations AFS Universal Display Operator's Manual | Publication 6-25590

Order the manual at mid-west-tech.com >

GENERAL TABLE OF CONTENTS

1 - TO THE OWNER **1**

2 - GENERAL INFORMATION **3**
INTRODUCTION 3
TRACTOR CAB INSTALLATION AND REMOVAL 5
AFS UNIVERSAL DISPLAY PLUS 6
DATA CARD 6
DATA CARD SLOT 6
SCREEN CARE 7
STORAGE CASE 7
CYCLING POWER 8
GENERAL DISPLAY SYMBOLS AND FUNCTIONS 9
UNIVERSAL DISPLAY START-UP REQUIREMENTS 10
UNIVERSAL DISPLAY PLUS START-UP REQUIREMENTS 11
MENU BAR NAVIGATION CHART 12
GENERAL DISPLAY SCREEN LAYOUT 14

3 - MONITOR SETUP **16**
RATE 16
DATE/TIME 19
ROW 21
ANHYDROUS 23
DISTANCE CALIBRATION 24
PRODUCT CALIBRATION 27
CALIBRATION CONSTANT VALUES 32

4 - UTILITY SCREENS **35**
LIGHT SCREEN 35
FAULT SCREEN 36
WARNING SOFTWARE SCREENS 37
SENSOR SCREEN 44

5 - UNIVERSAL DISPLAY PLUS MAP SCREENS **46**
FILE SCREEN 46
LAYER SCREEN 50
MARKER SCREEN 52

6 - UNIVERSAL DISPLAY - APPLY SCREEN **54**
APPLY SCREEN 54
PRODUCT APPLICATION CONTROL 55
IMPLEMENT POSITION DISPLAY 57

MidWestTech | Case Display Plus, Concord Seeding Operations AFS Universal Display Ope... Order the manual at mid-west-tech.com >

7 - UNIVERSAL DISPLAY PLUS - APPLY SCREEN **58**
APPLY SCREEN 58
FIELD MARKER BUTTONS/ZOOM CONTROLS 59
PRESCRIPTION MAP DISPLAY 60
DATA CARD AND GPS/DGPS INDICATOR 61
IMPLEMENT POSITION DISPLAY 62
MASTER APPLICATION CONTROL 63
PRODUCT APPLICATION CONTROL 64

8 - MONITOR SCREEN **66**
MONITOR SCREEN 66
FAN SPEED CONTROL (HYDRAULIC FAN DRIVE ONLY) 67
BIN LEVEL DISPLAY 68
AREA APPLIED DISPLAY 69
FAN RPM AND LOW OIL PRESSURE DISPLAY (DIESEL ONLY) 70
RUN BLOCKAGE SCREEN (IF EQUIPPED) 71

9 - ADJUSTMENTS **72**
WHEEL SPEED SENSOR ADJUSTMENT 72
IMPLEMENT STATUS SWITCH MOUNTING AND ADJUSTMENT 73
METER BLOCKAGE CALIBRATION 74

10 - FUSES **75**
FUSE REQUIREMENTS 75
FUSE BOX 75

11 - FAULT CODES **77**
STARTING UP THE MONITOR 77
MIU FAULT CODES 78
MCC1 FAULT CODES 87

DETAIL INDEX **93**

MidWestTech | Case Display Plus, Concord Seeding Operations AFS Universal Display Ope... Order the manual at mid-west-tech.com >