# 845 GRADER

**Pin HBZ020101 and After**

## Operators Manual

**Bur 6-30382NA**

CASE CONSTRUCTION

MidWestTech | Case 845 Grader Operator's Manual | Publication 6-30382

Order the manual at mid-west-tech.com >

## TABLE OF CONTENTS


RUN-IN ..... 58
BOOSTER BATTERY CONNECTIONS TO MACHINE BATTERIES (JUMP START) ..... 59
OPERATING INSTRUCTIONS ..... 60
OPERATING TIPS ..... 66
TYPICAL OPERATION ..... 67

**WHEELS/TIRES ..... 71**
ADDING AIR TO THE TIRES ..... 73
TIRE OR RIM SERVICE ..... 73
TIRE TREAD DIRECTION ..... 73
WHEEL NUTS TORQUE AND TIRE PRESSURE ..... 74
TANDEM WHEEL LUG NUTS ..... 74
TIRE PRESSURE CHECK ..... 74

**LUBRICATION/FILTERS/FLUIDS ..... 77**
GENERAL SAFETY BEFORE YOU SERVICE ..... 77
ENGINE HOURMETER ..... 78
TRANSPORT/SERVICE PIN ..... 79
ENVIRONMENT ..... 79
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM ..... 80
PLASTIC AND RESIN PARTS ..... 80
ENGINE HOOD ..... 81
MAINTENANCE ..... 82
GENERAL ..... 82
FLUIDS AND LUBRICANTS ..... 83
LUBRICATION & MAINTENANCE CHART ..... 84
ACCESS DOORS ..... 87
FLUID LEVELS ..... 88
EACH 10 HOURS OR DAILY SERVICES ..... 88
EACH 50 HOURS SERVICES ..... 90
GREASE FITTINGS ..... 91
EACH 100 HOURS SERVICES ..... 91
EACH 250 HOURS SERVICES ..... 93
EACH 500 HOURS SERVICES ..... 95
ENGINE LUBRICATION ..... 96
ENGINE OIL SELECTION ..... 96
OIL VISCOSITY AND TEMPERATURE RANGES ..... 97
ENGINE SERVICE SPECIFICATIONS ..... 98
ENGINE OIL LEVEL ..... 98
ENGINE OIL CHANGE AND FILTER REPLACEMENT ..... 98
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM ..... 99
AIR FILTER SYSTEM ..... 100
SERVICE SPECIFICATIONS ..... 100
CLEANING THE AIR FILTER ELEMENT ..... 100
ENGINE COOLING SYSTEM ..... 102
SERVICE SPECIFICATIONS ..... 102
THERMOSTAT ..... 102
COOLANT MIXTURE ..... 102
DRAINING AND FLUSHING THE COOLING SYSTEM ..... 103
RADIATOR CLEANING ..... 103
DIESEL FUEL SYSTEM ..... 105
SERVICE SPECIFICATIONS ..... 105
FUEL CONDITIONER ..... 105
FUEL FILLER CAP ..... 105
DIESEL FUEL ..... 106
FUEL STORAGE ..... 106
SPECIFICATIONS FOR ACCEPTABLE NO. 2 DIESEL FUEL ..... 106
FUEL TANK DRAIN COCK CLEAN ..... 107




MidWestTech | Case 845 Grader Operator's Manual | Publication 6-30382 Order the manual at mid-west-tech.com >

CHANGING THE FUEL FILTERS ..... 107
CHECKING THE FUEL INJECTOR NOZZLES ..... 108
HYDRAULIC/BRAKE SYSTEM ..... 109
SERVICE SPECIFICATIONS ..... 109
HYDRAULIC/BRAKE SYSTEM FLUID CHART ..... 109
HYDRAULIC SYSTEM OIL FILTER ..... 110
CLEANING THE SUCTION LINE FILTER ..... 110
HYDRAULIC/BRAKE OIL CHANGE ..... 111
TRANSMISSION ..... 112
SERVICE SPECIFICATIONS ..... 112
TRANSMISSION OIL LEVEL CHECK ..... 112
TRANSMISSION OIL FILTER CHANGE ..... 113
TRANSMISSION OIL CHANGE AND SCREEN CLEANING ..... 113
REAR AXLE ..... 114
SERVICE SPECIFICATIONS ..... 114
AXLE OIL LEVEL ..... 114
REAR AXLE OIL CHANGE ..... 114
REAR AXLE END COMPARTMENT OIL LEVEL (OPCIONAL) ..... 115
SWING/CIRCLE TURN GEAR BOX ..... 116
SERVICE SPECIFICATIONS ..... 116
CHECKING CIRCLE TURN GEAR BOX OIL ..... 116
TANDEM ..... 117
SERVICE SPECIFICATIONS ..... 117
TANDEM DRIVE CASE OIL LEVEL CHECK ..... 117
TANDEM DRIVE CASE OIL CHANGE ..... 117
TANDEM WHEEL NUT ..... 117
WINDSHIELD WASHER RESERVOIR (IF EQUIPPED) ..... 118
**MAINTENANCE/ADJUSTMENT ..... 119**
PARKING BRAKE CHECK ..... 119
ROLL-OVER PROTECTIVE STRUCTURE ..... 119
SEAT BELT ..... 119
MAINTENANCE AND INSPECTION OF ROPS ..... 120
TORQUE SPECIFICATIONS FOR ROPS CAB AND ROPS ..... 120
DAMAGE TO THE ROPS ..... 121
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS ..... 122
OPERATORS SEAT ..... 122
CAB HEADLINER ..... 123
DOORS HINGES ..... 123
HOSES AND WIRING ..... 123
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) ..... 123
TYPE OF FIRE EXTINGUISHER ..... 123
ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT ..... 124
ALTERNATOR BELT AND TENSIONER ..... 124
DRIVE BELT AND TENSIONER INSPECTION ..... 125
DRIVE BELT TENSIONER ..... 125
REINSTALLING THE DRIVE BELT ..... 125
CIRCLE GUIDES CHECK AND ADJUST ..... 125
WEAR PLATE ADJUSTMENT ..... 125
DRAWBAR ..... 126
HYDRAULIC DIAGNOSTIC PANEL CHECK ..... 127
**ELECTRICAL SYSTEM ..... 129**
ELECTRICAL SYSTEM ..... 129
BATTERY SAFETY ..... 129
BATTERY SERVICE ..... 130
BATTERY FLUID LEVEL ..... 130
BATTERY VENTS ..... 130



MidWestTech | Case 845 Grader Operator's Manual | Publication 6-30382 Order the manual at mid-west-tech.com >