885 GRADER

Pin HBZ024101 and After

Operators Manual

Bur 6-30442NA

CASE CONSTRUCTION

MidWestTech | Case 885 Grader Operator's Manual | Publication 6-30442

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

BOOSTER BATTERY CONNECTIONS TO MACHINE BATTERIES (JUMP START) 59
OPERATING INSTRUCTIONS 60
OPERATING TIPS 66
TYPICAL OPERATION 67

WHEELS/TIRES 71
ADDING AIR TO THE TIRES 73
TIRE OR RIM SERVICE 73
TIRE TREAD DIRECTION 73
WHEEL NUTS TORQUE AND TIRE PRESSURE 74
TANDEM WHEEL LUG NUTS 74
TIRE PRESSURE CHECK 74

LUBRICATION/FILTERS/FLUIDS 77
GENERAL SAFETY BEFORE YOU SERVICE 77
ENGINE HOURMETER 78
TRANSPORT/SERVICE PIN 79
ENVIRONMENT 79
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 80
PLASTIC AND RESIN PARTS 80
ENGINE HOOD 81
MAINTENANCE 82
GENERAL 82
FLUIDS AND LUBRICANTS 83
LUBRICATION & MAINTENANCE CHART 84
ACCESS DOORS 87
FLUID LEVELS 88
EACH 10 HOURS OR DAILY SERVICES 88
EACH 50 HOURS SERVICES 90
GREASE FITTINGS 91
EACH 100 HOURS SERVICES 91
EACH 250 HOURS SERVICES 93
EACH 500 HOURS SERVICES 95
ENGINE LUBRICATION 96
ENGINE OIL SELECTION 96
OIL VISCOSITY AND TEMPERATURE RANGES 97
ENGINE SERVICE SPECIFICATIONS 98
ENGINE OIL LEVEL 98
ENGINE OIL CHANGE AND FILTER REPLACEMENT 98
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 99
AIR FILTER SYSTEM 100
SERVICE SPECIFICATIONS 100
CLEANING THE AIR FILTER ELEMENT 100
ENGINE COOLING SYSTEM 102
SERVICE SPECIFICATIONS 102
THERMOSTAT 102
COOLANT MIXTURE 102
DRAINING AND FLUSHING THE COOLING SYSTEM 103
RADIATOR CLEANING 103
DIESEL FUEL SYSTEM 105
SERVICE SPECIFICATIONS 105
FUEL CONDITIONER 105
FUEL FILLER CAP 105
DIESEL FUEL 106
FUEL STORAGE 106
SPECIFICATIONS FOR ACCEPTABLE NO. 2 DIESEL FUEL 106
FUEL TANK DRAIN COCK CLEAN 107
CHANGING THE FUEL FILTERS 107

MidWestTech | Case 885 Grader Operator's Manual | Publication 6-30442 Order the manual at mid-west-tech.com >

CHECKING THE FUEL INJECTOR NOZZLES 108
ADJUSTING ENGINE VALVES 108
HYDRAULIC/BRAKE SYSTEM 109
SERVICE SPECIFICATIONS 109
HYDRAULIC/BRAKE SYSTEM FLUID CHART 109
HYDRAULIC SYSTEM OIL FILTER 110
CLEANING THE SUCTION LINE FILTER 110
HYDRAULIC/BRAKE OIL CHANGE 111
TRANSMISSION 112
SERVICE SPECIFICATIONS 112
TRANSMISSION OIL LEVEL CHECK 112
TRANSMISSION OIL FILTER CHANGE 113
TRANSMISSION OIL CHANGE AND SCREEN CLEANING 113
REAR AXLE 114
SERVICE SPECIFICATIONS 114
AXLE OIL LEVEL 114
REAR AXLE OIL CHANGE 114
SWING/CIRCLE TURN GEAR BOX 116
SERVICE SPECIFICATIONS 116
CHECKING CIRCLE TURN GEAR BOX OIL 116
TANDEM 117
SERVICE SPECIFICATIONS 117
TANDEM DRIVE CASE OIL LEVEL CHECK 117
TANDEM DRIVE CASE OIL CHANGE 117
WINDSHIELD WASHER RESERVOIR (IF EQUIPPED) 118
MAINTENANCE/ADJUSTMENT 119
PARKING BRAKE CHECK 119
ROLL-OVER PROTECTIVE STRUCTURE 119
SEAT BELT 119
MAINTENANCE AND INSPECTION OF ROPS 120
TORQUE SPECIFICATIONS FOR ROPS CAB AND ROPS 120
DAMAGE TO THE ROPS 121
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 122
OPERATORS SEAT 122
CAB HEADLINER 123
DOORS HINGES 123
HOSES AND WIRING 123
FIRE EXTINGUISHER MOUNTING (IF EQUIPPED) 123
TYPE OF FIRE EXTINGUISHER 123
ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT 124
ALTERNATOR BELT AND TENSIONER 124
DRIVE BELT AND TENSIONER INSPECTION 125
DRIVE BELT TENSIONER 125
REINSTALLING THE DRIVE BELT 125
CIRCLE GUIDES CHECK AND ADJUST 125
WEAR PLATE ADJUSTMENT 125
DRAWBAR 126
HYDRAULIC DIAGNOSTIC PANEL CHECK 127
ELECTRICAL SYSTEM 129
ELECTRICAL SYSTEM 129
BATTERY SAFETY 129
BATTERY SERVICE 130
BATTERY FLUID LEVEL 130
BATTERY VENTS 130
CLEANING THE BATTERIES 130
LIMP-HOME 131

MidWestTech | Case 885 Grader Operator's Manual | Publication 6-30442 Order the manual at mid-west-tech.com >