921C Wheel Loader

Operators Manual

P.I.N. JEE0125746 and After

Bur 6-30550NA

CASE CONSTRUCTION

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-30550na

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

TO THE OWNER **1**
AFTER DELIVERY CHECK 3
RIGHT, LEFT, FRONT AND REAR SIDES OF THE MACHINE 3
IDENTIFICATION NUMBERS 3
MACHINE COMPONENTS 6

SAFETY/DECALS/HAND SIGNALS **9**
SAFETY RULES 9
UTILITY SAFETY 10
BEFORE OPERATION 11
MACHINE OPERATION 12
PARKING THE MACHINE 12
MAINTENANCE 13
BURN PREVENTION 14
FIRE OR EXPLOSION PREVENTION 14
WHEELS AND TIRES SAFETY 15
HAZARDOUS CHEMICALS 16
INFORMATIONAL DECALS 17
SAFETY DECALS 17
HAND SIGNALS 26

INSTRUMENT/CONTROLS **29**
FRONT CONSOLE 29-33
INSTRUMENT PANEL INDICATORS 34-49
INFORMATION CENTER 50-55
GAUGE DISPLAY 56-62
TRANSMISSION DISPLAY CENTER 63-65
FOOT PEDALS 66
LOADER CONTROL LEVERS 67
SIDE CONSOLE 78-85
MASTER DISCONNECT SWITCH 85
OPERATORS SEAT 89
SEAT BELT 92

OPERATING INSTRUCTIONS **95**
BEFORE STARTING THE ENGINE 95
RUN-IN PROCEDURE 95
SEAT BELT 96
STARTING THE ENGINE 97
STOPPING THE ENGINE AND PARKING THE MACHINE 99
MACHINE OPERATION 104
LOADER CONTROL LEVERS 108
LOADER FUNCTION SWITCHES 114
CLUTCH CUTOUT 117

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-30550na Order the manual at mid-west-tech.com >

RIDE CONTROL 117
BUCKET LEVEL INDICATOR 118
AUXILIARY HYDRAULIC CONNECTION (IF EQUIPPED) 118
ROTATING BEACON (IF EQUIPPED) 119
BRAKE ACCUMULATORS 119
COUPLER PIN ENGAGEMENT (IF EQUIPPED) 120
LOADER OPERATING TIPS 121
TOWING THE MACHINE 123
TRANSPORTING THE MACHINE 124
OPERATING IN COLD WEATHER 126
OPERATING IN HOT WEATHER 128

WHEELS/TIRES/BALLAST 129
BALLAST 129
WHEELS AND TIRES 129

LUBRICATION/FILTERS/FLUIDS 135
GENERAL SAFETY BEFORE YOU SERVICE 135
SYSTEMGARD LUBRICATION ANALYSIS PROGRAM 136
PLASTIC AND RESIN PARTS 137
ENVIRONMENT 137
TRANSPORT/SERVICE LINK 137
ENGINE HOURMETER 138
FLUIDS AND LUBRICANTS 139
LUBRICATION/MAINTENANCE CHART 140-142
ACCESS DOORS 143
GREASE FITTINGS - 50 HOURS 144
GREASE FITTINGS - 100 HOURS 145
GREASE FITTINGS - 1000 HOURS 145
FLUID LEVELS 146
ENGINE LUBRICATION 149
AIR FILTER SYSTEM 154
ENGINE COOLING SYSTEM 158
DIESEL FUEL SYSTEM 161
HYDRAULIC/BRAKE SYSTEM 164
TRANSMISSION 171
AXLES
EARLY PRODUCTION GKN (DANA) 174
AXLES
LATE PRODUCTION ZF 177
CAB AIR FILTER 180

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-30550na Order the manual at mid-west-tech.com >

MAINTENANCE/ADJUSTMENT **185**
ETHER CONTAINER 185
CAB SERVICE 186
TRANSMISSION CLUTCH CALIBRATION 189
CLUTCH CUTOUT ADJUSTMENT 190
SECONDARY STEERING CHECK 192
PARKING BRAKE CHECK 193
LOADER ADJUSTMENTS 195
ROLL-OVER PROTECTIVE STRUCTURE 205
TORQUE SPECIFICATIONS FOR SEAT AND SEAT BELTS 207
FAN, BELT, ALTERNATOR BELT AND AIR CONDITIONING COMPRESSOR BELT 208
FIRE EXTINGUISHER MOUNTING (If Equipped) 212
SPARK ARRESTING MUFFLER (IF Equipped) 213

ELECTRICAL SYSTEM **215**
BATTERY SERVICE 215
FUSES 217
SERVICE ELECTRICAL CONNECTOR (IF EQUIPPED) 217
AUXILIARY POWER OUTLET (IF EQUIPPED) 218
AUXILIARY POWER EQUIPMENT MOUNTING BRACKET LOCATION 218
REPLACEMENT BULBS 219

MACHINE STORAGE **221**

SPECIFICATIONS **223**
ENGINE DATA 223
OPERATING DATA AND DIMENSIONS 921C 225
Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket with Teeth and Bolt on Edges 226
Machines with 3.82 m3(5.0 yd3) General Purpose Bucket 227
OPERATING DATA AND DIMENSIONS 921C XR 228
XR Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket 228
XR Machines with 3.63 m3 (4.75 yd3) General Purpose Bucket with Teeth and Bolt on Edges 229
XR Machines with 3.82 m3 (5.0 yd3) General Purpose Bucket 230
OPERATING WEIGHT ADJUSTMENTS 231
SPECIAL BOLT TORQUES 232
AFTER DELIVERY CHECK 241-243

TRIM THIS EDGE

MidWestTech | Case 921C Wheel Loader Operator's Manual | Publication 6-30550na Order the manual at mid-west-tech.com >