A TEREX BRAND

Parts Manual

Serial Number Range

GTH-4016SR

from SN 19782 to 20421

GTH-4018SR

from SN 19785 to 20172

Part No. 645030

Rev C

October 2010

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genieindustries.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genieindustries.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals
101.1 606151 Decals - View 1....10
102.1 606152 Decals - View 2....12

200 Drive Chassis Components
201.1 606153 Basic Frame Chassis....14
202.1 606154 Engine Casing Unit....16
203.1 606155 Turret Chassis - View 1....18
204.1 606156 Turret Chassis - View 2....20
205.1 606157 Transmission And Wheels....22
206.1 606158 Hydraulic Oil - Diesel Tanks....24
207.1 606159 Outriggers GTH-4016SR....26
208.1 606160 Outriggers GTH-4018SR Part 1....28
209.1 606161 Outriggers GTH-4018SR Part 2....30
210.1 606162 Front Axle - Housing....32
211.1 606163 Front And Rear Axle - Differential....34
212.1 606164 Front And Rerar Axle - Bevel Gear Seat....36
213.1 606165 Front And Rear Axle - Double U - Joint Hub And Final Reduction....38
214.1 606166 Front And Rear axle - Steering Cylinder And Swivel Housing....40
215.1 606167 Front And Rear Axle - Brakes....42
216.1 606168 Rear Axle - Housing....44
217.1 606169 Transmission Housing....46
218.1 606170 Transmission Gear And Shafts....48
219.1 606171 Transmission Rear Support....50

300 Engine Components
301.1 606172 Diesel Engine....52
302.1 606173 Engine Cooling System, air filter....54
303.1 606174 Engine Heatsink....56
304.1 606175 Exhaust System And Accelerator....58
305.1 606176 Hydraulic Pumps....60

400 Cab
401.1 606177 Cab, View 1....62
402.1 606178 Cab View 2....64
403.1 606179 Cab, View 3....66
404.1 606180 Cab, View 4....68
405.1 606181 Seat Assembly....70
406.1 606182 Dashboard....72
407.1 606183 Cab Heater....74
408.1 606184 Complete Cab Heater....76

500 Boom Components
501.1 606185 1st Telescopic Element GTH 4016SR....78
502.1 606186 Arm 2nd - 3rd Telescopic Element GTH 4016SR....80
503.1 606187 1st - 2nd Telescopic Element GTH 4018SR..82
504.1 606188 3rd - 4th Telescopic Element GTH 4018SR...84
505.1 606189 Chain Unit 1st Boom Section GTH 4018SR..86
506.1 606190 Chain Unit 2nd Boom Section GTH 4018SR....88
507.1 606191 chain Unit 3rd Boom Section GTH 4018SR..90
508.1 606192 Chain Unit 4th Boom Section GTH 4018SR..92
509.1 606193 Stop spacer Boom Section GTH 4018SR.....94
510.1 606194 Coupling Unit....96
511.1 606195 Forks....98
512.1 606196 Lifting, Tilt, Fork Levelling Cylinders....100
513.1 606197 Boom Extension Cylinders GTH 4016SR....102
514.1 606198 Boom Extension Cylinder GTH 4018SR.....104

600 Hydraulic System
601.1 606199 Boom Extension Cylinders GTH 4016SR....106
602.1 606200 Boom Extension Cylinder GTH 4018SR.....108
603.1 606201 Fork Balancing Cylinders GTH 4016SR.....110
604.1 606202 Fork balancing Cylinders GTH 4018SR.....112
605.1 606203 Attachment GTH 4016SR....114
606.1 606204 Attachment GTH 4018SR....116
607.1 606205 Rear Axle Pivoting Cylinders....118
608.1 606206 Front Outriggers GTH 4016SR....120
609.1 606207 Rear Outriggers GTH 4016SR....122
610.1 606208 Front Outriggers GTH 4018SR....124
611.1 606209 Rear Outriggers GTH 4018SR....126
612.1 606210 Lift Cylinder....128
613.1 606211 Turret Rotation....130
614.1 606212 Service And Parking Brake, Differential Lock Solenoid Valve - Part 1....132
615.1 606213 Service And Parking Brake, Differential Lock Solenoid Valve - Part 2....134
616.1 606214 Brakes Max Pressure Valve GTH 4016SR..136
617.1 606215 Brakes And Outriggers Max Pressure Valve GTH 4018SR....138
618.1 606216 Main Valve Locking And Outriggers Solenoid Valve Block....140
619.1 606217 Main Valve Components....142
620.1 606218 Power Steering....144
621.1 606219 Hydraulic Oil Cooler....146
622.1 606220 Turret Flexible Hoses Locking System....148
623.1 606221 pressure Plugs....150
624.1 606222 Suction System Hydraulic Pumps....152
625.1 606223 Hydraulic Transmission....154
626.1 606224 Shift Gear Solenoid valve....156

700 Electric Installation
701.1 606225 Cabin Fuses And Relay Box....158

MidWestTech | Terex Genie GTH-4016SR, GTH-4018SR Articulated Boom Lift Parts Manual... Order the manual at mid-west-tech.com >

702.1 606226 Engine Line.....160
703.1 606227 Outriggers stability load Cell System.....162
704.1 606228 Base frame Line.....164
705.1 606229 Turret base frame Line - Part 1.....166
706.1 606230 Turret base Frame - Line Part 2.....168
707.1 606231 Dashboard Line.....170
708.1 606232 Side Cabe Line.....172
709.1 606233 Control Unit Line And Display.....174
710.1 606234 Dashboard.....176
711.1 606235 Rear Road Light.....178
712.1 606236 Connectors.....180
713.1 606237 Connectors.....182
714.1 606238 Connectors.....184
715.1 606239 Connectors.....186
716.1 606240 Connectors.....188
717.1 606241 Connectors.....190
718.1 606242 Connectors.....192

800 Optionals

801.1 606243 Transport Locking Devices.....194
802.1 606244 T.U.V. Dotation.....196
803.1 606245 Plate For Swiss Market.....198
804.1 606246 Hydraulic Jack.....200
805.1 606247 Boom Electric Line - Part 1.....202
806.1 606248 Boom Electric Line - Part 2.....204
807.1 606249 Hydraulic Quick Coupling for Attachment.....206
808.1 606250 Air Conditioning - Cabin Part.....208
809.1 606251 Air Conditioning - Hydraulic Part.....210
810.1 606252 Air Conditioning - Electrical Part.....212
811.1 606253 Man Platform Predisposition - Part 1- Emergency Pump Kit.....214
812.1 606254 Mixing Bucket Predisposition.....216
813.1 606255 Electrical Predisposition Boom Light, Auxiliary Hydraulic Circuit GTH 4016SR.....218
814.1 606256 Electrical Predisposition Boom Light, Auxiliary Hydraulic Circuit GTH 4018SR.....220
815.1 606257 Windscreen Grate.....222
816.1 606258 Windscreen Wiper.....224
817.1 606259 Boom Work Light.....226
818.1 606260 Cabin Work Light.....228
819.1 606331 Auxiliary Hydraulic Circuit.....230
820.1 606333 Emergency Electric Pump.....232
821.1 606334 Auxiliary Left Joystick.....234
822.1 606335 Towing Hitch.....236
823.1 606337 Optionals - Machines Interface Connectors.238
824.1 606338 Fem 3 Forks.....240
825.1 606339 Man platform Predisposition - Part 2.....242
826.1 606332 Air and Electric Line.....244
827.1 606336 Remote Radio Control GTH 4016SR.....246
828.1 606341 Remote Radio Control GTH 4018SR.....248
829.1 606340 Spare Wheel.....250

Indices

Part Number Index.....252
Part Description Index.....258

Cross References

MidWestTech | Terex Genie GTH-4016SR, GTH-4018SR Articulated Boom Lift Parts Manual... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	07.0740.0360	Electrical Fan	1
2	07.0740.0361	Diffuseur	1
3	07.0740.0359	Heater	1

MidWestTech | Terex Genie GTH-4016SR, GTH-4018SR Articulated Boom Lift Parts Manual... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	56.0012.0028	Lenght-Angle-Temp. Transducer	1
2	56.0012.0063	Pressure Transducer	4

MidWestTech | Terex Genie GTH-4016SR, GTH-4018SR Articulated Boom Lift Parts Manual... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	09.4675.0003	Hydraulic Jack	1
2	09.4675.0000	Ratchet Socket	1

MidWestTech | Terex Genie GTH-4016SR, GTH-4018SR Articulated Boom Lift Parts Manual... Order the manual at mid-west-tech.com >