A TEREX BRAND

Parts Manual

Serial Number Range

GTH-4016 SR

for SN 20584

from SN 20559 to 20598

GTH-4018 SR

for SN 20623

for SN 20708

Part No. 645047

Rev B

January 2012

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals
101.1 606951 Decals - View 1....10
102.1 606952 Decals - View 2....12

200 Drive Chassis Components
201.1 606953 Basic Frame Chassis....14
202.1 606954 Engine Casing Unit....16
203.1 606955 Turret chassis - View 1....18
204.1 606956 Turret Chassis - View 2....20
205.1 606957 Transmission And Wheels....22
206.1 606958 Hydraulic Oil And Diesel Tanks....24
207.1 606959 Outriggers ONLY GTH-4016SR....26
208.1 606960 Outriggers ONLY GTH-4018SR Part 1....28
209.1 606961 Outriggers ONLY GTH-4018SR Part 2....30
210.1 606962 Front Axle - Housing....32
211.1 606963 Front Axle And Rear Axle - Differential....34
212.1 606964 Front And Rear Axle - Bevel Gear Seat....36
213.1 606965 Front And Rear Axle - Double U - Joint Hub And Final Reduction....38
214.1 606966 Front And Rear Axle - Steering Cylinder And Swivel Housing....40
215.1 606967 Front And Rear Axle - Brakes....42
216.1 606968 Rear Axle - Housing....44
217.1 606969 Transmission Housing....46
218.1 606970 Transmission Gear And Shafts....48
219.1 606971 Transmission Rear Support....50

300 Engine Components
301.1 606972 Diesel Engine....52
302.1 606973 Engine Cooling Sysrtem, Air Filter....54
303.1 606974 Engine Heatsink....56
304.1 606975 Exhaust System And Accelerator....58
305.1 606976 Hydraulic Pumps....60

400 Cab
401.1 606977 Cab, View 1....62
402.1 606978 Cab, View 2....64
403.1 606979 Cab, View 3....66
404.1 606980 Cab, View 4....68
405.1 606981 Seat assembly....70
406.1 606982 Dashboard....72
407.1 606983 Cab Heater....74
408.1 606984 Engine Cab Heater....76
409.1 606985 Complete Cab Heater....78

500 Boom Components
501.1 606986 1st Telescopic Element GTH-4016SR....80
502.1 606987 Arm 2nd - 3rd Telescopic Element GTH 4016SR....82
503.1 606988 1st - 2nd Telescopic Element GTH 4018SR..84
504.1 606989 Arm 3rd - 4th Telescopic Element GTH 4018SR....86
505.1 606990 Chain Unit 1st Boom Section GTH 4018SR..88
506.1 606991 Chain Unit 2nd Boom Section GTH 4018SR....90
507.1 606992 Chain Unit Boom Section GTH 4018SR....92
508.1 606993 Chain And Cap Unit 4th Boom Section GTH 4018SR....94
509.1 606994 Stop Spacer Boom Section GTH 4018SR....96
510.1 606995 Coupling Unit....98
511.1 606996 Forks....100
512.1 606997 Lifting, Tilt, Fork Levelling Cylinders....102
513.1 606998 Boom Extension Cylinders GTH 4016SR....104
514.1 606999 Boom Extension Cylinder GTH 4018SR....106

600 Hydraulic System
601.1 607000 Boom Extension Cylinders GTH 4016SR....108
602.1 607001 Boom Extension Cylinder GTH 4018SR....110
603.1 607002 Fork Balancing Cylinders GTH 4016SR....112
604.1 607003 Fork Balancing Cylinders GTH 4018SR....114
605.1 607004 Attachment GTH 4016SR....116
606.1 607005 Attachment GTH 4018SR....118
607.1 607006 Rear Axle Pivoting Cylinders....120
608.1 607007 Front Outriggers GTH 4016SR....122
609.1 607008 Hoses Fittings Holder Plate....124
610.1 607009 Rear Outriggers GTH 4016SR....126
611.1 607010 Front Outriggers GTH 4018SR....128
612.1 607011 Rear Outriggers GTH 4018SR....130
613.1 607012 Lift Cylinder....132

MidWestTech | Terex Genie GTH-4016 SR, GTH-4018 SR Articulated Boom Lift Parts Manu... Order the manual at mid-west-tech.com >

614.1 607013 Turret Rotation....134
615.1 607014 Service And Parking Brake, Differential Lock Solenoid Valve - Part 1....136
616.1 607015 Service And Parking Brake, Differential Lock Solenoid Valve - Part 2....138
617.1 607016 Brakes Max Pressure Valve GTH 4016SR..140
618.1 607017 Brakes And Outriggers Max Pressure Valve GTH 4018SR....142
619.1 607018 Main Valve And Outriggers Solenoid Valve Block....144
620.1 607019 Main Valve Components....146
621.1 607020 Power Steering....148
622.1 607021 Hydraulic Oil Cooler....150
623.1 607022 Turret Flexible Hoses Locking System....152
624.1 607023 Pressure Plugs....154
625.1 607024 Suction System Hydraulic Pumps....156
626.1 607025 Hydraulic Transmission....158
627.1 607026 Shift Gear Solenoid Valve....160

700 Electric Installation

701.1 607027 Cabin Fuses And Realay Box....162
702.1 607028 Engine Line....164
703.1 607029 Base Frame Line....166
704.1 607030 Turret Base Frame Line - Part 1....168
705.1 607031 Turret Base Frame Line - Part 2....170
706.1 607032 Dashboard Line....172
707.1 607033 Side Cab Line....174
708.1 607034 Dashboard....176
709.1 607035 Rear Road Light....178
710.1 607036 Connectors....180
711.1 607037 Connectors....182
712.1 607038 Connectors....184
713.1 607039 Connectors....186
714.1 607040 Connectors....188
715.1 607041 Connectors....190
716.1 607042 Connectors....192

800 Optionals

801.1 607043 Transport Locking Devices....194
802.1 607044 T.U.V. Dotation....196
803.1 607045 Plate For Swiss Market....198
804.1 607046 Hydraulic Jack....200
805.1 607047 Boom Electric - Part 1....202
806.1 607048 Boom Electric Line - Part 2....204
807.1 607049 Hydraulic Coupling For Attachment....206
808.1 607050 Air Conditioning - Cabin Part....208
809.1 607051 Air Conditioning - Hydraulic Part....210
810.1 607052 Air Conditioning - Electrical Part....212
811.1 607053 Man Platform Predisposition - Part 1 - Emergency Pump Kit....214
812.1 607054 Mixing Bucket Predisposition....216
813.1 607055 Electrical Predisposition Boom Light, Auxiliary Hydraulic Circuit GTH 4016SR....218
814.1 607056 Electrical Predisposition Boom Light, Auxiliary Hydraulic Cicuit GTH 4018SR....220
815.1 607057 Windscreen Grate....222
816.1 607058 Windscreen Wiper....224
817.1 607059 Boom Work Light....226
818.1 607060 Cabin Work Light....228
819.1 607061 Auxiliary Hydraulic Circuit....230
820.1 607062 Emergency Electric Pump....232
821.1 607063 Auxiliary Left Joystick....234
822.1 607064 Towing Hitch....236
823.1 607065 Fem 3 Forks....238
824.1 607066 Remote Radio Control....240
825.1 607067 Spare Wheel....242
826.1 607068 Special plate For Outriggers....244
827.1 607069 LMI Tower Lights....246

Indices

Part Number Index....248
Part Description Index....254

Cross References

MidWestTech | Terex Genie GTH-4016 SR, GTH-4018 SR Articulated Boom Lift Parts Manu... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	07.0703.0383	6-way Deutsch Connector	
2	56.0002.0069	3-way Deutsch Connector	
3	56.0002.0104	1-way Mark II Connector	
4	124221	2-way Connector	
5	56.0002.0153	2-way Deutsch Connector	
6	124234	Connector	
7	56.0002.0169	Rigid White Faston Cover	
8	125005	3-way Deutsch Connector	
9	101040	C/c D. 10 For Wire D. 70	
10	56.0002.0622	C/c D. 5,3 For Wire D. 1-2,5	
11	56.0002.0119	C/c D. 5,3 For Wire D. 3,10-5,30	
12	101052	C/c D. 10 For Wire D. 70	

MidWestTech | Terex Genie GTH-4016 SR, GTH-4018 SR Articulated Boom Lift Parts Manu... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	09.4675.0003	Hydraulic Jack	1
2	09.4675.0000	Ratchet Socket	1

MidWestTech | Terex Genie GTH-4016 SR, GTH-4018 SR Articulated Boom Lift Parts Manu... Order the manual at mid-west-tech.com >

Item	Part No.	Description	Qty.
1	56.0024.0027	Remote Control Kit	1
2	09.0803.0148	Adhesive Gasket	0,5-m
3	56.0008.5202	Backup Battery 12V 1,2Ah	1

MidWestTech | Terex Genie GTH-4016 SR, GTH-4018 SR Articulated Boom Lift Parts Manu... Order the manual at mid-west-tech.com >