1650K
Crawler Dozer

Service Manual

6-46470

CASE CONSTRUCTION

MidWestTech | Case 1650K Crawler Dozer Service Manual | Publication 6-46470

Order the manual at mid-west-tech.com >

SECTION 0


GENERALITIES


TABLE OF CONTENTS


SUBJECT	PAGE
SAFETY RULES	I - VIII
TABLE OF CAPACITIES	1
TABLE OF CENTRE OF GRAVITY	2
MAIN DIMENSIONS	3
TABLES OF TECHNICAL DATA	5
CHECK DATA ON THE MACHINE	16
EQUIPMENT MANOEUVRE TIMES	17
TABLE OF WEIGHTS	18
LEAKAGES	19
GENERAL INSTRUCTIONS	20
DIAGNOSTIC CHECKS	25
UNITS OF MEASURE	26
TABLE OF TIGHTENING TORQUES	28

MidWestTech | Case 1650K Crawler Dozer Service Manual | Publication 6-46470 Order the manual at mid-west-tech.com >

4.5.5 REAR TRANSMISSION (Section view transmission side)







Order the manual at mid-west-tech.com >