
bobcat

1600

SERVICE MANUAL



MELROE
INGERSOLL-RAND

6566906 (8-87)

bobcat

Printed in U.S.A.

MidWestTech | Bobcat 1600 Skid Steer Loader Service Manual | Publication 6566906_8_87 Order the manual at mid-west-tech.com >


HYDRAULIC / HYDROSTATIC FLOW CHART

For Model

1600 (S/N 11001 THRU 11999)

Chart # 6566839 (Printed February 1986)

RED - - - - - - - - High Pressure
BLUE - - - - - - - Low Pressure
GREEN - - - - - - Case Drain & Reservoir
ORANGE - - - - - Charge Pressure
LT. ORANGE - - Hydraulic Pump Charge



* Pump Inlet

E-1545

NOTE
Chart shows oil flow in Forward Drive Position and with Hydraulic Cylinders Partially Extended. For Hydraulic/ Hydrostatic System Operation, refer to Sheet 2 of this publication.

MidWestTech | Bobcat 1600 Skid Steer Loader Service Manual | Publication 6566906_8_87
Order the manual at mid-west-tech.com >