753

Operation & Maintenance Manual



MELROE COMPANY
A BUSINESS UNIT OF GREENLEE EQUIPMENT COMPANY

6720583 (12-9) Revised (10-92)-1.5M Printed in U.S.A.

bobcat®

© Melroe Company 1992

MidWestTech | Bobcat 753 Skid Steer Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

B. BEFORE OPERATING THE BOBCAT LOADER

⚠ This safety symbol is used for important safety messages. When you see this symbol, follow the safety message to avoid personal injury or death.

⚠WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.

W-2001-1285



B-10731

The Bobcat loader must be in good operating condition before use.

Check all of the items on the Service Schedule under the 8 - 10 hour column.

⚠WARNING

Warnings on the machine in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W-2044-1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284

C. SAFE OPERATION NEEDS A QUALIFIED OPERATOR

A QUALIFIED OPERATOR* MUST DO THE FOLLOWING:

1. UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS

   a. The written instructions from Melroe Company include the delivery report, Operation & Maintenance Manual and plastic handbook, EMI manual and machine signs (decals).

   b. Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may identify a hazard such as utility supply line.

2. HAVE TRAINING WITH ACTUAL OPERATION

   a. Operator training must consist of a demonstration and verbal instruction. This training is given by your dealer before the loader is delivered.

   b. The new operator should start in an area without bystanders and use all the controls until he can operate the loader safely under all conditions of the work area. Always fasten seat belt and lower seat bar before operating.

3. KNOW THE WORK CONDITIONS

   a. For each material to be handled, the operator must know how to avoid exceeding the rated operating capacity of the loader. For example, in handling certain loose material with a given bucket, he must know whether he can safely take a full load, or only part of a bucket load.

   b. The operator must know any prohibited uses or work areas, for example, he needs to know about excessive slopes.

   c. Wear tight fitting clothing. Always wear safety glasses when maintaining or servicing loader. Safety glasses, hearing protection or loader special applications kit are required for some work. See your dealer about Melroe safety equipment.

* For an operator to be qualified, he must not use drugs or alcoholic drinks which impair his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

MidWestTech | Bobcat 753 Skid Steer Loader Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >