bobcat®

LANDSCAPE RAKE

Operation & Maintenance Manual



MELROE COMPANY

6722755 (5–94) Revised (6–95)

A BUSINESS UNIT OF CLARK EQUIPMENT COMPANY

bobcat®

© Melroe Company 1995
Printed in U.S.A.

MidWestTech | Bobcat 4A, 4A-3, 5A, 5A-3, 6A, 6A-3 Landscape Rake Operation & Maintena... Order the manual at mid-west-tech.com >

SAFETY INSTRUCTIONS

SAFETY IS THE OPERATOR'S RESPONSIBILITY

The Bobcat loader and Bobcat Landscape Rake are designed to give maximum safety; but no machine design can prevent operator error or carelessness.

READ THIS MANUAL BEFORE YOU OPERATE THE BOBCAT LANDSCAPE RAKE AND LOADER

⚠ WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death



B–10731

Operation & Maintenance Manuals are written to give the owner/operator instructions on the safe operation and maintenance of the Bobcat loader and LANDSCAPE RAKE. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL AND THE LOADER OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR BOBCAT LOADER AND LANDSCAPE RAKE. If you have any questions, see your Bobcat Loader dealer.

⚠WARNING

Warnings on the machine and in the manuals are for your safety. Failure to obey warnings can cause injury or death.

W–2044–1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I–2019–0284

SAFE OPERATION NEEDS A QUALIFIED OPERATOR*

A QUALIFIED OPERATOR* MUST DO THE FOLLOWING:

- UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS
  - The written instructions from Melroe Company include the delivery report, loader operator's handbook and Manual, the attachment manual and machine signs (decals).
  - Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may identify a hazard such as a utility line.
- HAVE TRAINING WITH ACTUAL OPERATION
  - Operator training must consist of a demonstration and verbal instruction. This training is given by the Bobcat dealer before the loader is delivered.
  - The new operator should start in an area without bystanders and use all the controls until he can control the loader safely under all conditions of the work area.
- KNOW THE WORK CONDITIONS
  - The operator must know any prohibited uses or work areas, for the loader. For example, he needs to know about excessive slopes.

* For an operator to be qualified, he must not use drugs or alcoholic drinks which change his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

MidWestTech | Bobcat 4A, 4A-3, 5A, 5A-3, 6A, 6A-3 Landscape Rake Operation & Maintena... Order the manual at mid-west-tech.com >