OPERATOR'S MANUAL

EH80 EXCAVATORS



6-85590NA

MidWestTech | New Holland EH80 Excavator Operator's Manual | Publication 6-85590

Order the manual at mid-west-tech.com >

FOREWORD

GENERAL

- This manual contains procedures to aid the operator gain peak performance through effective machine operation and maintenance.
- Before operating the machine, operators must thoroughly read and understand all Safety, Operation and Maintenance instructions found in this manual. Failure to follow the instructions given in this manual may lead to serious injury to persons and or equipment failure.
- Operators and persons working with this machine should continually study this manual until proper Safety, Operation and Maintenance procedures are completely understood.
- This manual describes the basic operating techniques. Skill is gained as the operator utilizes these techniques and perfects them with an actual machine.
- Some illustrated pictures may be different from your machine, as technical improvement is continuous, manuals are periodically updated to reflect these changes.
- This manual may not contain attachments and optional equipment that are available in your area. Please contact an authorized dealer for any optional equipment.
- Materials and specifications are subject to change without notice.

TABLE OF CONTENTS

Section I – SAFETY PRECAUTIONS ..... 1-0 ~ 1-19
Section II – MACHINE FAMILIARIZATION ..... 2-0 ~ 2-29
Section III – BASIC MACHINE OPERATION ..... 3-0 ~ 3-35
Section IV – MAINTENANCE ..... 4-0 ~ 4-56
Section V – TRANSPORTATION ..... 5-0 ~ 5-8
Section VI – SPECIFICATIONS ..... 6-0 ~ 6-13
Section VII – TROUBLESHOOTING ..... 7-0 ~ 7-3
Section VIII – SCHEMATICS ..... 8-0 ~ 8-3
Section IX – OPTIONAL EQUIPMENT ..... 9-0 ~ 9-2
Section X – SPECIAL PROCEDURES ..... 10-0 ~ 10-7
Section XI – SPECIFICATIONS (EPA ENGINE) ..... 11-1 ~ 11-3

NOTICE


The contents of this manual may not reflect the specifications of the machine delivered. Contact an authorized Dealer to obtain assistance in specifications for machines equipped with options not contained in the manual.

Owing to the policy of continued improvement, changes may be made by NEW HOLLAND CONSTRUCTION to any its products without obligation on the part of NEW HOLLAND CONSTRUCTION

MidWestTech | New Holland EH80 Excavator Operator's Manual | Publication 6-85590 Order the manual at mid-west-tech.com >

8.1 ELECTRICAL SCHEMATIC

A. ELECTRIC CIRCUIT DIAGRAM (A)



MidWestTech | New Holland EH80 Excavator Operator's Manual | Publication 6-85590

Order the manual at mid-west-tech.com >