
X 325
X 328

Excavator Operation & Maintenance Manual

325 (S/N 514014900 & Above)
328 (S/N 516611001 & Above)



BOBCAT
INGERSOLL-RAND
6900556 (10-99) Revised (4-00)

Printed in U.S.A.

bobcat

© Bobcat/Ingersoll-Rand 2000

MidWestTech | Bobcat X325, X328 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

AIR CLEANER SERVICE 38

ALTERNATOR BELT ADJUSTMENT 44

COOLING SYSTEM
- Coolant Level 43
- Coolant Replacement 43

ELECTRICAL SYSTEM
- Electrical Relays and Diodes 44
- Electric Solenoid (Engine Stop) 48
- Fuses 44
- Removal And Installation of the Battery 48
- Service The Electrical System (and Battery) 45
- Using A Booster Battery (Jump Starting) 47

ENGINE COVER
- Adjustment Of The Engine Cover Latch 38
- Opening The Engine Cover 38

ENGINE LUBRICATION SYSTEM
- Checking Engine Oil 42
- Replacement Of Oil and Filter 42

FUEL SYSTEM
- Filling The Fuel Tank 40
- Fuel Filter 40
- Fuel Specifications 41
- Fuel System Maintenance 41
- Removing Air From The Fuel System 41

HEATER AIR FILTER (With Cab Option Only) 60

HYDRAULIC SYSTEM
- Checking And Adding Fluid 49
- Cleaning The Case Drain Filter 50
- Diagnostic Couplers 49
- Replacing The Hydraulic Filter 50
- Replacing The Hydraulic Oil 50

JOYSTICK CONTROL CHANGE
- ISO To Standard Control Pattern 55
- Standard To ISO Control Pattern 55

LUBRICATION OF THE HYDRAULIC EXCAVATOR 57

MAINTENANCE SAFETY 36

SERVICE SCHEDULE 37

SPARK ARRESTOR MUFFLER 51

TRACK TENSION
- Adjustment 52
- Rubber Tracks 52
- Steel Tracks 53

TRAVEL MOTOR
- Checking Oil Level 54
- Draining And Refilling 54

MidWestTech | Bobcat X325, X328 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

BEFORE OPERATING THE BOBCAT HYDRAULIC EXCAVATOR

Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before operating Bobcat loader or excavator and approved attachment. Untrained operators can cause injury or death.

W–2253–0996



B–10731

The Excavator must be in good operating condition before use. Check all of the items on the Service Schedule under the 8–10 hour column or as shown in this manual.

WARNING

For your safety, warnings are on the machine and in the Operation & Maintenance manual. Failure to obey warnings can cause injury or death.

W–2044–1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I–2019–0284

SAFE OPERATION NEEDS A QUALIFIED OPERATOR*

A QUALIFIED OPERATOR MUST DO THE FOLLOWING:

- UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS
  - The written instructions from Bobcat include the Delivery Report, Operation & Maintenance Manual, Operator Handbook, and machine signs (decals).
  - Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of Slow Moving Vehicle emblem. Regulations may identify a hazard such as a utility line.
- HAVE TRAINING WITH ACTUAL OPERATION
  - Operator training must consist of a demonstration and verbal instruction. This training is given by your excavator dealer before the excavator is delivered.
  - The new operator should start in an area without bystanders and use all the controls until he can operate safely under all conditions of the work area.
  - The Compact Excavator Operator Training Course is available in English and Spanish. The course provides information for safe and efficient operation. See your dealer for availability.
  - The Service Safety Training Course is available from your Bobcat dealer. This course provides information for safe and correct service procedures for Bobcat Hydraulic Excavator.
- KNOW THE WORK CONDITIONS
  - For each material to be handled, the operator must know how to avoid exceeding the rated lift capacity of the excavator. For example, you should not use the excavator for lifting heavy objects.
  - The operator must know any prohibited uses or work areas, for example, he needs to know about excessive slopes.
  - Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *SAFETY INSTRUCTIONS* Section of this manual.
  - Wear tight fitting clothing. Always wear safety glasses when maintaining or servicing excavator. Safety glasses, hearing protection or an excavator special application kit are required for some work. See your dealer about Melroe Safety equipment.

* For an operator be qualified, he must not use drugs or alcoholic drinks which impair his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

SI23–0100

MidWestTech | Bobcat X325, X328 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >