
X 337
X 341

Excavator Operation & Maintenance Manual

337 (S/N 515411001 & Above)
341 (S/N 230611001 & Above)



BOBCAT
INGERSOLL-RAND
6900662 (10-99) Revised (1-00)

Printed in U.S.A.

bobcat

©Bobcat/Ingersoll-Rand 2000

MidWestTech | Bobcat X337, X341 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

PREVENTIVE MAINTENANCE

AIR CLEANER
Air Cleaner Service 36

ALTERNATOR BELT
Adjustment 42

COOLING SYSTEM
Coolant Level 41
Propylene Glycol (Factory Installed) 41
Replacing Coolant 41

ELECTRICAL SYSTEM
Electrical Relays And Diodes 43
Electric Solenoid (Engine Stop) 47
Fuses 43
Removing And Installing The Battery 45
Servicing The Battery 46
Servicing The Electrical System 44
Using A Booster Battery (Jump Starting) 44

ENGINE COVER
Adjusting The Engine Cover Latches 36

ENGINE LUBRICATION SYSTEM
Checking Engine Oil 40
Replacing Oil And Filter 40

FUEL SYSTEM
Filling The Fuel Tank 38
Fuel Filter Service 38
Fuel Specifications 39
Fuel System Maintenance 39
Removing Air From The Fuel System 39

HEATER AIR FILTER (With Cab Option Only) 60

HYDRAULIC SYSTEM
Checking And Adding Fluid 47
Diagnostic Couplers 51
Replacing The Case Drain Filter 50
Replacing The Hydraulic Filter 49
Replacing The Hydraulic Oil 48

JOYSTICK CONTROL CHANGE (If Equipped)
ISO/Standard Control Pattern 56

LUBRICATION OF THE HYDRAULIC EXCAVATOR 57

MAINTENANCE SAFETY 34

SERVICE SCHEDULE 35

SPARK ARRESTOR MUFFLER (If Equipped) 52

TRACK TENSION
Adjustment 53
Rubber Tracks 53
Steel Tracks 54

TRAVEL MOTOR
Checking Oil Level 55
Draining And Refilling 55

MidWestTech | Bobcat X337, X341 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

BEFORE OPERATING THE BOBCAT HYDRAULIC EXCAVATOR

Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

WARNING

Operator must have instructions before operating Bobcat loader or excavator and approved attachment. Untrained operators can cause injury or death.

W–2253–0996



B–10731

The Excavator must be in good operating condition before use. Check all of the items on the Service Schedule under the 8–10 hour column or as shown in this manual.

WARNING

For your safety, warnings are on the machine and in the Operation & Maintenance manual. Failure to obey warnings can cause injury or death.

W–2044–1285

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I–2019–0284

SAFE OPERATION NEEDS A QUALIFIED OPERATOR*

A QUALIFIED OPERATOR MUST DO THE FOLLOWING:

- UNDERSTAND THE WRITTEN INSTRUCTIONS, RULES AND REGULATIONS
  - The written instructions from Bobcat include the Delivery Report, Operation & Maintenance Manual, Operator Handbook, and machine signs (decals).
  - Check the rules and regulations at your location. The rules may include an employer's work safety requirements. Regulations may apply to local driving requirements or use of Slow Moving Vehicle emblem. Regulations may identify a hazard such as a utility line.
- HAVE TRAINING WITH ACTUAL OPERATION
  - Operator training must consist of a demonstration and verbal instruction. This training is given by your excavator dealer before the excavator is delivered.
  - The new operator should start in an area without bystanders and use all the controls until he can operate safely under all conditions of the work area.
  - The Compact Excavator Operator Training Course is available in English and Spanish. The course provides information for safe and efficient operation. See your dealer for availability.
  - The Service Safety Training Course is available from your Bobcat dealer. This course provides information for safe and correct service procedures for Bobcat Hydraulic Excavator.
- KNOW THE WORK CONDITIONS
  - For each material to be handled, the operator must know how to avoid exceeding the rated lift capacity of the excavator. For example, you should not use the excavator for lifting heavy objects.
  - The operator must know any prohibited uses or work areas, for example, he needs to know about excessive slopes.
  - Know the location of any underground lines. Call local utilities or the TOLL FREE phone number found in the *SAFETY INSTRUCTIONS* Section of this manual.
  - Wear tight fitting clothing. Always wear safety glasses when maintaining or servicing excavator. Safety glasses, hearing protection or an excavator special application kit are required for some work. See your dealer about Bobcat Safety equipment.

* For an operator to be qualified, he must not use drugs or alcoholic drinks which impair his alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he can safely operate a machine.

SI23–0100

MidWestTech | Bobcat X337, X341 Excavator Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >