
Trenchers

LT112
MX112
LT113
LT213
LT313
LT414

Bobcat®

Trencher Chain Pattern Manual

(LT112) S/N 045200101 & Above
(MX112) S/N 045100101 & Above
(LT113) S/N 233800101 & Above
(LT213) S/N 045300101 & Above
(LT313) S/N 045400101 & Above
(LT414) S/N AORS00101 & Above



Ingersoll Rand
Compact Vehicle Technologies

6903853 (4-06)

Printed in U.S.A.

© Bobcat Company 2006

MidWestTech | Bobcat LT112, MX112, LT113, LT213, LT313, LT414 Trencher Service Man... Order the manual at mid-west-tech.com >

LT112 & MX112 TRENCHERS

LT113 TRENCHERS

LT213 TRENCHERS

LT313 TRENCHERS

LT414 TRENCHERS

CONTENTS

CHAIN AND SPROCKET WEAR LIMITS IV

CHAIN PITCH III

GROUND CONDITIONS. III
Digging Speed III

LT112 & LT113 TRENCHERS 112-01

LT113 TRENCHERS. 113-01

LT213 TRENCHERS. 213-01

LT313 TRENCHERS. 313-01

LT414 TRENCHERS. 414-01

REFERENCE INFORMATION

Write the correct information for YOUR Trencher Attachment in the spaces below. Always use these numbers when referring to your Trencher.

Trencher Serial Number _____

_____

_____

_____

NOTES:

_____

_____

YOUR BOBCAT® DEALER:

ADDRESS:

_____

PHONE:

_____


Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
J. Huysmanslaan 59
B-1651 LOT
Belgium

MidWestTech | Bobcat LT112, MX112, LT113, LT213, LT313, LT414 Trencher Service Man... Order the manual at mid-west-tech.com >


Component Description (Cont'd)

Figure 414-20-6




Center Mount Assembly **[Figure 414-20-6]**.

Figure 414-20-7




1.0 Mount Assembly **[Figure 414-20-7]**.

Figure 414-20-8




2.0 Mount Assembly **[Figure 414-20-8]**.

Figure 414-20-9




3.0 Mount Assembly **[Figure 414-20-9]**.

Figure 414-20-10



4.0 Mount Assembly **[Figure 414-20-10]**.

Figure 414-20-11



5.0 Mount Assembly **[Figure 414-20-11]**.

MidWestTech | Bobcat LT112, MX112, LT113, LT213, LT313, LT414 Trencher Service Man... Order the manual at mid-west-tech.com >