
Bobcat®

Parts Manual
S185 Skid-Steer Loader

S/N A3L911001 & Above
S/N A3LH11001 & Above
S/N AEYU11001 & Above



EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)

6986838 (5-08)

Printed in U.S.A.

© Bobcat Company 2008

MidWestTech | Bobcat S185 Skid Steer Loader Parts Manual | Publication 6986838 Order the manual at mid-west-tech.com >

Title: Connector Harness Assembly
Model Number: S185
Serial Number: A3L911001 & Above, A3LH11001 & Above, AEYU11001 & Above

Ref #	Part #	Description	S/N	Q-ty
1		CONNECTOR, CONNECTOR, NSS - Order components		1
2		BOLT, BOLT, NSS - Order Ref. 3		1
3	6688834	CONNECTOR, cab - W/Ref. 2 & 4		1
4		SEAL, SEAL, NSS - Order Ref. 3 or 7 - Was 6697794, A		1
5		SEAL, SEAL, NSS - Order Ref. 6 - Was 6697793, A		1
6	6688836	FLANGE, W/Ref. 5 & 8		1
7	6688833	CONNECTOR, engine - W/Ref. 4		1
8		CLIP, CLIP, NSS - metal - Order Ref. 6		2

Order the manual at mid-west-tech.com >

Title: Governor (Fork Lever)
Model Number: S185
Serial Number: A3L911001 & Above, A3LH11001 & Above, AEYU11001 & Above

Ref #	Part #	Description	S/N	Q-ty
1	7000639	LEVER, FORK, W/Ref. 2-12		1
2		BEARING, BEARING, NSS - Order Ref. 1		2
3		SHAFT, SHAFT, NSS - Order Ref. 1		1
4		BRACKET, BRACKET, NSS - Order Ref. 1		1
5		LEVER, LEVER, NSS - Order Ref. 1		1
6		SPRING, SPRING, NSS - Order Ref. 1		1
7		PIN, PIN, NSS - Order Ref. 1		1
8		BUSHING, BUSHING, NSS - Order Ref. 1		2
9	6680823	SNAP RING		1
10	6680822	RING SNAP, Was 7000596, B,D		2
11	6680821	SNAP RING		1
12	6680820	WASHER		1
13	7000732	SPRING GOVERNOR		1
14	7000733	SPRING START		1
15	6685952	NUT		1
16	7000624	SHAFT, FORK LEVER	Engine 9FZ999 & Below	
16	7020987	SHAFT, FORK LEVER	Engine 9G0001 & Above	
17	6652592	PIN		1

Order the manual at mid-west-tech.com >

Title: Hydrostatic Pump (Manual Controls & ACS)
Model Number: S185
Serial Number: A3L911001 & Above, A3LH11001 & Above, AEYU11001 & Above

Ref #	Part #	Description	S/N	Q-ty
25		WASHER, WASHER, NLA - Order Ref. 53		1
26		SPRING, SPRING, NLA - Order Ref. 53		1
27		WASHER, WASHER, NLA - Order Ref. 53		1
28		WASHER, WASHER, NLA - Order Ref. 53		1
29	6687774	PLATE PUMP		1
30	6650636	PIN		1
31	47K8	PLUG		2
31	6645083	O-RING		2
32	6675342	PIN		4
33		PLUG, PLUG, NLA - Order Ref. 51		2
34	6657028	O-RING		2
35	79K8	O-RING		2
36		SPRING, SPRING, NLA - Order Ref. 51		2
37		RETAINER, RETAINER, NLA - Order Ref. 51		2
38		CHECK VALVE, CHECK VALVE, NLA - poppet - Order Ref. 51		1
39	7023162	CAP END, Was 6669406, A		1
40	6650637	BOLT		4
41	6650635	BEARING		1
42	6650647	O-RING		1
43	6645081	O-RING		1
44	6650675	COUPLER		1
45	6650646	O-RING		1
46	6660814	RING QUAD		2
47	6645086	PLUG		2
47	6661481	O-RING		1

Order the manual at mid-west-tech.com >