
Bobcat®

Service Manual
Three-Point Snow Blower

3SB
(54 Inch) S/N ABCW00101 & Above
(66 Inch) S/N ABCU00101 & Above
(72 Inch) S/N AB4K00101 & Above



6987121 (11-08)

Printed in U.S.A.

© Bobcat Company 2008

MidWestTech | Bobcat 3SB Three-Point Snow Blower Attachment Service Manual | Publica... Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

AUGER 30-10-1

CHAIN DRIVE 30-20-1
CROSS SHAFT 30-90-1

DEFLECTOR 30-40-1
DELIVERY REPORT III
DISCHARGE CHUTE 30-30-1

FAN 30-40-1

GEARBOX 30-60-1
GEARBOX FLUID CHANGE 10-60-1

HAND CRANK 30-70-1
HYDRAULIC SCHEMATIC . . . . . SPEC 10-1

IDENTIFICATION AND MACHINE SIGNS (DECALS) IV
IMPLEMENT STORAGE AND RETURN TO SERVICE 10-80-1
INSPECTION 10-30-1

LUBRICATING THE IMPLEMENT 10-40-1

REGULAR MAINTENANCE ITEMS 10-50-1
REMOVAL AND INSTALLATION 10-70-1
ROTATOR CHAIN (LOWER CHAIN) 30-81-1
ROTATOR CHAIN (UPPER CHAIN) 30-80-1
ROTATOR MOTOR 20-10-1

SERIAL NUMBER LOCATION III
SERVICE SCHEDULE 10-20-1
SNOW BLOWER IMPLEMENT SPECIFICATIONS . . . . . SPEC 20-1

TROUBLESHOOTING 10-10-1

MidWestTech | Bobcat 3SB Three-Point Snow Blower Attachment Service Manual | Publica... Order the manual at mid-west-tech.com >

CONTENTS

DELIVERY REPORT III

IDENTIFICATION AND MACHINE SIGNS (DECALS) IV

SERIAL NUMBER LOCATION III

PREVENTIVE MAINTENANCE 10-1

HYDRAULIC SYSTEM 20-1

MAIN FRAME 30-1

SPECIFICATIONS AND SCHEMATICS SPEC-1

REFERENCE INFORMATION

Write the correct information for YOUR three-point snow blower in the spaces below. Always use these numbers when referring to your three-point snow blower.

Three-Point Snow Blower Serial Number _____

_____

_____

_____

NOTES:

_____

_____

_____

_____

YOUR BOBCAT® DEALER:

ADDRESS:

_____

PHONE:

_____

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Dréve Richelle 167
B-1410 WATERLOO
Belgium

MidWestTech | Bobcat 3SB Three-Point Snow Blower Attachment Service Manual | Publica... Order the manual at mid-west-tech.com >

TROUBLESHOOTING


Chart

PROBLEM	CAUSE	CORRECTION
Snow blower does not operate	Damaged or incorrect attachment of the PTO driveline	Check connection, connect properly, repair or replace
	Auger shear bolt has sheared / missing	Replace bolt
	PTO shear bolt has sheared / missing	Replace bolt
	Chain broke or derailed	Repair or replace
	Bolt at connection of sprocket to auger broke or missing	Replace bolt
Chute does not rotate	Loose or broken chute rotation chain	Repair or replace
Snow blower cuts too low / too high	Skid shoes out of adjustment	Raise or lower skid shoes as needed
OPTIONAL HYDRAULIC CHUTE ROTATION EQUIPPED MODELS		
PROBLEM	**CAUSE**	**CORRECTION**
Chute does not rotate	Damaged quick couplers	Replace quick couplers
	Damaged hydraulic motor	Repair or replace
	Loose or broken chute rotation chain	Repair or replace

MidWestTech | Bobcat 3SB Three-Point Snow Blower Attachment Service Manual | Publica... Order the manual at mid-west-tech.com >

HYDRAULIC SCHEMATIC

Hydraulic Chute Schematic (Optional)



P-83099

MidWestTech | Bobcat 3SB Three-Point Snow Blower Attachment Service Manual | Publica... Order the manual at mid-west-tech.com >