ISUZU

WORKSHOP MANUAL
INDUSTRIAL
DIESEL ENGINE
6RB1·6RB1T
MODELS

FOREWORD

This Workshop Manual is designed to help you perform necessary maintenance, service, and repair procedures on applicable Isuzu industrial engines.

Information contained in this Workshop Manual is the latest available at the time of publication.

Isuzu reserves the right to make changes at any time without prior notice.

The Table of Contents at the right hand side of this page shows you the general arrangement of the material in this Workshop Manual. A more detailed Table of Contents precedes each individual section.

The black spot at the right hand side of some pages indicates the first page of a given section.

This Workshop Manual is applicable to 1987 and earlier models.

TABLE OF CONTENTS

SECTION	NAME
1	GENERAL INFORMATION
2	MAINTENANCE
3	ENGINE ASSEMBLY I (DISASSEMBLY)
4	ENGINE ASSEMBLY II (INSPECTION & REPAIR)
5	ENGINE ASSEMBLY III (REASSEMBLY)
6	LUBRICATING SYSTEM
7	COOLING SYSTEM
8	FUEL SYSTEM
9	TURBOCHARGER
10	AIR COMPRESSOR
11	ENGINE ELECTRICALS
12	TROUBLESHOOTING
13	SPECIAL TOOL LIST
14	CONVERSION TABLE

MidWestTech | JCB Isuzu 6RB1-6RB1T Industrial Diesel Engine Service Manual | Publicati... Order the manual at mid-west-tech.com >

SECTION 1

GENERAL INFORMATION

TABLE OF CONTENTS

ITEM	PAGE
General repair instructions	1— 2
Notes on the format on this manual	1— 2
Main data and specifications	1— 6
Design features and general outline	1— 8
Tightening torque specifications	1— 9
Angular nut and bolt tightening method	1—10
Major parts fixing nuts and bolts	1—12
Identifications	1—23

MidWestTech | JCB Isuzu 6RB1-6RB1T Industrial Diesel Engine Service Manual | Pub... Order the manual at mid-west-tech.com >