# 1150G Crawler

# Parts Catalog

**Bur 7-1023**

CASE CONSTRUCTION



Order the manual at mid-west-tech.com >

# PICTORIAL SECTION INDEX




















GENERAL 1

ENGINE 2

FUEL 3

ELECTRICAL 4

TRACKS 5

POWER TRAIN 6

BRAKES 7

HYDRAULIC 8

CHASSIS AND MOUNTED EQUIPMENT 9

NUMERICAL INDEX 10




MidWestTech | Case 1150G Crawler Parts Catalog | Publication 7-1023 Order the manual at mid-west-tech.com >

# GENERAL INFORMATION

## Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

## Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

## Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

## Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

## Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

## Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

## Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

# HYDRAULIC FILTER

| REF. | PART NO. | DESCRIPTION | REQ'D. |
|---|---|---|---|
| 1 | D4356734 | FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after | 1 |
| | D61903 | HEAD ASSEMBLY - filter | 1 |
| 2 | NSS | HEAD - filter, order D61903 head assembly | 1 |
| 3 | D58199 | VALVE - bypass | 1 |
| | D43800 | KIT - filter element, replaces D35700 element kit | 1 |
| 4 | NSS | ELEMENT - filter, order D43800 element kit | 1 |
| 5 | A27994 | O-RING - filter | 1 |
| 6 | D61948 | HOUSING -filter | 1 |
| 7 | REF | CANOPY - ROPS, order from Machinery Price List | 1 |
| 8 | 843065C1 | HOSE - 3353 mm (132 inch) long, reservoir to pump | 1 |
| 9 | 113-323 | BOLT - hex, 7/16 NC x 1-3/4 inch | 2 |
| 10 | 814-8030 | BOLT - hex, 8 - 1.25 x 30 mm | 4 |

MidWestTech | Case 1150G Crawler Parts Catalog | Publication 7-1023 Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX


A

Adjuster - track ..... 5-9
Air Cleaner Assembly ..... 2-15,2-15B
Air Cleaner Mounting ..... 2-13,2-13B
Air Conditioning System ..... 9-65 - 9-69
Air Intake Parts ..... 2-15,2-15B
Air Restriction Indicator ..... 2-17,4-9
Alarm - backup ..... 4-33
Alternator
  Assembly ..... 4-5
  Mounting ..... 2-3,4-15
Aneroid System ..... 3-11D
Arm - windshield wiper ..... 4-29,4-31
Armrests ..... 9-37

B

Backup Alarm ..... 4-33
Batteries and Cables ..... 4-13
Battery Mounting ..... 4-13
Belt
  Air Conditioning Compressor ..... 9-71
  Fan ..... 2-3
  Seat ..... 9-37
Blade - dozer ..... 9-5,9-7
Blade - windshield wiper ..... 4-29,4-31
Block - cylinder, engine ..... 2-39 - 2-41D
Block Heater - engine ..... 2-41,2-41D
Blower - air conditioning condenser ..... 4-41
Blower - cab ..... 4-39
Brakes
  Pedals ..... 7-7
  Power - pedals ..... 7-5,7-9
  Transmission ..... 7-3
  Valve ..... 7-11
Brush Screens - ROPS ..... 9-45,9-47

C

Cab
  Air Conditioning ..... 9-65 - 9-69
  Air Filter ..... 9-59
  Blower - inside cab roof ..... 4-39
  Compressor - air conditioning ..... 9-71
  Condenser - air conditioning ..... 9-65
  Condenser Blower - cooling ..... 4-41
  Control Panel ..... 4-25
  Door ..... 9-51
  Electrical ..... 4-25,4-27
  Frame and Mounting ..... 9-49
  Glass ..... 9-55,9-57
  Headliner ..... 9-59
  Heating System ..... 9-63
  Screen - rear ..... 9-53
  Window - door ..... 9-53

C

Cab - Cont'd
  Windshield Wipers ..... 4-29,4-31
Camshaft - engine ..... 2-37,2-37B
Canopy - ROPS ..... 9-45,9-47
Carrier Roller Assembly ..... 5-13
C-Frame - dozer ..... 9-3
Chain - track ..... 5-19 - 5-23
Circuit Breaker - cab ..... 4-27
Clutch - transmission ..... 6-17 - 6-21
Cold Start System ..... 4-37
Compressor - air conditioning ..... 9-71
Connecting Rods - engine ..... 2-47,2-47B
Control Valve - equipment ..... 8-45 - 8-59
Control Valve Mounting - equipment ..... 8-35
Controls
  Brake ..... 7-5,7-7
  Engine Throttle ..... 3-3 - 3-3F
  Equipment - levers and linkage ..... 8-37 - 8-43D
  Fuel Shutoff ..... 3-7
  Transmission ..... 6-47,6-49
Coolant Recovery System - radiator ..... 2-9
Cooling System - transmission ..... 6-39,6-41
Covers
  Air Conditioning System ..... 9-65
  Backup Alarm ..... 4-33
  Console ..... 6-49
  Engine Oil Drain ..... 9-17
  Equipment Controls and Valve ..... 9-49
  Fuel Gauge ..... 3-5
  Fuse Block ..... 4-25,9-59
  Gear - front ..... 2-21,2-21B
  Instrument Panel - anti-vandalism ..... 9-33
  Rear - battery access ..... 9-23
  Recoil Housing ..... 5-7
  Reservoir - hydraulic ..... 8-5
  Track Adjuster ..... 5-5
Crankshaft - engine ..... 2-43,2-43B
Cylinder - cold start fluid ..... 4-37
Cylinder Block ..... 2-39,2-41
Cylinder Head ..... 2-35,2-35B
Cylinder Head Cover ..... 2-33,2-33B
Cylinders - hydraulic
  Angle ..... 8-31
  Lift ..... 8-27
  Ripper ..... 8-33
  Tilt ..... 8-29

D

Decals ..... 9-73,9-75
Dipstick
  Engine Oil ..... 2-5,2-5B
  Transmission Oil ..... 6-13




MidWestTech | Case 1150G Crawler Parts Catalog | Publication 7-1023 Order the manual at mid-west-tech.com >