CASE

PROFESSIONAL PARTNER

# PARTS CATALOG
# GRADER

## 885
## TIER 3

**ASN N8AF05111~**

71114175 NA

Issued 01Mar 08



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 02-02 | 01 | ENGINE - MOUNTING |
| 02-04 | 01 | COOLING SYSTEM - RADIATOR - MOUNTING |
| 02-06 | 01 | COOLING SYSTEM - FAN - MOUNTING |
| 02-08 | 01 | COOLING SYSTEM - TUBING |
| 02-10 | 01 | COOLING SYSTEM - EXPANSION TANK |
| 02-12 | 01 | COOLING SYSTEM - AFTERCOOLER |
| 02-14 | 01 | AIR CLEANER - MOUNTING |
| 02-16 | 01 | AIR CLEANER - ASSEMBLY |
| 02-18 | 01 | AIR PRE-CLEANER - ASSEMBLY |
| 02-20 | 01 | MUFFLER AND EXHAUST SYSTEM |
| 02-22 | 01 | ENGINE - BELT |
| 02-24 | 01 | ENGINE - OIL FILTER |
| 03-02 | 01 | THROTTLE AND LINKS |
| 03-04 | 01 | ACCELERATOR PEDAL |
| 03-06 | 01 | FUEL RESERVOIR |
| 03-08 | 01 | FUEL LINE |
| 03-10 | 01 | FUEL FILTER - LINES |
| 03-12 | 01 | FUEL FILTER - WATER SEPARATOR |
| 03-14 | 01 | FUEL FILTER |
| 04-02 | 01 | STARTER - ASSEMBLY |
| 04-04 | 01 | ALTERNADOR 80A - ASSEMBLY |
| 04-06 | 01 | ALTERNADOR 80A - ASSEMBLY |
| 04-08 | 01 | ELECTRICAL SYSTEM - MAIN |
| 04-10 | 01 | ELECTRICAL SYSTEM - INSTRUMENT PANEL |
| 04-12 | 01 | ELECTRICAL SYSTEM - CIGARETTE LIGHTER |
| 04-14 | 01 | ELECTRICAL SYSTEM - COMMAND PANEL |
| 04-16 | 01 | ELECTRICAL SYSTEM - RELAYS AND FUSES |
| 04-18 | 01 | ELECTRICAL SYSTEM - ELECTRONIC CONTROL UNIT |
| 04-20 | 01 | ELECTRICAL SYSTEM - ENGINE |
| 04-22 | 01 | ELECTRICAL SYSTEM - BATTERY |
| 04-24 | 01 | ELECTRICAL SYSTEM - TRANSMISSION |
| 04-26 | 01 | ELECTRICAL SYSTEM - HORN |
| 04-28 | 01 | ELECTRICAL SYSTEM - VOLTAGE CONVERTER |
| 04-30 | 01 | ELECTRICAL SYSTEM - BACK-UP ALARM |
| 04-32 | 01 | ELECTRICAL SYSTEM - HYDRAULIC ACCUMULATOR (AUX. EQUIPMENT OPCIONAL) |
| 04-34 | 01 | ELECTRICAL SYSTEM - CAB |
| 04-36 | 01 | ELECTRICAL SYSTEM - OPEN CAB |
| 04-38 | 01 | FRONT CHASSIS HEADLIGHTS |
| 04-40 | 01 | CAB HEADLIGHT AND LANTERN |
| 04-42 | 01 | FRONT AND REAR HEADLIGHT - COMPONENTS |
| 04-44 | 01 | ROTATING BEACON - COMPONENTS |
| 04-46 | 01 | REAR LAMP AND TURN SIGNAL - COMPONENTS |
| 04-48 | 01 | AIR CONDITIONING SYSTEM |
| 04-50 | 01 | FRONT/REAR WINDSHIELD WIPER MOTOR (CAB) |
| 04-52 | 01 | ELECTRICAL SYSTEM - SCARIFIER AND RIPPER |
| 04-54 | 01 | FAN - OPEN CAB |
| 04-56 | 01 | LOWER CAB HEADLIGHTS |
| 04-58 | 01 | ELECTRICAL SYSTEM - REVERSE FAN |
| 05-02 | 01 | STEERING COLUMN - ASSEMBLY |
| 05-04 | 01 | BRAKE AND STEERING - HYDRAULIC CIRCUIT |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 05-06 | 01 | STEERING CYLINDER - ASSEMBLY |
| 05-08 | 01 | HYDROSTATIC STEERING VALVE - ASSEMBLY |
| 05-10 | 01 | PRIORITY VALVE - ASSEMBLY |
| 06-02 | 01 | TRANSMISSION AND COUPLING |
| 06-04 | 01 | TRANSMISSION - SHIFT LEVER |
| 06-06 | 01 | TRANSMISSION - CLUTCH PEDAL (INCHING) |
| 06-08 | 01 | TRANSMISSION - LUBRICATING SYSTEM |
| 06-10 | 01 | TRANSMISSION - OIL FILTER |
| 06-12 | 01 | TRANSMISSION - OIL DIPSTICK |
| 06-14 | 01 | TRANSMISSION - HOUSING AND INPUT SHAFT |
| 06-16 | 01 | TRANSMISSION - 1st SPEED AXLE |
| 06-18 | 01 | TRANSMISSION - 2nd SPEED AXLE |
| 06-20 | 01 | TRANSMISSION - 3rd SPEED AXLE |
| 06-22 | 01 | TRANSMISSION - 4th SPEED AXLE |
| 06-24 | 01 | TRANSMISSION - 5th SPEED AXLE |
| 06-26 | 01 | TRANSMISSION - 6th SPEED AXLE |
| 06-28 | 01 | TRANSMISSION - OUTPUT SHAFT |
| 06-30 | 01 | TRANSMISSION - MAIN HOUSING |
| 06-32 | 01 | TRANSMISSION - CONTROL VALVE ASSEMBLY |
| 06-34 | 01 | TRANSMISSION - CONTROL VALVE COMPONENTS |
| 06-36 | 01 | TRANSMISSION - SOLENOID VALVE |
| 06-38 | 01 | TRANSMISSION - OUTPUT FLANGE |
| 06-40 | 01 | TRANSMISSION - OIL PUMP |
| 06-42 | 01 | TRANSMISSION - OIL COOLING SYSTEM |
| 06-44 | 01 | TRANSMISSION - OIL COOLING SYSTEM |
| 06-46 | 01 | FRONT AXLE - ASSEMBLY |
| 06-48 | 01 | FRONT AXLE - LEFT SIDE STEERING KNUCKLE - ASSEMBLY |
| 06-50 | 01 | FRONT AXLE - RIGHT SIDE STEERING KNUCKLE - ASSEMBLY |
| 06-52 | 01 | FRONT AXLE - WHEEL HUB - ASSEMBLY |
| 06-54 | 01 | FRONT AXLE - SUPPORT BEARING |
| 06-56 | 01 | REAR AXLE GRAZIANO - ASSEMBLY |
| 06-58 | 01 | REAR AXLE GRAZIANO - CENTER HOUSING |
| 06-60 | 01 | REAR AXLE GRAZIANO - PLANETARY GEAR - ASSEMBLY |
| 06-62 | 01 | REAR AXLE GRAZIANO - DIFFERENTIAL |
| 06-66 | 01 | REAR AXLE GRAZIANO - TANDEM |
| 06-68 | 01 | REAR AXLE GRAZIANO - BRAKE ASSEMBLY |
| 06-70 | 01 | WHEELS AND TIRES |
| 07-02 | 01 | PARKING BRAKE - LINKAGE |
| 07-04 | 01 | PARKING BRAKE - LEVER |
| 07-06 | 01 | PARKING BRAKE - BRAKE DISC |
| 07-08 | 01 | PARKING BRAKE - BRAKING CALIPER |
| 07-10 | 01 | SERVICE BRAKE PEDAL |
| 07-12 | 01 | SERVICE BRAKE HYDRAULIC CIRCUIT |
| 07-14 | 01 | BRAKE VALVE |
| 07-16 | 01 | SERVICE BRAKE HYDRAULIC SYSTEM |
| 07-18 | 01 | EMERGENCY BRAKE SYSTEM - ASSEMBLY |
| 07-20 | 01 | EMERGENCY BRAKE SYSTEM - ACCUMULATOR |
| 08-002 | 01 | HYDRAULIC OIL RESERVOIR - ASSEMBLY |
| 08-004 | 01 | HYDRAULIC OIL RESERVOIR - FILTER |
| 08-006 | 01 | MAIN HYDRAULIC PUMP |
| 08-008 | 01 | MAIN HYDRAULIC PUMP - RELIEF VALVE |



Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 08-010 | 01 | MAIN HYDRAULIC PUMP - HYDRAULIC CIRCUIT |
| 08-012 | 01 | MAIN HYDRAULIC PUMP - HYDRAULIC CIRCUIT |
| 08-014 | 01 | BLADE HYDRAULIC CIRCUIT - SIDE SHIFT AND TILT |
| 08-016 | 01 | BLADE HYDRAULIC CIRCUIT - SIDE SHIFT AND TILT |
| 08-018 | 01 | BLADE HYDRAULIC CIRCUIT - SIDE SHIFT ACCUMULATOR (OPTIONAL) |
| 08-020 | 01 | BLADE HYDRAULIC CIRCUIT - ROTATING DISTRIBUTOR |
| 08-022 | 01 | BLADE HYDRAULIC CIRCUIT - LOCK (3 HOLES) |
| 08-024 | 01 | BLADE HYDRAULIC CIRCUIT - LOCK (5 HOLES) |
| 08-026 | 01 | BLADE HYDRAULIC CIRCUIT - LIFTING |
| 08-028 | 01 | BLADE HYDRAULIC CIRCUIT - LIFTING ACCUMULATOR (OPTIONAL) |
| 08-030 | 01 | BLADE HYDRAULIC CIRCUIT - TILT |
| 08-032 | 01 | BLADE HYDRAULIC CIRCUIT - FLOAT CONTROL |
| 08-034 | 01 | BLADE HYDRAULIC CIRCUIT - FLOAT CONTROL |
| 08-036 | 01 | BLADE HYDRAULIC CIRCUIT - FLOAT SOLENOID VALVE |
| 08-038 | 01 | CIRCLE HYDRAULIC CIRCUIT - SIDE SHIFT |
| 08-040 | 01 | CIRCLE HYDRAULIC CIRCUIT - TURN-CIRCLE CIRCUIT |
| 08-042 | 01 | CIRCLE HYDRAULIC CIRCUIT - TURN-CIRCLE REDUCER |
| 08-044 | 01 | CIRCLE HYDRAULIC CIRCUIT - TURN-CIRCLE HYDRAULIC MOTOR |
| 08-046 | 01 | FRONT AXLE HYDRAULIC CIRCUIT - TILT |
| 08-048 | 01 | ARTICULATION HYDRAULIC CIRCUIT |
| 08-050 | 01 | SCARIFIER HYDRAULIC CIRCUIT |
| 08-052 | 01 | SCARIFIER AND RIPPER HYDRAULIC CIRCUIT |
| 08-054 | 01 | RIPPER HYDRAULIC CIRCUIT |
| 08-056 | 01 | RIPPER HYDRAULIC CIRCUIT |
| 08-058 | 01 | REAR HYDRAULIC CIRCUIT |
| 08-060 | 01 | ENGINE COOLING SYSTEM - FAN HYDRAULIC CIRCUIT |
| 08-062 | 01 | ENGINE COOLING SYSTEM - REVERSE FAN HYDRAULIC PUMP |
| 08-064 | 01 | ENGINE COOLING SYSTEM - REVERSE FAN HYDRAULIC MOTOR |
| 08-066 | 01 | ENGINE COOLING SYSTEM - HYDRAULIC PUMP ASSEMBLY |
| 08-068 | 01 | ENGINE COOLING SYSTEM - CONTROL VALVE |
| 08-070 | 01 | ENGINE COOLING SYSTEM - "ON-OFF" SYSTEM |
| 08-072 | 01 | ENGINE COOLING SYSTEM - HYDRAULIC MOTOR |
| 08-074 | 01 | ENGINE COOLING SYSTEM - HYDRAULIC MOTOR |
| 08-076 | 01 | BRAKE AND STEERING - HYDRAULIC CIRCUIT |
| 08-078 | 01 | BRAKE AND STEERING - HYDRAULIC PUMP |
| 08-080 | 01 | BRAKE AND STEERING - RELIEF VALVE |
| 08-082 | 01 | DIFFERENTIAL LOCK - HYDRAULIC CIRCUIT |
| 08-084 | 01 | DIFFERENTIAL LOCK - SOLENOID VALVE |
| 08-086 | 01 | DISTRIBUTOR - ASSEMBLY |
| 08-088 | 01 | DISTRIBUTOR - HYDRAULIC CIRCUIT |
| 08-090 | 01 | DISTRIBUTOR - OUTPUT VALVE |
| 08-092 | 01 | DISTRIBUTOR - BLADE LIFT VALVE LH/RH |
| 08-094 | 01 | DISTRIBUTOR - FRONT AXLE AND BLADE TILT VALVE |
| 08-096 | 01 | DISTRIBUTOR - ARTICULATION LINK VALVE |
| 08-098 | 01 | DISTRIBUTOR - TURN-CIRCLE SIDE SHIFT VALVE |
| 08-100 | 01 | DISTRIBUTOR - TURN-CIRCLE VALVE |
| 08-102 | 01 | DISTRIBUTOR - BLADE SIDE SHIFT VALVE |
| 08-104 | 01 | DISTRIBUTOR - SCARIFIER/RIPPER VALVE |
| 08-106 | 01 | DISTRIBUTOR - INPUT VALVE |
| 08-108 | 01 | VALVE RETAINER - ASSEMBLY |
| 08-110 | 01 | FRONT AXLE LEAN CYLINDER - ASSEMBLY |



Order the manual at mid-west-tech.com >

## CAB HEADLIGHT AND LANTERN

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | 1 | REF | | 4 | INSTRUCTION, HEAD-LIGHT |
| 2 | | 14496621 | | 4 | WASHER, M10 x 21 x 2 |
| 3 | | 79089658 | | 4 | PAD |
| 4 | | 75252602 | | 4 | WASHER |
| 5 | | 12104121 | | 4 | NUT |
| 6 | 2 | REF | | 2 | INSTRUCTION, LIGHT turn-signal |
| 7 | | 12644421 | | 4 | WASHER, M6 x 15 x 1 |
| 8 | | 70928182 | | 4 | SCREW |
| 9 | | 75267959 | | 1 | SUPPORT, LH |
| 9 | | 75267960 | | 1 | SUPPORT, RH |
| 10 | | 12104121 | | 3 | NUT |
| 11 | | 12646721 | | 3 | WASHER, M8 x 20 x 2 |
| 12 | 2 | REF | | 1 | INSTRUCTION, ROAD LIGHT RH |
| 12 | 2 | REF | | 1 | INSTRUCTION, ROAD LIGHT LH |
| 13 | | 10977611 | | 4 | SCREW |
| 14 | | 11195471 | | 4 | WASHER, LOCK |

(1) Page 04-42
(2) Page 04-46



MidWestTech | Case 885 Tier 3 Grader Parts Catalog | Publication 71114175NA Order the manual at mid-west-tech.com >

## BLADE HYDRAULIC CIRCUIT - SIDE SHIFT AND TILT

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | 1 | REF | | 1 | INSTRUCTION, DISTRIBUTOR rotary Assy |
| 2 | | 70921565 | | 4 | SCREW |
| 3 | | 70912441 | | 4 | WASHER |
| 4 | | 70923717 | | 2 | CONNECTOR, HYD. |
| 5 | | 70921205 | | 2 | O-RING, 10-1, 90 Duro, .755" ID x .097" Thk |
| 6 | | 70900942 | | 1 | PIN, SPLIT (COTTER) |
| 7 | | 70658592 | | 1 | PIN |
| 8 | | 70911115 | | 1 | WASHER |
| 9 | | 70922457 | | 2 | CONNECTOR, HYD. |
| 10 | | 75320161 | | 2 | HOSE, FLEXIBLE |
| 11 | | 75267313 | | 1 | SUPPORT |
| 12 | | 70922457 | | 2 | CONNECTOR, HYD. |
| 13 | | 70921349 | | 2 | O-RING, 8-1, 90 Duro, .644" ID x .087" Thk |
| 14 | 2 | REF | | 1 | INSTRUCTION, VALVE retainer Assy |
| 15 | | 70921409 | | 2 | CONNECTOR, HYD. |
| 16 | | 70921349 | | 2 | O-RING, 8-1, 90 Duro, .644" ID x .087" Thk |
| 17 | | 75255794 | | 2 | HOSE, HYDRAULIC |
| 18 | | 70923905 | | 2 | ELBOW |
| 19 | | 70921349 | | 2 | O-RING, 8-1, 90 Duro, .644" ID x .087" Thk |
| 20 | | 11701721 | | 2 | NUT, M10, Cl 10 |
| 21 | | 11107331 | | 2 | BOLT, Hex, M10 x 55, 10.9 |
| 22 | | 70630753 | | 2 | WASHER |
| 23 | | 75255800 | | 2 | HOSE, HYDRAULIC |
| 24 | | 70929344 | | 1 | CLAMP |
| 25 | | 70677004 | | 2 | WASHER |
| 26 | | 70927541 | | 1 | SCREW |

(1) Page 08-20
(2) Page 08-110



MidWestTech | Case 885 Tier 3 Grader Parts Catalog | Publication 71114175NA Order the manual at mid-west-tech.com >

## CYLINDER - SADDLE AND SADDLE ACTUATING (3 HOLES)

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | 75267015 | | 2 | PLATE |
| 2 | | 8291995 | | 4 | GASKET |
| 3 | | 75248669 | | 2 | COVER |
| 4 | | 70915972 | | 8 | NUT |
| 5 | | 70931523 | | 8 | WASHER |
| 6 | | 8291846 | | 2 | SEAL |
| 7 | | 79106797 | | 2 | BUSHING |
| 8 | 1 | REF | | 2 | INSTRUCTION, CYLINDER Blade Lift |
| 9 | | 70914465 | | 7 | NIPPLE, LUBE |
| 10 | | 70923137 | | 8 | SCREW |
| 11 | | 70914726 | | 8 | WASHER, LOCK |
| 12 | | 70620920 | | 32 | SHIM, .015" Thk |
| 13 | | 75267024 | | 2 | COVER |
| 14 | | 11114631 | | 1 | BOLT, Hex, M12 x 120, 10.9 |
| 15 | 2 | REF | | 1 | INSTRUCTION, CYLINDER saddle |
| 16 | | 10719321 | | 1 | NUT, M12 x 1.75, Cl 10 |
| 17 | | 79106797 | | 4 | BUSHING |
| 18 | | 75248663 | | 2 | RING |
| 19 | | 70924686 | | 2 | O-RING |
| 20 | | 75267009 | | 2 | FORK |
| 21 | | 75327135 | | 4 | BUSHING |
| 22 | | 87359686 | | 4 | PIN |
| 23 | | 87359665 | | 4 | PLATE |
| 24 | | 70910287 | | 12 | WASHER, LOCK |
| 25 | | 70923276 | | 12 | SCREW |
| 26 | | 75256896 | | 2 | SHIM, 0.06mm |
| 27 | | 70928452 | | 8 | WASHER |
| 28 | | 11398137 | | 8 | BOLT, Hex, M24 x 2 x 80, 10.9 |
| 29 | | 75248665 | | 6 | SHIM, 0.003mm |
| 30 | | 75248666 | | 10 | SHIM, 0.005mm |
| 31 | | 75248667 | | 12 | SHIM, 0.20mm |
| 32 | | 75266988 | | 1 | SUPPORT |

(1) Page 08-114
(2) Page 08-122



MidWestTech | Case 885 Tier 3 Grader Parts Catalog | Publication 71114175NA Order the manual at mid-west-tech.com >