PARTS CATALOG

EXCAVATOR

9060B

7-1191 NA

Replaces 7-1190 NA

Issued 01Sept95

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-1191NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

1-1	9060B EXCAVATOR PARTS CATALOG
1-2	LOCATION OF SERIAL AND PRODUCT IDENTIFICATION NUMBERS
1-4	GENERAL INFORMATION
2-02	ENGINE MOUNTS AND ADAPTING PARTS
2-04	RADIATOR MOUNTING AND COOLANT OVERFLOW RESERVOIR, USED ON 6D22-TC ENGINE
2-06	RADIATOR ASSEMBLY, USED WITH 6D22-TC ENGINE
2-08	AIR CLEANER SYSTEM, USED ON 6D22-TC ENGINE
2-10	MUFFLER AND MOUNTING PARTS, USED ON 6D22-TC ENGINE
2-12	FAN, FAN DRIVE AND IDLER PULLEY, 6D22-TC ENGINE
2-14	FAN DRIVE BEARING AND IDLER BEARING LUBE LINES, 6D22-TC
2-16	WATER PUMP ASSEMBLY AND BELTS, 6D22-TC ENGINE
2-18	EXHAUST MANIFOLDS & INTERCOOLR, 6D22-TC ENGINE
2-20	TURBOCHARGER SYSTEM, 6D22-TC ENGINE
2-22	TURBOCHARGER ASSEMBLY, 6D22-TC ENGINE
2-24	OIL FILTER, 6D22-TC ENGINE
2-26	ENGINE OIL COOLER, 6D22-TC ENGINE
2-28	OIL PUMP AND STRAINER, 6D22-TC ENGINE
2-30	OIL PAN, FILLER AND DIPSTICK, 6D22-TC ENGINE
2-32	CYLINDER HEAD, 6D22-TC ENGINE
2-34	VALVE MECHANISM, 6D22-TC ENGINE
2-36	CYLINDER HEAD COVERS AND ENGINE BREATHER, 6D22-TC ENGINE
2-38	WATER PIPE AND THERMOSTAT, 6D22-TC ENGINE
2-40	CAMSHAFT AND TIMING GEAR TRAIN, 6D22-TC ENGINE, CAMSHAFT, TIMING GEAR TRAIN
2-42	CYLINDER BLOCK ASSEMBLY, 6D22-TC ENGINE
2-44	CYLINDER BLOCK ATTACHING PARTS AND ENGINE GASKET KIT, 6D22-TC ENGINE
2-46	CRANKSHAFT, 6D22-TC ENGINE
2-48	FLYWHEEL AND HOUSING, 6D22-TC ENGINE
2-50	PISTONS AND CONNECTING RODS, 6D22-TC ENGINE
2-52	AIR COMPRESSOR SYSTEM, 6D22-TC ENGINE
2-54	AIR COMPRESSOR ASSEMBLY, 6D22-TC ENGINE
2-58	OIL LINES FOR AIR COMPRESSOR AND INJECTION PUMP, 6D22-TC ENGINE
2-60	AIR CONDITIONER COMPRESSOR MOUNTING, USED ON 6D22-TC ENGINE
3-02	FUEL TANK
3-04	FUEL LINES
3-06	THROTTLE AND FUEL SHUTOFF CONTROLS
3-08	INJECTION TUBES
3-10	FUEL RETURN LINES, 6D22-TC ENGINE
3-12	FUEL INJECTION PUMP ASSEMBLY AND MOUNTING, 6D22-TC ENGINE
3-14	FUEL INJECTION NOZZLE, 6D22-TC ENGINE
3-16	FUEL FILTER AND HOSES, 6D22-TC ENGINE
3-18	WATER SEPARATOR
4-02	STARTER AND ALTERNATOR MOUNTING, USED ON 6D22-TC ENGINE
4-04	STARTER ASSEMBLY, USED ON 6D22-TC ENGINE
4-06	ALTERNATOR ASSEMBLY, USED ON 6D22-TC ENGINE
4-07A	ELECTRICAL PARTS IN CAB
4-08	ELECTRICAL PARTS IN CAB
4-09A	ELECTRICAL PARTS OUTSIDE CAB
4-10	ELECTRICAL PARTS OUTSIDE CAB
4-12	ELECTRICAL PARTS OUTSIDE CAB - CONTINUED

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

4-14	ELECTRICAL PARTS OUTSIDE CAB - CONTINUED
4-16	ELECTRICAL PARTS - ABOVE BATTERIES
4-18	INSTRUMENT CLUSTER ASSEMBLY AND COVER
4-20	BATTERIES AND MOUNTING
4-22	WORKING LAMPS
4-24	CAB HEATER AND HOSES
4-26	CAB FAN
4-28	CONTROLLER
4-30	ELECTRIC HORNS
4-32	CAB RADIO
4-34	RH AND LH CONSOLE BOX CONTROL PANEL ASSEMBLIES
4-36	WINDSHIELD WASHER
4-38	WINDSHIELD WIPER
4-40	ENGINE STOP, 6D22-TC ENGINE
5-02	TRACK FRAME AND DRIVE SPROCKET
5-04	TRACK CHAIN AND SHOES, 25 & 26 LINK TRACK CHAIN ASSEMBLIES
5-06	IDLER WHEEL
5-08	TRACK ADJUSTER
5-10	TRACK CARRIER ROLLERS, MANUFACTURED BY SUMITOMO
5-12	TRACK CARRIER ROLLERS, MANUFACTURED BY INTERTRAC
5-14	TRACK ROLLERS, MANUFACTURED BY SUMITOMO
5-16	TRACK ROLLERS, MANUFACTURED BY INTERTRAC
6-02	FINAL DRIVE TRANSMISSION AND TRACK DRIVE MOTOR
6-04	FINAL DRIVE TRANSMISSION
6-08	TRACK DRIVE MOTOR, SHAFT, CYLINDER BLOCK, PISTONS AND BRAKES
6-10	TRACK DRIVE MOTOR - CONTINUED, REAR COVER AND VALVES
6-14	TRACK DRIVE CONTROLS, PEDALS AND LEVERS
6-16	AUXILIARY HYDRAULIC CONTROL, PEDAL AND FLOORMAT
6-18	TRACK DRIVE HYDRAULIC CIRCUIT, SWIVEL TO TRACK DRIVE MOTORS
6-20	COUNTERBALANCE VALVE
8-002	HYDRAULIC RESERVOIR
8-004	RESERVOIR PRESSURIZATION SYSTEM
8-008	HYDRAULIC PUMP AND COUPLING
8-010	RESERVOIR TO PUMP SUCTION LINE
8-012	CONTROL VALVE SUPPLY LINES
8-014	COOLING SYSTEM COMPONENTS, AND HOSE AND TUBE SUPPORTS
8-016	OIL COOLER SUPPLY LINE
8-018	OIL COOLER RECIRCULATING AND RETURN LINES
8-020	BYPASS OIL FILTER AND LINES
8-024	CONTROL COMPONENT MOUNTING AND HOSE SUPPORTS
8-028	CONTROL COMPONENT MOUNTING AND HOSE SUPPORTS, CONTINUED
8-030	CONTROL COMPONENT MOUNTING AND HOSE SUPPORTS, CONTINUED
8-032	CONTROL SIGNAL LINES, PUMP REGULATOR LINES
8-034	PUMP PILOT SUPPLY LINES
8-036	PILOT PRESSURE DISTRIBUTION LINES
8-038	MANUAL CONTROL VALVE PRESSURE AND RETURN LINES
8-040	PEDAL CONTROL VALVE PRESSURE AND RETURN LINES
8-042	BOOM CONTROL LINES, UP, DOWN & SIGNAL LINES
8-045A	BOOM CONTROL LINES, MODELS WITH COUNTERWEIGHT REMOVAL
8-046	BOOM CONTROL LINES, PILOT LINES, MISCELLANEOUS BOOM PILOT LINES
8-048	BOOM CYLINDER LINES , BOOM-UP & BOOM-DOWN

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

8-050	ARM CONTROL LINES - ARM-OUT/ ARM-IN & ARM HOLDING SIGNAL
8-054	ARM CYLINDER SUPPLY LINES - MAIN CONTROL VALVE TO ARM CYLINDER
8-056	ARM CYLINDER LINES - ARM-IN/OUT TUBE TO ARM CYLINDER
8-058	BUCKET CONTROL LINES
8-060	BUCKET CYLINDER SUPPLY LINES
8-062	BUCKET CYLINDER LINES
8-064	SWING CONTRL LINES, SWING-LEFT/ SWING-RIGHT
8-068	FREE SWING CIRCUIT
8-070	SWING MOTOR POWER CIRCUIT
8-072	SWIVEL AND SWING MOTOR DRAIN LINES
8-074	TRAVEL CONTROL LINES
8-080	TRACK DRIVE HYDRAULIC CIRCUIT
8-082	CONTROL VALVE DRAIN LINES
8-084	PRESSURE AND RETURN MANIFOLD DRAIN LINES
8-086	MISCELLANEOUS DRAIN LINES
8-088	HYDRAULIC PUMP, HOUSINGS, MAJOR SUBASSEMBLIES, AND RELATED COMPONENTS
8-090	HYDRAULIC PUMP, GEAR DRIVEN PISTON PUMP
8-092	HYDRAULIC PUMP, SHAFT DRIVEN PISTON PUMP
8-094	HYDRAULIC PUMP, IDLER GEAR ASSEMBLY AND PILOT GEAR PUMP, IDLER GEAR ASSEMBLY, PILOT GEAR PUMP
8-096	HYDRAULIC PUMP, PUMP CONTROLLER
8-098	HYDRAULIC PUMP - THROTTLE VALVE, PROPORTIONAL VALVE, & CONTROL SPRING ASSEMBLY
8-100	HYDRAULIC PUMP, CONTROLLER COVER
8-102	HYDRAULIC PUMP, REGULATOR COVER
8-104	MANUALLY OPERATED CONTROL VALVE
8-106	PEDAL OPERATED REMOTE CONTROL VALVE
8-108	CONTROL VALVE MOUNTING
8-110	CONTROL VALVE, HOUSINGS, MAJOR SUBASSEMBLIES, AND RELATED COMPONENTS
8-112	CONTROL VALVE, PLUGS AND COVERS
8-114	CONTROL VALVE, MAIN PILOT VALVES, FIVE-SPOOL VALVE BANK
8-116	CONTROL VALVE, MAIN PILOT VALVES, FOUR-SPOOL VALVE BANK
8-118	CONTROL VALVE, MISCELLANEOUS VALVES BENEATH MAIN VALVE COVERS
8-120	CONTROL VALVE, MAIN VALVE COVERS AND RELATED COMPONENTS
8-122	CONTROL VALVE, WORKING CIRCUIT RELIEF VALVES
8-124	CONTROL VALVE, ANTI-DRIFT VALVE
8-126	CONTROL VALVE, BASE COVER VALVE ASSEMBLY
8-128	CONTROL VALVE, PILOT VALVE
8-130	CONTROL VALVE, MISCELLANEOUS VALVES
8-132	PILOT CONTROL SOLENOID VALVE
8-134	SOLENOID VALVES, FOR FREE SWING AND AUXILIARY EQUIPMENT
8-136	SOLENOID VALVE
8-138	REDUCING VALVE
8-140	BOOM CYLINDERS, STANDARD MODELS WITHOUT LOAD HOLDING OPTION
8-141A	BOOM CYLINDERS, MODELS WITH LOAD HOLDING OPTION
8-142	ARM CYLINDER
8-144	ARM CYLINDER, STANDARD MODELS WITHOUT LOAD HOLDING OPTION
8-146	BUCKET CYLINDER
8-148	HYDRAULIC SWIVEL

Order the manual at mid-west-tech.com >

PRESSURE AND RETURN MANIFOLD DRAIN LINES

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		152128A1		1	ADAPTER - straight, Includes: Ref. 2
2		154475A1		1	O-RING - adapter
3		162565A1		1	HOSE - 1000 mm (39-3/8 inch) long, cushion valve drain line (cushion valve port \xd2 T\xd3 to pressure and return manifold port \xd2 T\xd3)
4		152128A1		1	ADAPTER - straight, Includes: Ref. 5
5		154475A1		1	O-RING - adapter
6		150913A1		1	ELBOW - 90 degree, Includes: Ref. 7
7		154467A1		1	O-RING - elbow
8		152281A1		1	HOSE - 800 mm (31-1/2 inch) long, solenoid valve drain line (single-spool solenoid valve port \xd2 T\xd3 to pressure and return manifold port \xd2 T8\xd3)
9		152127A1		1	ADAPTER - straight, Includes: Ref. 10
10		154467A1		1	O-RING - adapter
11		153378A1		1	ADAPTER - straight, Includes: Ref. 12
12		154475A1		1	O-RING - adapter
13		161482A1		1	HOSE - 1500 mm (59-1/16 inch) long, swing brake release valve drain line (swing brake release valve port \xd2 T\xd3 to pressure and return manifold port \xd2 T7\xd3)
14		152127A1		1	ADAPTER - straight, Includes: Ref. 15
15		154467A1		1	O-RING - adapter
16		152128A1		1	ADAPTER - straight, Includes: Ref. 17
17		154475A1		1	O-RING - adapter
18		152771A1		1	HOSE - 3000 mm (118-1/8 inch) long, pressure and return manifold drain line (pressure and return manifold port \xd2 T1\xd3 to drain manifold port \xd2 T8\xd3)
19		152128A1		1	ADAPTER - straight, Includes: Ref. 20
20		154475A1		1	O-RING - adapter

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-1191NA Order the manual at mid-west-tech.com >

CONTROL VALVE, ANTI-DRIFT VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		163974A1		1	VALVE ASSEMBLY - anti-drift, Includes: Ref. 1 - 29
1		NSS		1	HOUSING - valve
2		NSS		2	BALL - steel
3		163368A1		5	PLUG - port, Includes: Ref. 4
4		154455A1		1	O-RING - plug
5		163369A1		1	PLUG - port, Includes: Ref. 6
6		154475A1		1	O-RING - plug
7		164470A1		1	PLUG - special, Includes: Ref. 8
8		154467A1		1	O-RING - plug
9		164498A1		1	SPRING - compression
10		164488A1		1	SEAT - spring
11		NSS		1	SPOOL - valve, Includes: Ref. 12 - 17
12		155086A1		1	O-RING - spool
13		154420A1		1	RING - backup
14		154466A1		1	O-RING - spool
15		153955A1		1	RING - backup
16		154470A1		1	O-RING - spool
17		153958A1		1	RING - backup
18		164469A1		1	PLUG - port, Includes: Ref. 19
19		154503A1		1	O-RING - plug
20		163379A1		1	VALVE ASSEMBLY - relief, Includes: Ref. 21
21		155223A1		1	O-RING - valve
22		164486A1		1	PLUNGER - valve
23		164497A1		1	SPRING - compression
24		164487A1		1	SEAT - spring
25		154542A1		1	O-RING - spring seat
26		154012A1		1	RING - backup
27		164503A1		1	COVER - valve assembly
28		164450A1		1	O-RING - passage
29		164501A1		4	BOLT - special

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-1191NA Order the manual at mid-west-tech.com >

SWING MOTOR ASSEMBLY, ANTI-SHOCK VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		163981A1		1	VALVE ASSEMBLY - anti-shock, Includes: Ref. 1 - 27
		NSS		1	HOUSING ASSEMBLY - anti-shock valve, Includes: Ref. 1 & 2
1		NSS		1	HOUSING - anti-shock valve
2		NSS		4	PLUG - port
3		164022A1		1	SPOOL - valve
4		164023A1		1	SEAT - spring
5		164070A1		1	SPRING - compression
6		164024A1		1	PLUG - socket head
7	1, 2	154455A1		1	O-RING - plug
8		164023A1		1	SEAT - spring
9		164070A1		1	SPRING - compression
10		164024A1		1	PLUG - socket head
11	1, 2	154455A1		1	O-RING - plug
12		164020A1		1	SLEEVE - valve
		163982A1		1	VALVE ASSEMBLY - check, Includes: Ref. 13 - 16
13		164017A1		1	SLEEVE - valve
14		164069A1		1	SPRING - compression
15		164018A1		1	PISTON - valve
16		164019A1		1	PLUG - check valve
17		164104A1		1	SPRING - compression
18		164021A1		1	PLUG - port
19	1, 2	154475A1		1	O-RING - plug
		163982A1		1	VALVE ASSEMBLY - check, Includes: Ref. 20 - 23
20		164017A1		1	SLEEVE - valve
21		164069A1		1	SPRING - compression
22		164018A1		1	PISTON - valve
23		164019A1		1	PLUG - check valve
24		164104A1		1	SPRING - compression
25		164021A1		1	PLUG - port
26	1, 2	154475A1		1	O-RING - plug
27		164073A1		4	BOLT - special

(1) Part of swing motor seal kit P/N 164049A1
(2) Part of anti-shock valve seal kit P/N 164052A1

MidWestTech | Case 9060B Excavator Parts Catalog | Publication 7-1191NA Order the manual at mid-west-tech.com >