550G Crawler

Parts Catalog

Bur 7-1223

Order the manual at mid-west-tech.com >

PICTORIAL SECTION INDEX


F951081


F9510813


F951085


F951087

GENERAL 1

ENGINE 2

FUEL SYSTEM 3

ELECTRICAL 4

TRACKS 5

POWER TRAIN 6

BRAKES 7

HYDRAULIC 8

CHASSIS 9

NUMERICAL INDEX 10


F951082


F951084


F951086


F951088

MidWestTech | Case 550G Crawler Parts Catalog | Publication 7-1223 Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

Section 1 of this catalog contains a SN and P.I.N. location guide, alphabetical index, pictorial index of the sections included, and pictorial index(es) for quick location of hoses and tubes (and other system components in some catalogs). An alphabetical index also appears at the beginning of each section. Section 10 is the Numerical Index which lists all part numbers in alpha/numeric order with their page location and reference number.

Illustrations

The arrangement of this parts catalog is for easy identification of parts. All parts are illustrated in "exploded views" in proper relation to each other. Reference numbers used in the illustrations refer to those on the text pages. The text pages list reference number, part number, part description and the quantity required.

Abbreviations

P.I.N. "Product Identification Number"

SN "Serial Number"

NSS "Not Serviced Separately" in the part number column indicates this part is not available for service.

REF "Reference" in the part number column indicates this part has special service information. The page where this information can be found is given in the part description column.

UAR "Use As Required" in the quantity required column indicates the number of parts used is determined by service needs.

Right-Hand and Left-Hand Identification

The reference to right-hand and left-hand in this catalog is identified by the operator standing at the rear of the basic unit (without rear attachment), looking toward the front of the machine (in normal forward travel). For pages covering any machine attachments, right-hand and left-hand are defined by the operator sitting in the position for proper operation of the attachment.

Catalog Revisions and Supplements

Changes to the product may make it necessary to revise or add pages to this catalog. A cover sheet will list all pages released in a revision or supplement. Each new or revised page will have a new issue date. All revised and new pages must be put into the parts catalog as soon as they are received.

Parts Orders

Orders must specify product model, all necessary serial numbers, correct part number, complete description, quantity required, method of shipment, and shipping address.

Text Format Explanation

An assembly may contain service items. The component parts of an assembly or subassembly are indented. The quantity required column lists the number of assemblies required for a completed machine, and the number of components required in a complete assembly or subassembly.

The example below illustrates the use of indents and other text page elements explained on this page.

HYDRAULIC FILTER

REF.	PART NO.	DESCRIPTION	REQ'D.
1	D4356734	FILTER ASSEMBLY - hydraulic oil, P.I.N. 7534840 and after	1
	D61903	HEAD ASSEMBLY - filter	1
2	NSS	HEAD - filter, order D61903 head assembly	1
3	D58199	VALVE - bypass	1
	D43800	KIT - filter element, replaces D35700 element kit	1
4	NSS	ELEMENT - filter, order D43800 element kit	1
5	A27994	O-RING - filter	1
6	D61948	HOUSING -filter	1
7	REF	CANOPY - ROPS, order from Machinery Price List	1
8	843065C1	HOSE - 3353 mm (132 inch) long, reservoir to pump	1
9	113-323	BOLT - hex, 7/16 NC x 1-3/4 inch	2
10	814-8030	BOLT - hex, 8 - 1.25 x 30 mm	4

MidWestTech | Case 550G Crawler Parts Catalog | Publication 7-1223 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Adjuster - track 5-5
Air Cleaner
  Assembly 2-13,2-13B
  Mounting 2-11,2-11B
Air Restriction Indicator 2-15,2-17
Alarm - backup 4-23
Alternator
  Assembly 4-7
  Mounting 4-15
  Pulley 4-7
Anti-Cavitation Check Valve 8-45
Aneroid System 3-9F
Armrests 9-23,9-25

B

Backup Alarm 4-23
Battery - mounting and cables 4-13
Battery Compartment 9-15
Belt
  Alternator 2-5
  Fan - radiator 2-5
  Seat 9-23,9-25
Blade - dozer 9-5
Block - engine cylinder ..... 2-43 - 2-49H
Block Heater 2-45,2-45D,2-45H,2-49,2-49D,2-49H
Brakes
  Brake Valve Assembly - power 7-9
  Hydraulic Lines 7-5
  Parking 7-7
  Pedals - brake 7-3
Breather - transmission 6-7
Brush Guard - ROPS canopy 9-35
Brush Screen - radiator 9-19
Brush Screens - ROPS canopy 9-33,9-35

C

C-Frame - dozer 9-3
Camshaft - engine 2-41,2-41B
Canopy - ROPS 9-33
Carrier Roller Assembly - track 5-9
Chain - track ..... 5-13 - 5-17B
Clutches - transmission 6-13,6-15
Cold Start System 4-27
Connecting Rods - engine ..... 2-55 - 2-57B
Control Valve - equipment ..... 8-35 - 8-37B
Controls
  Brake Pedals and Linkage 7-3
  Engine Throttle 3-3,3-3B
  Equipment Valve and Linkage 8-31,8-33
  Forward, Neutral and Reverse 6-35
  Track Speed 6-35

C

Converter - torque 6-3,6-5
Coolant Bottle - radiator 2-9
Cooling System - transmission 6-31
Counterweight 9-9
Cover - rear, battery access 9-15
Crankshaft - engine 2-51,2-51B
Crossmember - main frame, front 9-11,9-11B
Cushions - seat 9-27,9-29
Cylinder Block - engine ..... 2-43 - 2-49H
Cylinder Head - engine ..... 2-37 - 2-39D
Cylinders - hydraulic
  Angle 8-25
  Lift 8-21
  Tilt 8-23
  Ripper 8-27

D

Decals 9-37,9-39
Dipsticks
  Engine Oil 2-7,2-7B
  Transmission Oil 6-7
Door - rear access 9-15
Dozer
  Blade 9-5
  C-Frame 9-3
  Leveling Beam 9-5
Drawbars 9-9
Drive - final, transmission ..... 6-17 - 6-19B
Drive Shaft 6-3

E

Electrical System ..... 4-9 - 4-27
Engine Components
  Aneroid System 3-9F
  Camshaft 2-41,2-41B
  Connecting Rods ..... 2-55 - 2-57B
  Crankshaft 2-51,2-51B
  Cylinder Block ..... 2-43 - 2-49H
  Cylinder Head Covers 2-37,2-37B
  Dipstick and Fill Tube 2-7,2-7B
  Flywheel and Housing 2-53,2-53B
  Flywheel Mounting 2-53,2-53B
  Front Gear Cover 2-25,2-25B
  Fuel Filter 3-11
  Fuel Injection System ..... 3-9 - 3-9D
  Gasket Kits 2-59,2-59B
  Injection Pump and Drive ..... 3-13 - 3-13D
  Injection Nozzle ..... 3-15 - 3-17B
  Manifolds - intake and exhaust 2-27,2-27B
  Oil Filter and Cooler 2-33,2-33B
  Oil Heater 2-35,2-35B
  Oil Pump and Pan 2-352-35B

MidWestTech | Case 550G Crawler Parts Catalog | Publication 7-1223 Order the manual at mid-west-tech.com >