A TEREX BRAND

Parts Manual

Serial Number Range

TMZ-34/19

from serial number T3400-001

Part No. 72020

Rev C8

April 2017

Order the manual at mid-west-tech.com >

Table of Contents

This manual is updated frequently. If you have a printed manual, you can keep it up to date by downloading new figures from the Genie website at www.genielift.com. For the most up-to-date parts information, visit the Parts Lookup System on the Genie website at www.genielift.com.

How to Read Your Serial Number....3
Parts Stocking List....7
How to Order Parts....8
Service Parts Fax Order Form....9

Electronic Version

Click on any page number to view the figure.

100 Decals and Paint
101.1 Decals and Paint....10

200 Base Components
201.1 Base - ANSI and CSA Models....12
201.1 Base - ANSI and CSA Models (all serial numbers)....14
202.1 Base - CE Models (to SN T3400-0099)....16
202.2 Base - CE Models (from SN T3400-100)....18
203.1 Axle and Hub - ANSI and CSA Models....20
204.1 Axle and Hub - CE Models....22
205.1 Hitch Assembly - ANSI and CSA Models....24
206.1 Hitch Assembly - CE Models....26
207.1 Hitch Options - ANSI and CSA Models....28
207.2 Hitch Options - ANSI and CSA Models....32
208.1 Outrigger Assembly - Manual....36
209.1 Outrigger Assembly - Hydraulic....38
210.1 Hydraulic Brake - ANSI and CSA Models....40
211.1 Mechanical Brake - CE Models....42
212.1 Parking Brake - ANSI and CSA Models....44
213.1 Parking Brake - CE Models....46
214.1 Parking Brake - CE Models....48
214.4 Parking Brake - CE Models....50
215.1 Hydraulic Hoses and Fittings - Outriggers....52
216.1 Hydraulic Hoses and Fittings - Outriggers....54

300 Turntable Components
301.1 Turntable Components....56
301.1 Turntable Components....58
302.1 Turntable - Ground Controls Side....60
303.1 Turntable - Hydraulic Power Unit Side....62
304.1 Ground Controls....64
305.1 Battery Charger - Domestic....66
305.2 Battery Charger - Worldwide....68
306.1 Hydraulic Power Unit....70
307.1 Battery Pack Module....72
308.1 Turntable Covers....74
309.1 Power Cables....76
310.1 Hydraulic Hoses and Fittings....78
311.1 Hydraulic Hoses and Fittings (models With cylinder return line)....80

400 Boom Components
401.1 Secondary Boom - View 1....82
402.1 Secondary Boom - View 2....84
403.1 Primary Boom....86
404.1 Jib Boom....88
405.1 Wire Harness - Taillights, ANSI and CSA Models....90
406.1 Wire Harness - Taillights, CE Models....92

500 Platform Components
501.1 Platform Installation....94
502.1 Platform Taillights - ANSI and CSA Models....98
503.1 Platform Taillights-CE Models....100
503.2 Platform Taillights-CE Models....102
504.1 Platform with Rotator Installation....104
505.1 Platform Rotator....106
506.1 Platform Controls....108

600 Accessories
601.1 Material Lift....110
602.1 Material Lift....112
603.1 Spare Tire Options....114
604.1 Air line to Platform....116
605.1 Operator Warning Light....118
605.2 Operator Warning Light....120
606.1 French Load Sensing Option....122
607.1 Hitch Extension....124
608.1 European Jib Boom Strap....126
609.1 Pipe Cradle....128

Indices
Part Number Index....130
Part Description Index....134


Cross References
Fittings Cross Reference....140

MidWestTech | Terex Genie TMZ-34/19 Boom Lift Parts Manual | Publication 72020 Order the manual at mid-west-tech.com >

207.2 Hitch Options - ANSI and CSA Models (continued)

Item	Part No.	Description	Qty.
38	59753GT	COUPLER CLEVIS,TMZ	1
		from SN 199	

MidWestTech | Terex Genie TMZ-34/19 Boom Lift Parts Manual | Publication 72020 Order the manual at mid-west-tech.com >



MidWestTech | Terex Genie TMZ-34/19 Boom Lift Parts Manual | Publication 72020 Order the manual at mid-west-tech.com >

Fitting Cross References (Continued)

Genie PN	Parker PN	Description
48892	6 C6LO-S	ELBOW,90°,SWIVEL NUT ORFS
48893	6 F5OHAO-S	UNION,STRAIGHT THREAD
48894	6 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48895	DT-370-MSMO-5	VALVE,CHECK
48896	6 JLO-S	UNION,TEE,ORFS
48897	DT-750-MSMS-5	VALVE,CHECK
48898	DT-750-MOMS-5	VALVE,CHECK
48899	DT-620-MOMS-5	VALVE,CHECK
48900	4-6 F5OLO-SW.035	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.035 ORI
48902	16-1 ACE4G-S	ELBOW,90° LONG,FEMALE PIPE TO STRAIGHT THREAD
48903	1 FF-S	NIPPLE,PIPE
48904	4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48905	4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48906	4 R5OLO-S	RUN TEE,STRAIGHT THREAD
48907	4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48908	4 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48909	4 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48910	4 GTX-S W.030	CONNECTOR,FEMALE PIPE TO FLARE TUBE
48911	4-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48912	4-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48913	4-6 F5OLO-SW.030	CONNECTOR,STRAIGHT THREAD TO ORFS, W/.030 ORI
48914	4-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48915	6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48916	6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48917	6 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48918	6 R5OLO-S	RUN TEE,STRAIGHT THREAD
48919	6 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48920	6 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48921	6 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48922	6-6 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48923	6 P5ON-S	PLUG,STRAIGHT THREAD
48925	6 WELO-S	UNION,90° BULKHEAD,ORFS
48926	6-4 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48927	6-4 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48928	6-4 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48929	6-8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48930	6-8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48931	6-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48932	8 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48933	8 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48934	8 FF5OLO-S	CONNECTOR,LONG,STRAIGHT THREAD TO ORFS
48935	8 R5OLO-S	RUN TEE,STRAIGHT THREAD
48936	8 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48937	8 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS

Genie PN	Parker PN	Description
48938	8 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48939	8 S6LO-S	BRANCH TEE,SWIVEL NUT TO ORFS
48940	8 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48941	8-4 TRLO-S	REDUCER,TUBE END TO SWIVEL,ORFS
48942	8-6 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48943	8-6 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48944	8-8 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48945	8 FTX-S	CONNECTOR,MALE PIPE TO FLARE TUBE
48946	8-10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48947	8-12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48948	8-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48949	8-16 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48950	10 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48951	10 CC5OLO-S	ELBOW,90° LONG,STRAIGHT THREAD TO ORFS
48952	10 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48953	10 R5OLO-S	RUN TEE,STRAIGHT THREAD
48954	10 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48955	10 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48956	10-4 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48957	10-6 TRLO-BL-S	REDUCER,TUBE END TO SWIVEL,ORFS
48958	10-12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48959	12 C5OLO-S	ELBOW,90°,STRAIGHT THREAD TO ORFS
48960	12 F5OLO-S	CONNECTOR,STRAIGHT THREAD TO ORFS
48961	12 R5OLO-S	RUN TEE,STRAIGHT THREAD
48962	12 S5OLO-S	BRANCH TEE,STRAIGHT THREAD TO ORFS
48963	12 V5OLO-S	ELBOW,45°,STRAIGHT THREAD TO ORFS
48964	12 R6LO-S	RUN TEE,SWIVEL NUT,ORFS
48965	12 CLO-S	ELBOW,90° MALE PIPE TO ORFS
48966	12 FLO-S	CONNECTOR,MALE PIPE TO ORFS
48967	12 JLO-S	UNION TEE,ORFS
48968	12 WLO-WLNL-S	UNION,BULKHEAD,ORFS
48969	12 WJJLO-WLNL-S	RUN TEE, BULKHEAD,ORFS
48970	12 WELO-WLNL-S	UNION,90° BULKHEAD W/NUT,ORFS

MidWestTech | Terex Genie TMZ-34/19 Boom Lift Parts Manual | Publication 72020 Order the manual at mid-west-tech.com >