NEW HOLLAND CONSTRUCTION

EC 160



OPERATOR'S MANUAL

73183061
December, 1999

NEW HOLLAND

MidWestTech | New Holland EC160 Crawler Excavator Operator's Manual | Publication 731...
Order the manual at mid-west-tech.com >

PART 1 - INTRODUCTION

PREFACE 3

Warnings and symbols 4

DESIGNATED USE 4

Organizational measures 5

Selection and qualification of personnel - basic responsibilities 6

Safety instructions governing specific operational phases

Standard operation 6

Special work in conjunction with utilization of the machine - maintenance and repairs during operation - disposal of parts and consumables 7

Warning of special dangers

Electric energy 8

Gas, dust, steam and smoke 8

Hydraulic and pneumatic equipment 9

Noise 9

Oil, grease and other chemical substances 9

Transporting and towing - recommissioning 9

California, Proposition 65 Warning 9

SAFETY PRECAUTIONS FOR OPERATION 10

General 10

Before Operation 12

MidWestTech | New Holland EC160 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >

PART 2 - OPERATION

Operation - safety instructions 21

DESCRIPTION OF THE MACHINE

Machine layout 25
Superstructure 25
Undercarriage 25
Working equipment 25
Undercarriage 25
Superstructure 25
Hydraulic system 25
Steering 25
Crawler unit brake 25
Electrical system 25
Working equipment 25

SIGNS

Warning and instruction signs 27
Machine number 27
Engine number 27
Component numbers 27

DRIVERS'S CAB

Climbing Up and Down 28
Opening / Closing the Driver's Cab Door 29
Adjustment of driver's seat 30
Adjustment of seat suspension 30
Fore and aft adjustment of seat 30
Adjustment of seat position 30
Adjustment of backrest inclination 30
Adjustment of armrests 30

Adjusting the control console position

Adjusting the Mirrors 32
Opening and Closing the Windscreen 32
Front window - Removing the lower part 33
Opening / closing side window 33
Emergency exit 33
Using the Sunshade 34
Rolling out the Sunshade 34
Rolling up the Sunshade 34
Cab interior lamp - switching on and off 35
Socket outlet in cab 35

MidWestTech | New Holland EC160 Crawler Excavator Operator's Manual | Publication 731... Order the manual at mid-west-tech.com >