CK62
CrawlerExcavator

Service Manual

7-55721


CASE CONSTRUCTION

MidWestTech | Case CK62 Crawler Excavator Service Manual | Publication 7-55721

Order the manual at mid-west-tech.com >

HYDRAULIC SCHEMATIC

1. TRAVEL MOTOR (L)
2. TRAVEL MOTOR (R)
3. SWING MOTOR
4. TRAVEL BRAKE VALVE
5. SWING BRAKE VALVE
6. DIPPER STICK CYLINDER
7. BOOM CYLINDER
8. BUCKET CYLINDER
9. OFFSET CYLINDER
10. DOZER BLADE CYLINDER
11. TRAVEL FLOW SELECTOR
12. HYDRAULIC SWIVEL
13. OPTION ELEMENT
14. DIPPER STICK CONTROL VALVE SECTION
15. INTERMEDIATE PLATE
16. BOOM SECTION
17. TRAVEL SECTION
18. TRAVEL SECTION
19. BOOM SECTION
20. BUCKET SECTION
21. SWING SECTION
22. OFFSET CYLINDER SECTION
23. DOZER BLADE SECTION
24. SPEED CHANGE ELECTROVALVE
25. RETURN FILTER
26. PRESSURE PORT
27. INLET FILTER
28. COOLER
30. PRESSURE LIMITER
31. LEFT-HAND CONTROL LEVER
32. RIGHT-HAND CONTROL LEVER
33. SWING FLOW SELECTOR/OFFSET CYLINDER
34. PILOT CIRCUIT FILTER
35. CHECK VALVE
36. CHECK VALVE



Lep 7-55861

Issued 11-91 Printed in England

MidWestTech | Case CK62 Crawler Excavator Service Manual | Publication 7-55721

Order the manual at mid-west-tech.com >