CASE

PROFESSIONAL PARTNER

PARTS CATALOG
WHEEL LOADER

570MXT

7-7124 NA
Replaces 7-7123 NA

Revised 01May05
Issued 01Jan07

MidWestTech | Case 570MXT Wheel Loader Parts Catalog | Publication 7-7124

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	RADIATOR - MOUNTING (MODELS WITHOUT AIR CONDITIONING, 320877A1 OIL COOLER)
02-02	RADIATOR - MOUNTING (383355A2 OIL COOLER)
02-03	RADIATOR ASSY
02-03A	RADIATOR ASSY (HEAVY DUTY)
02-04	AIR CLEANER - AIR INTAKE PARTS
02-05	AIR CLEANER - PRECLEANER ASSY (MODELS WITHOUT TURBOCHARGED ENGINE)
02-06	AIR CLEANER - PRECLEANER ASSY (MODELS WITH TURBOCHARGED ENGINE)
02-07	MUFFLER - EXHAUST SYSTEM (MODELS WITH TURBOCHARGED ENGINE)
02-08	MUFFLER - EXHAUST SYSTEM (MODELS WITHOUT TURBOCHARGED ENGINE)
02-09	COLD START SYSTEM
02-10	ENGINE - MOUNTING
02-11	WATER PUMP SYSTEM - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-12	FRONT GEAR COVER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-13	MANIFOLDS - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-14	TURBOCHARGER SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02-15	TURBOCHARGER ASSY - 4T-390 EMISSIONS CERTIFIED ENGINE
02-16	OIL FILTER AND COOLER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-17	OIL PUMP AND OIL PAN - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-18	CYLINDER HEAD COVERS - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-19	CYLINDER HEAD AND VALVE MECHANISM - 4-390 EMISSIONS CERTIFIED ENGINE
02-20	CYLINDER HEAD AND VALVE MECHANISM - 4T-390 EMISSIONS CERTIFIED ENGINE
02-21	CAMSHAFT - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-22	CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02-23	CYLINDER BLOCK - 4-390 EMISSIONS CERTIFIED ENGINE
02-24	CRANKSHAFT - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-25	FLYWHEEL AND HOUSING - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-26	PISTONS AND CONNECTING ROD - 4T-390 EMISSIONS CERTIFIED ENGINE
02-27	PISTONS AND CONNECTING ROD - 4-390 EMISSIONS CERTIFIED ENGINE
02-28	GASKET KIT, VALVE GRIND - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-29	GASKET KIT, CYLINDER BLOCK - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
02-30	GASKET KIT, BASIC SERVICE ENGINE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03-01	FUEL LINES, RESERVOIR - FILTER, IN-LINE FUEL
03-02	CONTROLS - THROTTLE, HAND
03-03	CONTROLS - THROTTLE, FOOT
03-04	FUEL INJECTION SYSTEM - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03-05	FUEL FILTER - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03-06	FUEL INJECTION PUMP AND DRIVE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
03-07	FUEL INJECTION NOZZLE - 4-390/4T-390 EMISSIONS CERTIFIED ENGINE
04-01	STARTER
04-02	ALTERNATOR
04-03	STARTER MOUNTING - ALTERNATOR MOUNTING
04-04	HARNESS, ENGINE - MOUNTING AND CONNECTIONS
04-05	BATTERY - CABLES
04-06	BATTERY, DUAL - COLD START
04-07	HARNESS, FRONT CONSOLE AND SWITCHES
04-08	HARNESS, SIDE CONSOLE - MOUNTING AND CONNECTIONS
04-09	HARNESS, SIDE CONSOLE - SWITCHES
04-10	INSTRUMENT PANEL, FRONT - COVERS

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-11	INSTRUMENT PANEL, SIDE - SWITCHES AND COVERS
04-12	INSTRUMENT CLUSTER
04-13	ELECTRICAL - LAMPS, ROPS CANOPY (STANDARD)
04-14	ELECTRICAL - LAMPS, SHORT ROPS CANOPY WITH MINIMAL ROOF
04-15	ELECTRICAL - LAMPS, ROPS CAB
04-16	LAMP ASSY - ROPS CANOPY MODELS
04-17	LAMP ASSY- ROPS CANOPY MODELS
04-18	LAMP ASSY - CAB MODELS
04-19	HORN - ALARM, BACKUP
04-20	BEACON, ROTATING
04-21	ANTENNA, RADIO - HARNESS, RADIO
05-01	STEERING WHEEL - COLUMN
05-02	HYDRAULICS - STEERING (MODELS WITHOUT HUSCO LOADER VALVE)
05-02A	HYDRAULICS - STEERING (MODELS WITH HUSCO LOADER VALVE)
05-03	STEERING COLUMN
05-04	CYLINDER ASSY - STEERING (D138954 / 437320A1 FRONT AXLE) (IF USED)
05-05	AXLE, FRONT (D138954 / 437320A1) - SPINDLES (IF USED)
05-06	AXLE, FRONT (D138954 / 437320A1) - HUB AND BEARINGS (IF USED)
05-07	AXLE, FRONT (429229A1 / 86990837) - MOUNTING (IF USED)
05-08	AXLE, FRONT (429229A1 / 86990837) - HOUSING (IF USED)
05-09	AXLE, FRONT (429229A1 / 86990837) - HOUSING, SWIVEL (IF USED)
05-10	AXLE, FRONT (429229A1 / 86990837) - CYLINDER, STEERING (IF USED)
05-11	AXLE, FRONT (429229A1 / 86990837) - HUB AND BEARINGS (IF USED)
05-12	WHEELS, FRONT - TIRES
06-01	AXLE, FRONT DRIVE - MOUNTING
06-02	AXLE, FRONT DRIVE - HOUSING
06-03	AXLE, FRONT DRIVE - HOUSING, SWIVEL
06-04	AXLE, FRONT DRIVE - CYLINDER, STEERING
06-05	AXLE, FRONT DRIVE - SHAFTS, AXLE
06-06	AXLE, FRONT DRIVE - PLANETARY
06-07	AXLE, FRONT DRIVE - DIFFERENTIAL
06-08	AXLE, FRONT DRIVE - RING AND PINION
06-09	DRIVE SHAFT, FRONT AXLE
06-10	COOLING SYSTEM - TRANSMISSION (WITHOUT AIR CONDITIONING)
06-11	COOLING SYSTEM - TRANSMISSION (WITH AIR CONDITIONING)
06-12	TRANSMISSION - MOUNTING
06-13	TRANSMISSION ASSY - FILTER, OIL
06-14	TRANSMISSION ASSY (2WD) - HOUSING
06-15	TRANSMISSION ASSY (4WD) - HOUSING
06-16	TRANSMISSION ASSY - PUMP, OIL
06-17	TRANSMISSION ASSY - SHIFTER MECHANISM
06-18	TRANSMISSION ASSY - SHAFT, IDLER AND PRIMARY
06-19	TRANSMISSION ASSY - SHAFT, INPUT
06-20	TRANSMISSION ASSY - SHAFT, SECONDARY
06-21	TRANSMISSION ASSY (4WD) - SHAFT, OUTPUT
06-22	TRANSMISSION ASSY (329081A1, A2, A3 OR 329082A1, A2, A3) - VALVE, CONTROL
06-22A	TRANSMISSION ASSY (87456845 OR 87456846) - VALVE, CONTROL
06-22B	TRANSMISSION ASSY (87396486 OR 87396487) - VALVE, CONTROL
06-23	TRANSMISSION ASSY (4WD) - VALVE, SOLENOID
06-24	WHEELS, REAR - TIRES
06-25	AXLE, REAR DRIVE - MOUNTING

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

06-26	AXLE, REAR - DIFFERENTIAL LOCK
06-27	AXLE, REAR DRIVE - HOUSING
06-28	AXLE, REAR DRIVE - DIFFERENTIAL (384952A1 AXLE / 2 SPIDER DIFFERENTIAL)
06-28A	AXLE, REAR DRIVE - DIFFERENTIAL (87422891 AXLE / 4 SPIDER DIFFERENTIAL)
06-29	AXLE, REAR DRIVE - RING AND PINION
06-30	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
06-31	AXLE, REAR DRIVE - PLANETARY
06-32	DRIVE SHAFT, REAR AXLE
07-01	AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
07-02	AXLE, REAR DRIVE - BRAKE, PARKING
07-03	BRAKE - PEDALS
07-04	HYDRAULICS - BRAKE MASTER CYLINDER
07-05	CYLINDER ASSY - BRAKE MASTER
07-06	CONTROLS - BRAKE, PARKING
08-01	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (MODELS WITHOUT HUSCO LOADER VALVE)
08-01A	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/SEPARATE PRIORITY VALVE)
08-01B	HYDRAULICS - PUMP, FILTER AND LOADER VALVE (WITH HUSCO LOADER VALVE W/BUILT-IN PRIORITY VALVE)
08-02	HYDRAULICS - COOLER, RETURN LINES AND FILTER
08-03	HYDRAULICS - CYLINDER, LOADER LIFT
08-04	HYDRAULICS - CYLINDER, LOADER BUCKET
08-05	HYDRAULICS - CYLINDER, LOADER CLAM
08-06	HYDRAULICS - CYLINDER, LOADER CLAM
08-07	HYDRAULICS - RIDE CONTROL (297977A4 SOLENOID VALVE)
08-07A	HYDRAULICS - RIDE CONTROL (86983598 SOLENOID VALVE)
08-07B	HYDRAULICS - RIDE CONTROL (87433240 SOLENOID VALVE)(MODELS WITH HUSCO LOADER VALVE)
08-08	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08-08A	HYDRAULICS - COUPLER, LOADER TOOL QUICK (MODELS WITH HUSCO LOADER VALVE)
08-09	HYDRAULICS - COUPLER, LOADER TOOL QUICK
08-09A	VALVE, COUPLER (87435909) - LOADER TOOL
08-10	HYDRAULICS - HITCH, THREE POINT (FOUR OR FIVE SPOOL VALVE)
08-11	HYDRAULICS - HITCH LOCK VALVE, THREE POINT (FOUR OR FIVE SPOOL VALVE)
08-12	HYDRAULICS - VALVE, LASER CONTROL (MODELS WITH THREE POINT HITCH LOCK VALVE)
08-13	PUMP, EQUIPMENT HYDRAULIC
08-14	VALVE ASSY - LOADER CONTROL, TWO SPOOL
08-15	VALVE ASSY - LOADER CONTROL, THREE SPOOL
08-16	VALVE SECTION - INLET
08-17	VALVE SECTION - LOADER BUCKET
08-18	VALVE SECTION - LOADER LIFT
08-19	VALVE SECTION - OUTLET
08-20	VALVE SECTION - LOADER CLAM
08-21	VALVE ASSY - RELIEF, CIRCUIT
08-21A	VALVE ASSY - LOADER CONTROL, TWO SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE)
08-21B	VALVE ASSY - LOADER CONTROL, THREE SPOOL (HUSCO - USED WITH SEPARATE PRIORITY VALVE)

Order the manual at mid-west-tech.com >

AXLE, FRONT DRIVE - HOUSING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87417387		1	AXLE ASSY, 4WD, Front, Incl. Ref 1 - 18; Also Includes Parts On Figures 06-02 - 06-08; Replaces 427084A1
1		427107A1		1	HOUSING, AXLE
2		D149725		1	BUSHING
3		N14367		2	SEAL
4		D149726		1	BUSHING
5		1966149C2		1	BREATHER
6		A156873		2	PLUG, DRAIN, 22 mm
7		122270A1		2	WASHER, Belleville
8		136990A1		2	SPACER, Used With Ref 9 Bushing; Has Been Replaced By Ref 9A; Used In 427084A1 Axle; If Used
9		100522A1		2	BUSHING, Used With Ref 8 Disc; Has Been Replaced By Ref 9A; Used In 427084A1 Axle; If Used
9A		87400286		2	BUSHING, Replaces Two Piece Bushing (Ref 8, 9) Used On Some Models
10		1966186C1		2	BUSHING
11		311565A1		2	SEAL, Oil, 30 x 44 x 14 mm thk, Triple Lip, Used In 15 mm Deep Counterbore
12		100520A1		2	BALL JOINT, Bushing, Two Piece
13		122268A1		2	WASHER, Belleville
		144454A1		1	SUPPORT ASSY., Differential Carrier; Incl. Ref 14 - 16
14		NSS		1	NOT SERVICED SEPARATELY, Carrier
15		S301065		4	SCREW, Hex Flg, M14 x 75, 12.9, 14 x 75 mm
16		1966136C1		4	BUSHING, Bushing
17		1966138C1		2	DOWEL, Dowel
18		5194169		10	SCREW, Hex Flg, M12 x 33, 12.9, Flange, M12 x 33; 12.9
		B17575		X	FLUID, 89 ml, Black RTV Silicone, Differential Carrier to Axle Housing

MidWestTech | Case 570MXT Wheel Loader Parts Catalog | Publication 7-7124 Order the manual at mid-west-tech.com >

HYDRAULICS - HITCH, THREE POINT (FOUR OR FIVE SPOOL VALVE)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
10A		87561386		1	HOSE ASSY., 855 mm (33-11/16 in); Models With Lock Valve; See Figure 08-11; Used With Ref 14A Gray Cylinder / 3 Pt Hitch Frame on Figure 09-13B
11		405841A1		1	HOSE ASSY., 800 mm (31-1/2 in); Lower Lift Port; To Cylinder Rod End; Used With Ref 14 Tan Cylinder / 3 Pt Hitch Frame on Figure 09-13, 09-13A
11A		87561383		1	HOSE ASSY., 1130 mm (44-1/2 in); Lower Lift Port; To Cylinder Rod End; Used With Ref 14A Gray Cylinder / 3 Pt Hitch Frame on Figure 09-13B
12		218-5281		1-2	ELBOW, 90°, 9/16"-18, 37° x 9/16"-18, O-Ring, 9/16 fl x 7/8 Or; Incl. 13; Two Used With Gray Cylinders
13		237-6010		1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk
14		296715A1		1	CYLINDER ASSY., 76 ID x 207 mm strk; Lift; Tan; See Figure 08-35; Used On Models With Offset 3 Pt Hitch Frame Draft Arms on Figure 09-13, 09-13A
14A		{86982542}		1	76 ID x 207 mm strk; Lift; Gray; See Figure 08-35A; Used On Models With Straight 3 Pt Hitch Frame Draft Arms on Figure 09-13B
15		218-5354		1	FITTING, 9/16"-18, 37° x 7/8"-14, O-Ring, Includes 16; Used with Ref. 11 hose
16		237-6010		1	O-RING, 10-1, 90 Duro, .755" ID x .097" Thk
17		405839A2		1	HOSE ASSY., 1225 mm (487/32 in); Upper Pitch Port; To Cylinder Rod End; Incl. Clamp And Sleeve; Replaces 405839A1
18		410702A1		1	HOSE ASSY., 975 mm; Lower Pitch Port; To Cylinder Closed End
19		218-5058		2	CONNECTOR, HYD., 9/16"-18, 37° x 3/4"-18, O-Ring, 9/16 fl x 3/4 Or; Incl. 20
20		237-6008		1	O-RING, 8-1, 90 Duro, .644" ID x .087" Thk
21		138235A1		1	CYLINDER ASSY., 64 ID x 178 mm strk; Pitch; Tan; See Figure 08-37; Used on Models With Offset 3 Pt Hitch Frame Draft Arms on Figure 09-13, 09-13A
21A		{86981818}		1	64 ID x 178 mm strk; Pitch; Gray; See Figure 08-37A; Used on Models With Straight 3 Pt Hitch Frame Draft Arms on Figure 09-13B

MidWestTech | Case 570MXT Wheel Loader Parts Catalog | Publication 7-7124 Order the manual at mid-west-tech.com >

SEAT PEDESTAL AND SUSPENSION, MECHANICAL SUSPENSION (MILSCO)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		413014A1		1	SEAT ASSY., Mechanical Suspension, Cloth; Includes Seat, Suspension, Pedestal and Weight Adjuster; Incl. Ref 1 - 17, Also Includes Figure 09-35; Without Armrest, See Figure(s) 09-32 For Armrests
		413013A1		1	SEAT ASSY., Mechanical Suspension, Vinyl; Includes Seat, Suspension, Pedestal and Weight Adjuster; Incl. Ref 1 - 17, Also Includes Figure 09-35; Without Armrest, See Figure(s) 09-32 For Armrests
1		307093A1		1	KIT, Suspension, Includes Suspension, Back Angle Adjust, (1) Handle, (8) Screws, (2) Springs, (3) Washers and (1) Rivet
1		307093A1		1	KIT, 307093A1 Kit Also Includes (1) Spacer, (2) Ties, (8) Clips, (12) Nuts, (1) Height Adjust Grip, (1) Back Angle Grip, (1) Rake Grip, (1) Fore/Aft/Swivel Grip, (1) Decal
2		176921A1		1	KIT, Plastic Components, Includes (2) Rollers, (4) Downstops, (2) Roller Guides, (2) Bearings, (1) Bumper, (4) Nuts, (10) Clips, (2) Washers and (1) Grip, For Additional Kit Parts, See Figure(s) 09-35, Ref 9
3		116521A1		1	KIT, Fore/Aft Adjuster Latch, Includes (1) Latch Bar, (1) Bolt, (1) Spacer, (2) Nuts, (1) Spring and (2) Ties, Includes 131-435
		131-435		X	NUT, LOCK, Push, 3/8", 3/8
4		176916A1		1	KIT, Weight Adjuster, Includes Adjusting Knob, (1) Spacer, (2) Roll Pins, (1) Shaft, (1) Spring, (10) Clips, (2) Washers, (1) Grip and (2) Ties
5		176914A1		1	KIT, Suspension Damper, Includes Damper, (2) Spacers, (4) Nuts, (10) Clips, (2) Washers, (1) Grip and (2) Ties
6		116547A1		1	KIT, Height Adjusting Spring, Includes (10) Shroud Retainers, (2) Washers, (2) Springs and (1) Wear Strip, For Additional Kit Parts, See Figure(s) 09-35, Ref 10

Order the manual at mid-west-tech.com >