750K Crawler

Parts Catalog

7-7621NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	ENGINE - MOUNTING
02 -02	FAN - FAN BELT
02 -03	RADIATOR - MOUNTING
02 -03A	RADIATOR ASSY
02 -04	COOLANT RECOVERY SYSTEM
02 -05	AIR CLEANER - MOUNTING
02 -06	AIR CLEANER ASSY
02 -07	MUFFLER - EXHAUST SYSTEM
02 -08	WATER PUMP SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -09	GEAR COVER, FRONT - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -09A	MANIFOLDS - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -10	TURBOCHARGER SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -11	TURBOCHARGER ASSY - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -12	FILTER AND COOLER - OIL, 4T-390 EMISSIONS CERTIFIED ENGINE
02 -13	OIL PUMP, PAN - HEATER, 4T-390 EMISSIONS CERTIFIED ENGINE
02 -13A	BALANCER, ENGINE
02 -14	CYLINDER HEAD - COVER, 4T-390 EMISSIONS CERTIFIED ENGINE
02 -15	CYLINDER HEAD - VALVE MECHANISM, 4T-390 EMISSIONS CERTIFIED ENGINE
02 -16	CAMSHAFT - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -17	CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -18	CRANKSHAFT - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -19	FLYWHEEL AND HOUSING - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -20	PISTONS - CONNECTING RODS, 4T-390 EMISSIONS CERTIFIED ENGINE
02 -21	GASKET KIT, VALVE GRIND - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -22	GASKET KIT, CYLINDER BLOCK - 4T-390 EMISSIONS CERTIFIED ENGINE
02 -23	GASKET KIT, BASIC ENGINE - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03 -02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03 -02A	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03 -03	FUEL TANK
03 -04	FUEL LINES
03 -04A	FUEL FILTER - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -05	FUEL INJECTION SYSTEM - 4T-390 EMISSIONS CERTIFIED ENGINE
03 -06	FUEL FILTER - PUMP, TRANSFER, 4T-390 EMISSIONS CERTIFIED ENGINE
03 -07	FUEL INJECTION - PUMP AND DRIVE, 4T-390 EMISSIONS CERTIFIED ENGINE
03 -08	FUEL INJECTION - NOZZLE, 4T-390 EMISSIONS CERTIFIED ENGINE
04 -01	STARTER
04 -02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04 -03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04 -04	BATTERY, SINGLE - CABLES
04 -05	BATTERY, DUAL - CANOPY, ROPS
04 -06	BATTERY, DUAL - CAB
04 -07	HARNESS, ENGINE - FUSES AND RELAYS
04 -08	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR MOUNTING
04 -09	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04 -10	HARNESS, ENGINE AND REAR WIRE HARNESS
04 -11	HARNESS, MICROCONTROLLER TO PUMP AND MOTORS
04 -12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04 -13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04 -14	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04 -15	HARNESS, CAB - HARNESS, MICROCONTROLLER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -16	CONSOLE, FRONT - CANOPY, ROPS
04 -17	CONSOLE, FRONT - CAB
04 -18	INSTRUMENT CLUSTER
04 -19	HARNESS, LAMP - CANOPY, ROPS
04 -20	HARNESS, LAMP - CAB
04 -21	ALARM, BACKUP - HORN
04 -22	COLD START SYSTEM
04 -23	WIPER, FRONT - CAB
04 -24	WIPER, REAR - CAB
05 -01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05 -02	FRAME, TRACK - COVERS
05 -03	SPROCKET, TRACK
05 -04	TRACK ADJUSTER AND IDLER - MOUNTING
05 -05	TRACK ADJUSTER
05 -06	TRACK IDLER
05 -07	TRACK ROLLER
05 -08	TRACK GUARDS
05 -09	TRACK CHAIN, SEALED
05 -10	TRACK CHAIN, CASE LUBRICATED
05 -11	TRACK CHAIN, EXTENDED LIFE
06 -01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06 -02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06 -03	HYDROSTATICS - MOTOR, DRIVE
06 -03A	DIAGNOSTIC LINES
06 -04	MOUNTING - FINAL DRIVE
06 -05	COVERS - FINAL DRIVE
06 -06	FINAL DRIVE ASSY, DROP HOUSING
06 -07	FINAL DRIVE ASSY, HUB
06 -08	FILTER ASSY
06 -09	CONTROLS, FORWARD AND REVERSE
07 -01	BRAKES - PEDALS AND LINKAGE
07 -02	BRAKE LINES
07 -03	BRAKE, PARKING/LOCKOUT LEVERS
08 -01	RESERVOIR, HYDRAULIC - COVERS
08 -02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08 -03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08 -04	VALVE ASSEMBLY, THERMAL BYPASS
08 -05	HYDRAULICS - LIFT CIRCUIT
08 -06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08 -07	HYDRAULICS - TILT CIRCUIT
08 -08	HYDRAULICS - ANGLE CIRCUIT
08 -09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08 -10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08 -11	CYLINDER ASSY - LIFT
08 -12	CYLINDER ASSY - TILT
08 -13	CYLINDER ASSY - ANGLE
08 -14	CYLINDER ASSY - RIPPER
08 -15	VALVE, CONTROL - MOUNTING
08 -16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08 -17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -18	VALVE, CONTROL
08 -19	VALVE ASSY, RELIEF
08 -20	SECTION ASSEMBLY - LIFT
08 -21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08 -22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08 -23	VALVE ASSY, RELIEF
09 -01	FRAME, LIFT - CYLINDERS, MOUNTING
09 -02	DOZER BLADE - MOUNTING
09 -03	BLADE, DOZER - EDGES, CUTTING
09 -04	SHIELDS, DOZER HYDRAULICS
09 -05	RIPPER
09 -06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09 -07	DRAWBAR - HOOK, TOWING
09 -08	FRAME, MAIN
09 -09	MOUNTING - FRAME, SEAT AND RESERVOIR
09 -10	DOOR, REAR - TANK, HYDRAULIC OIL
09 -11	DOORS, REAR
09 -12	HOOD AND SIDE PANELS
09 -13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09 -14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09 -15	SEAT ASSY, MECHANICAL SUSPENSION
09 -16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09 -17	SEAT ASSY, AIR SUSPENSION
09 -18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09 -19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09 -20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09 -21	CANOPY, ROPS - CONSOLES, SIDE
09 -22	CANOPY, ROPS - GUARD, BRUSH
09 -23	CANOPY, ROPS - SCREENS
09 -24	CAB OR CANOPY - TILT COMPONENTS
09 -25	CAB - FRAME AND MOUNTING
09 -26	CAB - DOORS
09 -27	CAB - LATCH, DOOR
09 -28	CAB - GLASS AND WINDOWS
09 -29	CAB - CONSOLES, SIDE
09 -30	CAB - COVERS, REAR INTERIOR AND SPEAKERS
09 -31	CAB - COVERS, INTERIOR POSTS
09 -32	CAB - COVERS, INTERIOR ROOF AND FLOOR
09 -33	CAB - MIRROR, SUN SHADE, GRAB HANDLE, DOME LAMP, ANTENNA
09 -34	CAB - WASHER, WINDSHIELD (WITH Y-FITTING, REF 8, IF USED)
09 -34A	CAB - WASHER, WINDSHIELD (WITH TEE-FITTING, REF 8, IF USED)
09 -35	CAB - HEATING SYSTEM (AT ENGINE)
09 -36	CAB - HEATER AND CONTROLS
09 -36A	CAB - HEATER AND AIR CONDITIONING
09 -37	CAB - HEATER SHROUD AND FILTERS
09 -38	CAB - AIR CONDITIONING CONTROLS, COMPRESSOR AND DRYER LINES
09 -39	CAB - AIR CONDITIONING CONDENSER
09 -40	CAB - AIR CONDITIONING DUCTS (CAB SERIAL 1001 - 1090)
09 -40A	CAB - AIR CONDITIONING DUCTS (CAB SERIAL 1091 AND AFTER)
09 -41	CAB - AIR CONDITIONING COMPRESSOR
09 -42	CAB - SCREEN, REAR

Order the manual at mid-west-tech.com >

TRACK CHAIN, CASE LUBRICATED

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION EACH MASTER LINK HAS TWO BOLT HOLES
		418603A1		2	CHAIN, TRACK 457 mm (18 inch); Chain; Incl. Shoes; Incl. 407017A1, Ref 1 - 17; 18, 19, 20
		87404008		2	TRACK ASSY, CRAWLER 508 mm (20 inch); Chain; Incl. Shoes; Incl. 407017A1, Ref 1 - 17; 18A, 19, 20
		418606A1		2	TRACK ASSY, CRAWLER 610 mm (24 inch); Chain; Incl. Shoes; Incl. 407017A1, Ref 1 - 17; 18B, 19, 20
		418610A1		2	TRACK ASSY, CRAWLER 711 mm (28 inch); Chain; Incl. Shoes; Incl. 407017A1, Ref 1 - 17; 18C, 19, 20
		407017A1		1	CHAIN, TRACK Incl. Ref 1 - 17; Order 418203A1, Ref 35
1		295178A2		38	LINK Right-Hand
2		295177A2		38	LINK Left-Hand
3		R56515		39	BUSHING 57 mm (2-1/4 in) OD
4		R51131		39	PIN, LARGE
5		R51132		78	SPACER
6		R50830		78	SEAL
7		R50441		39	PLUG
		299237A1		1	KIT Master Link; Right-Hand; Incl. Ref 8 - 12
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Right-Hand; Incl. Ref 8, 9
8		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link
9		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Bushing On Inside Of Regular Track Link
10		295325A1		2	BOLT 5/8 NF x 3-1/4
12		178328A3		1	TAG Installation Instructions
		299234A1		1	KIT Master Link; Left-Hand; Incl. Ref 13 - 17
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Left-Hand; Incl. Ref 13, 14
13		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link; Not Illustrated

Order the manual at mid-west-tech.com >

FINAL DRIVE ASSY, HUB

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		385250A4		2	DRIVE ASSY. Final Drive Assembly; 1575 mm (62 inch) Gauge Long Track (LT) Models; Incl. Ref 1 - 23, 24 - 27; Also Includes Figure 06-06, Ref 1 - 39
		385251A4		2	DRIVE ASSY. Final Drive Assembly; 1778 mm (70 inch) Gauge Wide Track (WT) or Low Ground Pressure (LGP) Models; Incl. Ref 1 - 22, 23A, 24 - 27; Also Includes Figure 06-06, Ref 1 - 39
1		385217A3		1	HUB Hub, Wheel Housing
2		(87028191)		6	Locking, M16 x 60; 10.9
3		(87028192)		6	Locking, M16 x 170; 10.9
4		238-5279		1	O-RING 1/8 x 13 in
5		385220A3		1	GEAR, PLANETARY 65 T; Planetary Ring
		385262A4		1	PLANET CARRIER Incl. Ref 6 - 8
6		NSS		1	NOT SERVICED SEPARATELY Carrier, Hub
7		NSS		3	NOT SERVICED SEPARATELY Pin
8		NSS		3	NOT SERVICED SEPARATELY Pin, Grooved, 3/8 x 1-3/4
9		385231A1		3	WASHER,SPECIAL
10		606-12025		3	BOLT Locking, M12 x 25; 10.9
11		837-5010		3	SPLIT PIN/SAFETY PIN 5 x 10 mm
12		385258A1		198	BEARING, ROLLER
13		385221A2		3	GEAR, PLANETARY 25 T
14		385205A1		1	PLATE, RETAINING Bearing
15		87018613		8	BOLT M12 x 50
16		385271A1		1	BEARING, CUP
17		385270A1		1	BEARING, CONE
18		385211A1		1	BEARING, CUP
19		385210A1		1	BEARING, CONE
20		385223A1		1	SEAL ASSY. Oil
21		385249A2		1	WASHER
22		800-1182		1	RING
23		385213A3		1	FLANGE Long Track (LT) Models
23A		385228A3		1	FLANGE Wide Track (WT) or Low Ground Pressure (LGP) Models
24		238-5156		1	O-RING 3/32 x 4-1/4
25		385214A2		1	PLATE, END Wheel

MidWestTech | Case 750K Crawler Parts Catalog | Publication 7-7621NA Order the manual at mid-west-tech.com >

DOORS, REAR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION LEFT-HAND AND RIGHT-HAND
		414381A3		1	DOOR ASSY. Right-Hand; Incl. Ref 1, 2, 3 - 6A
		414383A3		1	DOOR ASSY. Left-Hand; Incl. Ref 1A, 2A - 6A
1		NSS		1	NOT SERVICED SEPARATELY Door, Right-Hand
1A		NSS		1	NOT SERVICED SEPARATELY Door, Left-Hand
2		414382A3		1	HINGE Door, Right-Hand
2A		414384A3		1	HINGE Door, Left-Hand
3		627-10025		3	SCREW M10 x 25
4		895-15010		4	WASHER 11 x 24 x 2 mm
5		122958A1		2	NUT M10
6		336371A1		2	PIN Nut Retainer
6A		832-10410		1	NUT M10
7		627-8025		6	BOLT M8 x 25
8		895-15008		6	WASHER 9 x 20 x 1,6 mm
9		437171A1		2	GASSTRUT Gas Spring
10		411339A1		2	MOUNTING
11		627-8020		8	BOLT M8 x 20
12		895-11008		8	WASHER 9 x 16 x 1,6 mm
13		F44883		4	CLIP,ELECTRICAL
14		109498A1		4	STUD
15		231-1445		4	NUT, LOCK 5/16
16		86990971		1	HANDLE Hydraulic Pump, Cab/Canopy Tilt; Door, Left-Hand
17		413925A2		2	PLATE Door Latch
18		614-12025		4	CAPSCREW M12 x 25
19		896-11012		4	WASHER 13,5 x 24 x 3 mm
20		N7673		2	BUFFER, RUBBER Bumper
21		495-11034		2	WASHER 11/32 x 11/16 x 1/16
22		231-1445		2	NUT, LOCK 5/16

MidWestTech | Case 750K Crawler Parts Catalog | Publication 7-7621NA Order the manual at mid-west-tech.com >