850K Crawler

Parts Catalog

7-7631NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	ENGINE - MOUNTING
02 -02	FAN - FAN BELT
02 -03	RADIATOR - MOUNTING
02 -03A	RADIATOR ASSY
02 -04	COOLANT RECOVERY SYSTEM
02 -05	AIR CLEANER - MOUNTING
02 -06	AIR CLEANER ASSY
02 -07	MUFFLER - EXHAUST SYSTEM
02 -08	WATER PUMP SYSTEM - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -09	GEAR COVER, FRONT - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -10	TURBOCHARGER SYSTEM - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -11	TURBOCHARGER ASSY - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -12	FILTER AND COOLER - OIL, 6T-590 EMISSIONS CERTIFIED ENGINE
02 -13	OIL PUMP, PAN - HEATER, 6T-590 EMISSIONS CERTIFIED ENGINE
02 -14	CYLINDER HEAD - COVER, 6T-590 EMISSIONS CERTIFIED ENGINE
02 -15	CYLINDER HEAD - VALVE MECHANISM, 6T-590 EMISSIONS CERTIFIED ENGINE
02 -16	CAMSHAFT - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -17	CYLINDER BLOCK - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -18	CRANKSHAFT - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -19	FLYWHEEL AND HOUSING - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -20	PISTONS - CONNECTING RODS, 6T-590 EMISSIONS CERTIFIED ENGINE
02 -21	GASKET KIT, VALVE GRIND - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -22	GASKET KIT, CYLINDER BLOCK - 6T-590 EMISSIONS CERTIFIED ENGINE
02 -23	GASKET KIT, BASIC ENGINE - 6T-590 EMISSIONS CERTIFIED ENGINE
03 -01	CONTROLS, THROTTLE - CABLE AND HAND LEVER
03 -02	CONTROLS, THROTTLE - DECELERATOR PEDAL AND CROSS SHAFT
03 -02A	CONTROLS, THROTTLE - LINKAGE AT ENGINE
03 -03	FUEL TANK
03 -04	FUEL LINES
03 -05	FUEL INJECTION SYSTEM - 6T-590 EMISSIONS CERTIFIED ENGINE
03 -06	FUEL FILTER - PUMP, TRANSFER, 6T-590 EMISSIONS CERTIFIED ENGINE
03 -07	FUEL INJECTION - PUMP AND DRIVE, 6T-590 EMISSIONS CERTIFIED ENGINE
03 -08	FUEL INJECTION - NOZZLE, 6T-590 EMISSIONS CERTIFIED ENGINE
04 -01	STARTER
04 -02	ALTERNATOR ASSY (MODELS WITHOUT AIR CONDITIONING)
04 -03	ALTERNATOR ASSY (MODELS WITH AIR CONDITIONING)
04 -04	BATTERY, SINGLE - CABLES
04 -05	BATTERY, DUAL - CANOPY, ROPS
04 -06	BATTERY, DUAL - CAB
04 -07	HARNESS, ENGINE - FUSES AND RELAYS
04 -08	HARNESS, ENGINE (RIGHT-HAND SIDE) - ALTERNATOR MOUNTING
04 -09	HARNESS, ENGINE (LEFT-HAND SIDE AND REAR)
04 -10	HARNESS, ENGINE AND REAR WIRE HARNESS
04 -11	HARNESS, MICROCONTROLLER TO PUMP AND MOTORS
04 -12	HARNESS, FRONT CONSOLE AND SWITCHES - CANOPY, ROPS
04 -13	HARNESS, FRONT CONSOLE AND SWITCHES - CAB
04 -14	HARNESS, CANOPY - HARNESS, MICROCONTROLLER
04 -15	HARNESS, CAB - HARNESS, MICROCONTROLLER
04 -16	CONSOLE, FRONT - CANOPY, ROPS
04 -17	CONSOLE, FRONT - CAB
04 -18	INSTRUMENT CLUSTER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -19	HARNESS, LAMP - CANOPY, ROPS
04 -20	HARNESS, LAMP - CAB
04 -21	ALARM, BACKUP - HORN
04 -22	COLD START SYSTEM
04 -23	WIPER, FRONT - CAB
04 -24	WIPER, REAR - CAB
05 -01	FRAME, TRACK - ROLLER AND RECOIL HOUSING
05 -02	FRAME, TRACK - COVERS
05 -03	SPROCKET, TRACK
05 -04	TRACK ADJUSTER AND IDLER - MOUNTING
05 -05	TRACK ADJUSTER
05 -06	TRACK IDLER
05 -07	TRACK ROLLER
05 -08	TRACK GUARDS
05 -09	TRACK CHAIN, SEALED
05 -10	TRACK CHAIN, CASE LUBRICATED
05 -11	TRACK CHAIN, EXTENDED LIFE
06 -01	MOUNTING - PUMP, HYDROSTATIC TANDEM AND DRIVESHAFT
06 -02	HYDROSTATICS - PUMP, TANDEM SUPPLY AND RETURN TO FILTER
06 -03	HYDROSTATICS - MOTOR, DRIVE
06 -03A	DIAGNOSTIC LINES
06 -04	MOUNTING - FINAL DRIVE
06 -05	COVERS - FINAL DRIVE
06 -06	FINAL DRIVE ASSY, DROP HOUSING
06 -07	FINAL DRIVE ASSY, HUB
06 -08	FILTER ASSY
06 -09	CONTROLS, FORWARD AND REVERSE
07 -01	BRAKES - PEDALS AND LINKAGE
07 -02	BRAKE LINES
07 -03	BRAKE, PARKING/LOCKOUT LEVERS
08 -01	RESERVOIR, HYDRAULIC - COVERS
08 -02	HYDRAULICS, EQUIPMENT - RESERVOIR TO PUMP AND CONTROL VALVE
08 -03	HYDRAULICS, EQUIPMENT - CONTROL VALVE TO THERMAL BYPASS VALVE AND FILTER
08 -04	VALVE ASSEMBLY, THERMAL BYPASS
08 -05	HYDRAULICS - LIFT CIRCUIT
08 -06	HYDRAULICS - TILT AND ANGLE CIRCUITS
08 -07	HYDRAULICS - TILT CIRCUIT
08 -08	HYDRAULICS - ANGLE CIRCUIT
08 -09	HYDRAULICS - RIPPER, VALVE TO REAR OF TRACTOR
08 -10	HYDRAULICS - RIPPER, REAR OF TRACTOR TO CYLINDERS
08 -11	CYLINDER ASSY - LIFT
08 -12	CYLINDER ASSY - TILT
08 -13	CYLINDER ASSY - ANGLE
08 -14	CYLINDER ASSY - RIPPER
08 -15	VALVE, CONTROL - MOUNTING
08 -16	CONTROLS - LEVER AND LINKAGE, THREE SPOOL VALVE
08 -17	CONTROLS - LEVER AND LINKAGE, FOURTH SPOOL
08 -18	VALVE, CONTROL
08 -19	VALVE ASSY, RELIEF
08 -20	SECTION ASSEMBLY - LIFT

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -21	SECTION ASSEMBLY - TILT, ANGLE, AND AUXILIARY
08 -22	VALVE ASSY, CHECK - VALVE ASSY, ANTI-CAVITATION
08 -23	VALVE ASSY, RELIEF
09 -01	FRAME, LIFT - CYLINDERS, MOUNTING
09 -02	DOZER BLADE - MOUNTING
09 -03	BLADE, DOZER - EDGES, CUTTING
09 -04	SHIELDS, DOZER HYDRAULICS
09 -05	RIPPER
09 -06	COUNTERWEIGHT, FRONT - HOOK, TOWING
09 -07	DRAWBAR - HOOK, TOWING
09 -08	FRAME, MAIN
09 -09	MOUNTING - FRAME, SEAT AND RESERVOIR
09 -10	DOOR, REAR - TANK, HYDRAULIC OIL
09 -11	DOORS, REAR
09 -12	HOOD AND SIDE PANELS
09 -13	GUARD, RADIATOR BRUSH SCREEN - GRILLE, HOOD
09 -14	SEAT ASSY, MECHANICAL SUSPENSION - MOUNTING
09 -15	SEAT ASSY, MECHANICAL SUSPENSION
09 -16	SEAT ASSY, AIR SUSPENSION - MOUNTING
09 -17	SEAT ASSY, AIR SUSPENSION
09 -18	CANOPY, ROPS - FRAME, MOUNTING AND GRAB HANDLES
09 -19	CANOPY, ROPS - HEADLINER, FLOORMAT AND MIRROR
09 -20	CANOPY, ROPS - ARMRESTS, TOOLBOX AND COVERS
09 -21	CANOPY, ROPS - CONSOLES, SIDE
09 -22	CANOPY, ROPS - GUARD, BRUSH
09 -23	CANOPY, ROPS - SCREENS
09 -24	CAB OR CANOPY - TILT COMPONENTS
09 -25	CAB - FRAME AND MOUNTING
09 -26	CAB - DOORS
09 -27	CAB - LATCH, DOOR
09 -28	CAB - GLASS AND WINDOWS
09 -29	CAB - CONSOLES, SIDE
09 -30	CAB - COVERS, REAR INTERIOR AND SPEAKERS
09 -31	CAB - COVERS, INTERIOR POSTS
09 -32	CAB - COVERS, INTERIOR ROOF AND FLOOR
09 -33	CAB - MIRROR, SUN SHADE, GRAB HANDLE, DOME LAMP, ANTENNA
09 -34	CAB - WASHER, WINDSHIELD (WITH Y-FITTING, REF 8, IF USED)
09 -34A	CAB - WASHER, WINDSHIELD (WITH TEE-FITTING, REF 8, IF USED)
09 -35	CAB - HEATING SYSTEM (AT ENGINE)
09 -36	CAB - HEATER AND CONTROLS
09 -36A	CAB - HEATER AND AIR CONDITIONING
09 -37	CAB - HEATER SHROUD AND FILTERS
09 -38	CAB - AIR CONDITIONING CONTROLS, COMPRESSOR AND DRYER LINES
09 -39	CAB - AIR CONDITIONING CONDENSER
09 -40	CAB - AIR CONDITIONING DUCTS (CAB SERIAL 1001 - 1090)
09 -40A	CAB - AIR CONDITIONING DUCTS (CAB SERIAL 1091 AND AFTER)
09 -41	CAB - AIR CONDITIONING COMPRESSOR
09 -42	CAB - SCREEN, REAR
09 -43	DECALS - ENGLISH
09 -44	DECALS - ENGLISH
09 -45	DECALS - ENGLISH

Order the manual at mid-west-tech.com >

TRACK CHAIN, EXTENDED LIFE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION EACH MASTER LINK HAS TWO BOLT HOLES
		418616A1		2	TRACK ASSY, CRAWLER 457 mm (18 inch); Chain; Incl. Shoes; Incl. 407021A1, Ref 1 - 18; 19, 20, 21
		418619A1		2	TRACK ASSY, CRAWLER 508 mm (20 inch); Chain; Incl. Shoes; Incl. 407021A1, Ref 1 - 18; 19A, 20, 21
		418623A1		2	TRACK ASSY, CRAWLER 610 mm (24 inch); Chain; Incl. Shoes; Incl. 407021A1, Ref 1 - 18; 19B, 20, 21
		418625A1		2	TRACK ASSY, CRAWLER 711 mm (28 inch); Chain; Incl. Shoes; Incl. 407021A1, Ref 1 - 18; 19C, 20, 21
		407021A1		1	CHAIN, TRACK Incl. Ref 1 - 18; Order 418500A1, Ref 30
1		295178A2		39	LINK Right-Hand
2		295177A2		39	LINK Left-Hand
3		114402A1		40	BUSHING 54mm (2-1/8 in) OD
4		323875A1		40	BUSHING
5		R51131		40	PIN, LARGE
6		R51132		80	SPACER
7		R50830		80	SEAL
8		R50441		40	PLUG
		299237A1		1	KIT Master Link; Right-Hand; Incl. Ref 9 - 13
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Right-Hand; Incl. Ref 9, 10
9		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link
10		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Bushing On Inside Of Regular Track Link
11		295325A1		2	BOLT 5/8 NF x 3-1/4
13		178328A3		1	TAG Installation Instructions
		299234A1		1	KIT Master Link; Left-Hand; Incl. Ref 14 - 18
		NSS		1	NOT SERVICED SEPARATELY Link Assy; Master; Left-Hand; Incl. Ref 14, 15
14		NSS		1	NOT SERVICED SEPARATELY Link; Fits Over Track Pin On Outside Of Regular Track Link; Not Illustrated

Order the manual at mid-west-tech.com >

BLADE, DOZER - EDGES, CUTTING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION 2642 mm (104 inch) DOZER BLADE
		430566A2		1	BLADE, DOZER 2642 mm (104 inch); Incl. Ref 1 - 6
1		NSS		1	NOT SERVICED SEPARATELY Blade
2		R42490		2	END 442 mm (17-7/16 in); Cutting Edge
3		115631A1		2	EDGE 867 mm (34-1/8 in); Center Cutting Edge; 6 Bolt Holes
4		R56474		22	SCREW 3/4 x 2-1/2; 8
5		92-11075		22	WASHER 3/4
6		29-1012		22	NUT 3/4; 8
		REF			INSTRUCTION 2794 mm (110 inch) DOZER BLADE
		430567A2		1	BLADE, DOZER 2794 mm (110 inch); Incl. Ref 7 - 12
7		NSS		1	NOT SERVICED SEPARATELY Blade
8		R42490		2	END 442 mm (17-7/16 in); Cutting Edge
9		430157A1		1	EDGE, CUTTING 1908 mm (75-1/8 in); Center Cutting Edge; 13 Bolt Holes
10		R56474		23	SCREW 3/4 x 2-1/2; 8
11		92-11075		23	WASHER 3/4
12		29-1012		23	NUT 3/4; 8
		REF			INSTRUCTION 3048 mm (120 inch) DOZER BLADE
		430569A2		1	BLADE, DOZER 3048 mm (120 in); Incl. Ref 13 - 18
13		NSS		1	NOT SERVICED SEPARATELY Blade
14		R42490		2	END 442 mm (17-7/16 in); Cutting Edge
15		327539A1		1	EDGE 2158 mm (85 in); Center Cutting Edge; 14 Bolt Holes
16		R56474		24	SCREW 3/4 x 2-1/2; 8
17		92-11075		24	WASHER 3/4
18		29-1012		24	NUT 3/4; 8
		REF			INSTRUCTION 3150 mm (124 inch) DOZER BLADE
		430570A2		1	BLADE, DOZER 3150 mm (124 in); Incl. Ref 19 - 24
19		NSS		1	NOT SERVICED SEPARATELY Blade
20		R42490		2	END 442 mm (17-7/16 in); Cutting Edge
21		126519A1		1	EDGE 2258 mm (88-5/16 in); Center Cutting Edge; 15 Bolt Holes
22		R56474		25	SCREW 3/4 x 2-1/2; 8
23		92-11075		25	WASHER 3/4
24		29-1012		25	NUT 3/4; 8

MidWestTech | Case 850K Crawler Parts Catalog | Publication 7-7631NA Order the manual at mid-west-tech.com >

DECALS - ENGLISH

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		87415248			KIT Decal, English; Incl. Figure 09-43, Ref 1 - 11, Figure 09-44, Ref 1, 3, 4, 6 - 14, Figure 09-45, Ref 1 - 13
1		87422188		1	DECAL Throttle; Replaces 87404200
2		321-4614		1	DECAL Do Not Operate Tag
3		379422A1		1	DECAL Master Disconnect Switch
4		87412595		1	DECAL Ignition Switch
5		87415509		1	DECAL Fuse/Relays, In Cab/Canopy Assembly
6		87412477		1	DECAL Fuse/Relays
9		87418216		1	DECAL Canopy/Cab Tilting Procedure; Replaces 87400044
10		87422184		1	DECAL Forward/Neutral/Reverse; Replaces 87403196
11		87422186		1	DECAL Reverse Controller; Replaces 87403197
12		87403199		1	DECAL Diagnostics
13		383972A1		1	DECAL Warning, Do Not Modify or Repair ROPS or FOPS In Any Manner
14		383971A1		1	DECAL Warning, Engine Decelerator Pedal
15		449842A1		2	DECAL Reflector, Rectangular; Not Illustrated

MidWestTech | Case 850K Crawler Parts Catalog | Publication 7-7631NA Order the manual at mid-west-tech.com >