85XT
Skid Steer

ASN JAF0352234(NA)
JAF0352715(EU)

Parts Catalog

7-8220NA

CASE
CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	RADIATOR - COOLANT RECOVERY SYSTEM
02 -02	FAN - FAN BELT
02 -03	EXHAUST SYSTEM
02 -04	AIR CLEANER - ENGINE
02 -05	COLD START - THERMOSTART
02 -06	ENGINE - MOUNTING
02 -07	WATER PUMP SYSTEM
02 -08	FRONT GEAR COVER
02 -09	MANIFOLDS - EXHAUST AND INTAKE
02 -10	FILTER AND COOLER - OIL
02 -11	OIL PUMP, PAN - HEATER
02 -12	CYLINDER HEAD COVER - THERMOSTAT AND HOUSING
02 -13	CYLINDER HEAD - VALVE MECHANISM
02 -14	CAMSHAFT
02 -15	CYLINDER BLOCK
02 -16	CRANKSHAFT
02 -17	FLYWHEEL AND HOUSING
02 -18	PISTONS - CONNECTING RODS
02 -19	GASKET KIT, VALVE GRIND
02 -20	GASKET KIT, CYLINDER BLOCK
02 -21	GASKET KIT, BASIC SERVICE ENGINE
03 -01	FUEL LINES
03 -02	CONTROLS - THROTTLE (NORTH AMERICA)
03 -03	CONTROLS - THROTTLE (EUROPE)
03 -04	FUEL INJECTION SYSTEM
03 -05	FUEL INJECTION - PUMP AND DRIVE
03 -06	FUEL INJECTION - NOZZLE
04 -01	STARTER ASSY
04 -02	ALTERNATOR ASSY
04 -03	MOUNTING - STARTER AND ALTERNATOR
04 -04	BATTERY - CABLES
04 -05	DISCONNECT SWITCH
04 -06	HARNESS, FRONT - CHASSIS
04 -07	HARNESS, REAR - CHASSIS
04 -08	HARNESS - CHASSIS OPTIONS
04 -09	SWITCH MOUNTING - CHASSIS OPTIONS
04 -10	HARNESS - TURN SIGNAL, FLASHER AND LICENSE PLATE LAMP
04 -11	SWITCH MOUNTING - LOCK, LOADER CONTROL
04 -12	HARNESS - CAB
04 -13	HARNESS - SEAT BAR
04 -14	K HARNESS - DOOR, FRONT
04 -15	HARNESS, FRONT - AUXILIARY
04 -16	WIPER, WINDSHIELD
04 -17	CONTROLS, RIGHT HAND - HANDLE
04 -18	CONTROLS, LEFT HAND - HANDLE
04 -19	LAMP ASSY - BEACON, ROTATING
04 -20	HORN - MOUNTING
04 -21	MOUNTING - LAMP, LICENSE PLATE
04 -22	LAMP ASSY - LICENSE PLATE
04 -23	MOUNTING - LAMP ASSY, COMBINATION
04 -24	MOUNTING - LAMP ASSY, COMBINATION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -25	MOUNTING - LAMPS, ROAD
04 -26	ENGINE - SHUTDOWN, AUTOMATIC
06 -01	HYDROSTATICS - PUMP, SUPPLY AND RETURN
06 -02	HYDROSTATICS - CASE DRAIN
06 -03	HYDROSTATICS - AUXILIARY VALVE PLUMBING
06 -04	HYDROSTATICS - PUMP AND DRIVE MOTORS
06 -05	FILTER ASSY - MOUNTING
06 -06	PUMP, TANDEM - MOUNTING
06 -07	PUMP, TANDEM
06 -08	PUMP, TANDEM
06 -09	PUMP, TANDEM
06 -10	PUMP, TANDEM
06 -11	PUMP, GEAR
06 -12	MOTOR ASSY
06 -13	DRIVE LINE
06 -14	AXLE ASSY
06 -15	WHEELS
06 -16	TRACK - STEEL (NORTH AMERICA)
06 -16A	WHEELS - TRACK, RUBBER
07 -01	BRAKE
07 -02	HYDRAULIC CIRCUIT, BRAKE
07 -03	BRAKE RELEASE - MANUAL
07 -04	PUMP - BRAKE
08 -01	HYDRAULICS - LOADER LIFT
08 -02	HYDRAULICS - LOADER BUCKET
08 -02A	HYDRAULICS - SELF-LEVELING
08 -03	HYDRAULICS - AUXILIARY SYSTEM
08 -04	HYDRAULICS - RIDE CONTROL
08 -05	HYDRAULICS - COUPLER SYSTEM
08 -06	HYDRAULICS - COUPLER SYSTEM
08 -07	VALVE, CONTROL - MOUNTING
08 -08	VALVE ASSY, CONTROL - LOADER
08 -09	VALVE ASSY, CONTROL - SPOOLS AND DETENTS
08 -09A	VALVE ASSY, CONTROL - SELF-LEVELING, DUAL
08 -09B	VALVE ASSY, CONTROL - SPOOLS AND DETENTS, SELF-LEVELING, DUAL
08 -10	AUXILIARY VALVE AND MOUNTING
08 -11	CYLINDER - LOADER LIFT
08 -12	CYLINDER - LOADER BUCKET
08 -13	VALVE, SOLENOID
08 -14	COUPLERS - HYDRAULIC
08 -15	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -16	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -17	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -18	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -19	HYDRAULICS, ATTACHMENT - HIGH FLOW, GEAR
08 -20	VALVE ASSY, CONTROL - HIGH FLOW
08 -21	HYDRAULIC SYSTEM - BACKHOE SUPPLY AND RETURN (NORTH AMERICA)
08 -22	HYDRAULIC SYSTEM - BACKHOE SWING CYLINDER (NORTH AMERICA)
08 -23	HYDRAULIC SYSTEM - BACKHOE STABILIZER CYLINDER (NORTH AMERICA)
08 -24	HYDRAULIC SYSTEM - BACKHOE BOOM CYLINDER (NORTH AMERICA)
08 -25	HYDRAULIC SYSTEM - BACKHOE DIPPER CYLINDER (NORTH AMERICA)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -26	HYDRAULIC SYSTEM - BACKHOE BUCKET CYLINDER (NORTH AMERICA)
08 -27	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -28	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -29	VALVE, CONTROL - BACKHOE (NORTH AMERICA)
08 -30	CYLINDER ASSY - BACKHOE SWING (NORTH AMERICA)
08 -31	CYLINDER ASSY - BACKHOE BOOM (NORTH AMERICA)
08 -32	CYLINDER ASSY - BACKHOE DIPPER (NORTH AMERICA)
08 -33	CYLINDER ASSY - BACKHOE BUCKET (NORTH AMERICA)
08 -34	CYLINDER ASSY - STABILIZER, FOLD DOWN (NORTH AMERICA)
08 -35	CYLINDER ASSY - STABILIZER, VERTICAL (NORTH AMERICA)
09 -01	FRAME - LOADER LIFT
09 -02	SUPPORT - LOADER FRAME
09 -03	ARM, LOADER H-FRAME
09 -04	COUPLER, MECHANICAL
09 -05	COUPLER, HYDRAULIC
09 -06	BUCKETS, LOADER - 1860 MM (73 IN) WIDE BUCKET
09 -07	BUCKETS, LOADER - 2083 MM (82 IN) WIDE BUCKET
09 -08	PALLET FORK
09 -09	CHASSIS
09 -10	PLATES, FLOOR
09 -11	CONSOLE, CONTROL
09 -12	CONTROLS - LOADER AND GROUND DRIVE
09 -13	LINKAGE - LOADER AND GROUND DRIVE
09 -14	LINKAGE - AUXILIARY SYSTEM
09 -15	HOOD - WITHOUT SOUNDPROOFING (NORTH AMERICA)
09 -16	HOOD - WITH SOUNDPROOFING (EUROPE)
09 -17	DOOR, REAR (NORTH AMERICA)
09 -18	DOOR, REAR - WITH SOUNDPROOFING (EUROPE)
09 -19	SOUNDPROOFING - PANELS (EUROPE)
09 -20	COUNTERWEIGHTS - DRAWBAR
09 -21	SEAT, MOUNTING - NON-SUSPENSION
09 -22	SEAT, MOUNTING - SUSPENSION
09 -23	SEAT - SUSPENSION
09 -24	SEAT - SUSPENSION
09 -25	SEAT - SUSPENSION
09 -26	CANOPY, ROPS - FRAME AND SEAT BAR
09 -27	CANOPY, ROPS - FRAME AND SEAT BAR
09 -28	CANOPY, ROPS - LIFT HOOK
09 -29	CANOPY, ROPS - REAR LATCH AND PIVOT
09 -30	CANOPY, ROPS - HEAT SHIELD
09 -31	CANOPY, ROPS - HEADLINER
09 -32	DOOR, FRONT - WINDSHIELD
09 -32A	DOOR, FRONT - WINDSHIELD
09 -33	DOOR, FRONT - MOUNTING, FRAME
09 -34	DOOR, FRONT - LATCH
09 -35	WINDOWS - SIDE AND TOP
09 -35A	MOUNTING MIRROR, REAR VIEW
09 -36	HEATING SYSTEM - HEATER, FLOOR
09 -37	HEATING SYSTEM - HEATER, DELUXE
09 -37A	AIR CONDITIONING SYSTEM
09 -37B	AIR CONDITIONING SYSTEM

Order the manual at mid-west-tech.com >

FUEL INJECTION - NOZZLE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					4-390 EMISSIONS CERTIFIED ENGINE
		JR930573		4	REMAN-NOZZLE,INJECT
					Remanufactured
					N.A. Only
		JC930573		4	CORE-NOZZLE, INJECT
1		J930573		4	INJECTOR ASSY.
					Incl. 1 - 10
2		J937142		1	SEAL
3		J906659		1	SEAL 2,5 mm
4		NSS		1	NOT SERVICED SEPARAT Body
5		NSS		1	NOT SERVICED SEPARAT Spring
6		NSS		1	NOT SERVICED SEPARAT Seat
7		NSS		1	NOT SERVICED SEPARAT Stop
8		NSS		1	NOT SERVICED SEPARAT Tip, Tooth
9		NSS		1	NOT SERVICED SEPARAT Nut
10		1806233C1		X	SHIM 1,00 mm
10		1806234C1		X	SHIM 1,04 mm
10		1806235C1		X	SHIM 1,08 mm
10		1806236C1		X	SHIM 1,10 mm
10		1806237C1		X	SHIM 1,14 mm
10		1806238C1		X	SHIM 1,18 mm
10		1806239C1		X	SHIM 1,20 mm
10		1806240C1		X	SHIM 1,24 mm
10		1806241C1		X	SHIM 1,28 mm
10		1806242C1		X	SHIM 1,30 mm
10		1806243C1		X	SHIM 1,34 mm
10		1806244C1		X	SHIM 1,38 mm
10		1806245C1		X	SHIM 1,40 mm
10		1806246C1		X	SHIM 1,44 mm
10		1806247C1		X	SHIM 1,48 mm
10		1806248C1		X	SHIM 1,50 mm
10		1806249C1		X	SHIM 1,54 mm
10		1806250C1		X	SHIM 1,58 mm
10		1806251C1		X	SHIM 1,60 mm
10		1806252C1		X	SHIM 1,64 mm
10		1806253C1		X	SHIM 1,68 mm

MidWestTech | Case 85XT Skid Steer Parts Catalog | Publication 7-8220NA

Order the manual at mid-west-tech.com >

SWITCH MOUNTING - CHASSIS OPTIONS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		400180A1		1	HARNESS Chassis Options Not Illustrated See Figure 04 -08
2		234311A2		1	PLATE ASSY. Switch Mounting Standard
2A		294081A1		1	PLATE Switch Mounting Models With Deluxe Heater Models With Air Conditioning
4		840-1516		1	SCREW M5 x 16; 4,8
4		223837A1		2	SWITCH Rocker Auxiliary Power If Equipped
5		122736A1		1	SWITCH Rocker Flasher If Equipped
6		133714A1		1	SWITCH Rocker Beacon Light If Equipped
7		254505A1		1	SWITCH,IGNITION Models With Hydraulic Coupler If Used
8		223-154		1	CONNECTOR Used With REF 7
9		631019C1		1	CONNECTOR,TERMINAL Used With REF 7
10		111282C1		1	BUTTON Blower Switch
11		109311H		1	NUT 7/16 NF
12		168822C2		1	SWITCH Blower
13		373331A1		1	SWITCH Rocker Loader Lock Europe Only
14		373296A1			HARNESS Rocker Loader Lock

MidWestTech | Case 85XT Skid Steer Parts Catalog | Publication 7-8220NA Order the manual at mid-west-tech.com >

PUMP, TANDEM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
					CYLINDER BLOCK AND PISTON
		433902A1		1	PUMP
					See Figure 06 -06
					Incl. 06 -07 - 06 -10
1		291125A1		2	COVER
					Rod End
2		373328A1		4	GASKET
3		218-5209		4	PLUG 9/16 Or
					Incl. 4
4		237-6006		1	O-RING 15/32 ID x 5/64
5		233029A1		2	NUT
6		233022A1		20	SCREW
		259495A1		2	SET OF PARTS
					Incl. 7 - 9
7		NSS		1	NOT SERVICED SEPARAT Piston
		233042A1		1	PACKAGE
					Incl. 8, 9
8		238-5139		2	O-RING 2-3/16 ID x 3/32
9		291278A1		2	O-RING
10		233047A1		2	COVER
					Plain End
11		373305A1		2	COVER
					Incl. 373327A1
12		373327A1		2	GASKET
13		324791A1		12	SCREW
14		373330A1		2	PLATE
15		291114A1		2	BEARING, NEEDLE
					Incl. 17
16		233012A1		1	BEARING, NEEDLE
		233039A1		2	PACKAGE
					Incl. 17 - 26
17		NSS		1	NOT SERVICED SEPARAT Block
18		291277A1		9	PISTON
19		291276A1		1	PLATE, LARGE
20		291275A1		1	BUSHING,LARGE
21		291274A1		3	SPLIT PIN/SAFETY PIN

MidWestTech | Case 85XT Skid Steer Parts Catalog | Publication 7-8220NA Order the manual at mid-west-tech.com >