CASE

PROFESSIONAL PARTNER

PARTS CATALOG

LONG REACH EXCAVATOR

CX240 LR

7-8941 NA

Replaces 7-8940 NA

Revised 01Aug06
Issued 01Aug02

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-01	ENGINE MOUNTING
02-02	AIR CLEANER
02-03	EXHAUST SYSTEM - MUFFLER
02-04	RADIATOR AND CONNECTIONS
02-05	COOLANT RECOVERY SYSTEM
02-06	RADIATOR ASSY
02-07	WATER PUMP SYSTEM
02-08	FRONT GEAR COVER
02-09	MANIFOLDS - EXHAUST AND INTAKE
02-10	TURBOCHARGER SYSTEM
02-11	TURBOCHARGER
02-12	FILTER AND COOLER - OIL
02-13	OIL PUMP, PAN - HEATER
02-14	CYLINDER HEAD - MOUNTING, ALTERNATOR
02-15	CYLINDER HEAD - VALVE MECHANISM
02-16	CAMSHAFT
02-17	CYLINDER BLOCK
02-18	CRANKSHAFT
02-19	FLYWHEEL - HOUSING
02-20	PISTONS - CONNECTING RODS
02-21	GASKET KIT, VALVE GRIND
02-22	GASKET KIT, CYLINDER BLOCK
02-23	GASKET KIT, BASIC ENGINE
03-01	FUEL TANK
03-02	FUEL LINES (P.I.N. DAC 0721099 - DAC212384)
03-02A	FUEL LINES (P.I.N. DAC212385 -)
03-02B	WATER SEPARATOR ASSY (P.I.N. DAC 0721099 - DAC212384)
03-02C	FUEL FILTER (P.I.N. DAC212385 -)
03-03	FUEL INJECTION SYSTEM
03-04	FUEL FILTER
03-05	PUMP, FUEL TRANSFER
03-06	FUEL INJECTION PUMP - GEAR AND MOUNTING BRACKETS
03-07	FUEL LINES
03-08	FUEL INJECTION - NOZZLE
03-09	FUEL FILLING
04-01	STARTER ASSY
04-02	ALTERNATOR ASSY
04-03	MODULE, ENGINE CONTROL
04-04	HARNESS - ELECTRONIC IGNITION CONTROL MODULE
04-05	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04-05A	HARNESS, MAIN - CLAMPS AND RETAINERS
04-05B	HARNESS, MAIN - RELAY PANEL
04-06	ELECTRICAL - CAB
04-07	CONVERTER
04-08	CAB ELECTRICAL - WIPER, WINDSHIELD
04-09	HORN
04-10	LAMPS
04-11	CONTROLLER
04-12	BATTERY - CABLES
04-13	MONITOR ASSY - INSTRUMENT PANEL
04-14	WINDSHIELD WASHER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-15	RADIO
05-01	UNDERCARRIAGE
05-02	GUARD, TRANSMISSION
05-03	UNDERCARRIAGE COVER, LOWER
05-04	TRACK CHAINS, 600 MM (23-5/8 IN) - P.I.N. DAC0724099 - DAC0724274
05-04A	TRACK CHAINS, 600 MM (23-5/8 IN) - P.I.N. DAC0724275 -
05-04B	TRACK CHAINS, 700 MM (27-5/8 IN) - P.I.N. DAC0724099 - DAC0724274
05-04C	TRACK CHAINS, 700 MM (27-5/8 IN) - P.I.N. DAC0724275 -
05-04D	TRACK CHAINS, 800 MM (31-1/2 IN) - P.I.N. DAC0724099 - DAC0724274
05-04E	TRACK CHAINS, 800 MM (31-1/2 IN) - P.I.N. DAC0724275 -
05-05	TRACK - IDLER
05-06	TRACK - ADJUSTER
05-07	TRACK - ROLLER, UPPER; PIN DAC0724099 - DAC0724170
05-07A	TRACK - ROLLER, UPPER; PIN DAC0724171 -
05-08	TRACK - ROLLER, LOWER
06-01	TRACK DRIVE ASSY
06-02	MOTOR ASSY - GEAR ASSY, REDUCTION
06-02A	MOTOR ASSY - GEAR ASSY, REDUCTION
06-03	MOTOR ASSY - TRAVEL, INLET AND OUTLET
06-03A	MOTOR ASSY - TRAVEL, INLET AND OUTLET
06-04	MOTOR ASSY - TRACK DRIVE
06-04A	MOTOR ASSY - TRACK DRIVE
06-05	HYDRAULICS - TRACK DRIVE
06-06	HYDRAULICS - TRAVEL
06-07	HYDRAULICS - TRAVEL CONTROL, SINGLE PEDAL
08-01	HYDRAULIC RESERVOIR
08-02	PUMP ASSY, HYDRAULIC - COUPLING
08-03	HYDRAULICS - PUMP SUCTION LINE
08-04	HYDRAULICS - CONTROL VALVE SUPPLY
08-05	HYDRAULICS - RESERVOIR RETURN
08-06	HYDRAULICS - BYPASS FILTER
08-07	HYDRAULICS - DRAIN LINE
08-09	HYDRAULICS - SWING
08-10	HYDRAULICS - BOOM
08-11	HYDRAULICS - ARM AND BUCKET
08-12	HYDRAULICS - ARM CYLINDER LINE
08-13	HYDRAULICS - BUCKET, 8,0 M (26 FT 3 IN) ARM
08-14	HYDRAULICS - FREE SWING
08-15	PILOT CONTROL LINES, TRAVEL - ALL MODELS
08-16	PILOT CONTROL LINES, ATTACHMENT - ALL MODELS
08-17	PILOT CONTROL LINES, ATTACHMENT - ALL MODELS
08-18	PILOT CONTROL LINES, PARTITION
08-19	PILOT CONTROL LINES, PARTITION
08-20	PILOT CONTROL LINES, PARTITION - MODELS WITH CONTROL SELECTOR VALVE
08-21	PILOT CONTROL LINES, PARTITION - MODELS WITH CONTROL SELECTOR VALVE
08-22	PILOT CONTROL LINES, CONTROL VALVE
08-23	PILOT CONTROL LINES, CONTROL VALVE
08-24	PILOT CONTROL LINES, CONTROL VALVE - MODELS WITH CONTROL SELECTOR VALVE
08-25	PILOT CONTROL LINES, CONTROL VALVE - MODELS WITH CONTROL SELECTOR VALVE

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08-26	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-26A	VALVE, SOLENOID - PILOT PRESSURE, RETURN LINES
08-27	MANIFOLD - PILOT PRESSURE, RETURN LINES
08-28	ACCUMULATOR - PILOT PRESSURE, RETURN LINES
08-29	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08-30	PUMP ASSY, HYDRAULIC - PISTON
08-31	PUMP ASSY, HYDRAULIC - DRIVE
08-32	PUMP ASSY, HYDRAULIC - LOW PRESSURE
08-33	PUMP ASSY, HYDRAULIC - SOLENOID VALVE
08-34	PUMP ASSY, HYDRAULIC - REGULATOR
08-35	MOUNTING - SWING MOTOR
08-38	KBC0127 GEAR ASSY, REDUCTION - MOTOR, SWING
08-38A	KBC0133 GEAR ASSY, REDUCTION - MOTOR, SWING
08-38B	KBC0157 GEAR ASSY, REDUCTION - MOTOR, SWING
08-39	HYDRAULICS - JOINT, SWIVEL CENTER, - P.I.N. DAC0724306
08-39A	HYDRAULICS - JOINT, SWIVEL CENTER, P.I.N. DAC0724307 -
08-40	CONTROL VALVE - SUPPORT
08-40A	VALVE ASSY - CONTROL
08-40B	VALVE ASSY - CONTROL
08-40C	VALVE ASSY - CONTROL
08-40D	VALVE ASSY - CONTROL
08-40E	VALVE ASSY - CONTROL
08-40F	VALVE ASSY - CONTROL
08-41	VALVE ASSY - HAND CONTROL
08-42	VALVE, CONTROL - TRAVEL
08-43	VALVE, CUSHION - PILOT CONTROL LINES
08-44	VALVE, PILOT - PILOT CONTROL LINES
08-44A	VALVE ASSY, REDUCING - PILOT CONTROL LINES
08-44B	VALVE, SOLENOID
08-45	VALVE, SOLENOID - FREE SWING
08-45A	VALVE ASSY - PEDAL CONTROL
08-45B	VALVE ASSY - SINGLE PEDAL
08-46	CYLINDER ASSY - BOOM
08-47	CYLINDER ASSY - BOOM
08-48	CYLINDER ASSY - ARM
08-49	CYLINDER ASSY - BUCKET
09-01	TURNTABLE BEARING
09-02	TURNTABLE
09-03	TURNTABLE - ACCESS COVERS
09-04	COUNTERWEIGHT - SOUNDPROOFING
09-05	FRAMES, COVERS - INSULATION (P.I.N. DAC0724099 - DAC0724170)
09-05A	FRAMES, COVERS - INSULATION (P.I.N. DAC0724171 -)
09-06	ACCESS DOOR - INSULATION
09-07	HOOD, ENGINE - INSULATION (P.I.N. DAC0724099 - DAC0724170)
09-07A	HOOD, ENGINE - INSULATION (P.I.N. DAC0724171 -)
09-08	STORAGE BOX - INSULATION (P.I.N. DAC0724099 - DAC0724170)
09-08A	STORAGE BOX - INSULATION (P.I.N. DAC0724171 -)
09-09	CONTROLS - OPERATORS COMPARTMENT
09-09A	TRAVEL CONTROL - SINGLE PEDAL
09-10	MAT, FLOOR - OPERATORS COMPARTMENT
09-11	OPERATORS COMPARTMENT

Order the manual at mid-west-tech.com >