CX135SR
Excavator

Parts Catalog

7-8960 NA

CASE CONSTRUCTION

MidWestTech | Case CX135SR Excavator Parts Catalog | Publication 7-8960NA

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02 -01	ENGINE MOUNTING
02 -02	AIR CLEANER
02 -03	AIR CLEANER ASSY
02 -04	EXHAUST SYSTEM - MUFFLER
02 -05	RADIATOR AND CONNECTIONS
02 -06	RADIATOR AND CONNECTIONS
02 -07	RADIATOR ASSY
02 -08	FAN DRIVE
02 -09	WATER PUMP SYSTEM
02 -10	FRONT GEAR COVER
02 -11	FLYWHEEL HOUSING
02 -12	MANIFOLD - EXHAUST
02 -13	MANIFOLD - INTAKE
02 -14	TURBOCHARGER SYSTEM
02 -15	TURBOCHARGER SYSTEM - OIL RETURN
02 -16	TURBOCHARGER ASSY
02 -17	OIL CIRCUIT
02 -18	OIL COOLER - OIL FILTER
02 -19	OIL PUMP
02 -20	OIL PAN
02 -21	CYLINDER HEAD COVER
02 -22	CYLINDER BLOCK - BREATHER
02 -23	CYLINDER HEAD
02 -24	THERMOSTAT AND HOUSING
02 -25	CAMSHAFT - VALVE MECHANISM
02 -26	CYLINDER BLOCK
02 -27	CRANKSHAFT - FLYWHEEL
02 -28	PACKAGE, SEALS
03 -01	FUEL TANK
03 -02	FUEL LINES
03 -03	FUEL LINES
03 -04	WATER SEPARATOR ASSY
03 -05	FUEL INJECTION PUMP - DRIVE
03 -06	PUMP - FUEL SYSTEM
03 -07	FUEL FILTER - SUPPORT
03 -08	FUEL INJECTION - NOZZLE
03 -09	COUPLING, FUEL INJECTION PUMP
03 -10	GOVERNOR CONTROL - ENGINE SHUTOFF
04 -01	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04 -02	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04 -03	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04 -04	HARNESS, MAIN - CHASSIS, UPPERSTRUCTURE
04 -05	HARNESS - OPERATORS COMPARTMENT
04 -06	RADIO
04 -07	CONVERTER
04 -08	HORN
04 -09	LAMP, WORK - CAB
04 -10	LAMP, WORK - BOOM
04 -11	WINDSHIELD WASHER
04 -12	BATTERIES
04 -13	STARTER - ALTERNATOR

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04 -14	ALTERNATOR ASSY
04 -15	STARTER ASSY
04 -16	ELECTRICAL ACCESSORIES - ENGINE
04 -17	TRAVEL ALARM
04 -18	ELECTRICAL PARTS - MODELS WITH LOAD HOLD
05 -01	UNDERCARRIAGE
05 -02	UNDERCARRIAGE COVER, LOWER
05 -03	TRACK CHAINS - STEEL
05 -04	TRACK CHAINS - RUBBER
05 -05	TRACK - IDLER
05 -06	CYLINDER ASSY - ADJUSTER
05 -07	TRACK - ROLLER, UPPER
05 -08	TRACK - ROLLER, LOWER
06 -01	TRACK DRIVE ASSY
06 -02	MOTOR ASSY - GEAR ASSY, REDUCTION
06 -03	MOTOR ASSY - PISTON
06 -04	MOTOR ASSY - PISTON
06 -05	VALVE ASSY, RELIEF - MOTOR, HYDRAULIC
06 -06	HYDRAULICS - TRACK DRIVE
08 -01	HYDRAULIC RESERVOIR
08 -02	HYDRAULIC RESERVOIR
08 -03	PUMP AND COUPLING - MODELS WITHOUT DOZER BLADE
08 -04	PUMP AND COUPLING - MODELS WITH DOZER BLADE
08 -05	PUMP SUCTION LINE - MODELS WITHOUT DOZER BLADE
08 -06	PUMP SUCTION LINE - MODELS WITH DOZER BLADE
08 -07	HYDRAULICS - CONTROL VALVE SUPPLY
08 -08	HYDRAULICS - CONTROL VALVE SUPPLY
08 -09	HYDRAULICS - RESERVOIR RETURN
08 -10	HYDRAULICS - BYPASS FILTER
08 -11	HYDRAULICS - DRAIN LINE, MODELS WITHOUT LOAD HOLD
08 -12	HYDRAULICS - DRAIN LINE, MODELS WITHOUT LOAD HOLD
08 -13	HYDRAULICS - DRAIN LINE, MODELS WITH LOAD HOLD
08 -14	HYDRAULICS - DRAIN LINE, MODELS WITH LOAD HOLD
08 -15	HYDRAULICS - TRAVEL
08 -16	HYDRAULICS - TRAVEL
08 -17	HYDRAULICS - SWING
08 -18	HYDRAULICS - BOOM
08 -19	HYDRAULICS - BOOM CYLINDER, MODELS WITHOUT LOAD HOLD
08 -20	HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08 -21	HYDRAULICS - BOOM CYLINDER, MODELS WITH LOAD HOLD
08 -22	HYDRAULICS - ARM AND BUCKET
08 -23	HYDRAULICS - ARM CYLINDER, MODELS WITHOUT LOAD HOLD
08 -24	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08 -25	HYDRAULICS - ARM CYLINDER, MODELS WITH LOAD HOLD
08 -26	HYDRAULICS - BUCKET, 2.4 METER (7 FT 10 IN) ARM
08 -27	HYDRAULICS - BUCKET, 2.85 METER (9 FT 4 IN) ARM
08 -28	HYDRAULICS - BLADE, DOZER
08 -29	HYDRAULICS - BLADE, DOZER
08 -30	HYDRAULICS - BLADE, DOZER
08 -31	HYDRAULICS - BLADE CYLINDER LINE, MODELS WITHOUT LOAD HOLD
08 -32	HYDRAULICS - BLADE CYLINDER LINE, MODELS WITH LOAD HOLD

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

08 -33	PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08 -34	PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08 -35	PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08 -36	PILOT CONTROL LINES - MODELS WITHOUT LOAD HOLD
08 -37	PILOT CONTROL LINES - MODELS WITH DOZER BLADE
08 -38	PILOT CONTROL LINES - MODELS WITH DOZER BLADE
08 -39	PILOT CONTROL LINES - MODELS WITH DOZER BLADE
08 -40	PILOT CONTROL LINES - MODELS WITH DOZER BLADE
08 -41	PILOT CONTROL LINES - MODELS WITH LOAD HOLD
08 -42	PILOT CONTROL LINES - MODELS WITH LOAD HOLD
08 -43	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08 -44	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08 -45	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08 -46	PILOT CONTROL LINES - MODELS WITH CONTROL SELECTOR VALVE
08 -47	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08 -48	HYDRAULICS - PILOT PRESSURE, RETURN LINES
08 -49	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08 -50	HYDRAULICS, AUXILIARY - SINGLE ACTING CIRCUIT
08 -51	HYDRAULICS, OPTION LINE - SINGLE ACTING AND MULTI-PURPOSE + 3 WAY VALVE CIRCUITS
08 -52	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08 -53	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08 -54	HYDRAULICS, AUXILIARY - MULTI-PURPOSE + 3 WAY VALVE
08 -55	HYDRAULICS, AUXILIARY - DOUBLE ACTING CIRCUIT
08 -56	HYDRAULICS, AUXILIARY - SECOND OPTION LINE
08 -57	HYDRAULICS, AUXILIARY ATTACHMENT - BOOM LINE
08 -58	PUMP ASSY, HYDRAULIC - PISTON, MODELS WITHOUT DOZER BLADE
08 -59	PUMP ASSY, HYDRAULIC - REGULATOR, MODELS WITHOUT DOZER BLADE
08 -60	PUMP ASSY, HYDRAULIC - REGULATOR, MODELS WITHOUT DOZER BLADE
08 -61	PUMP ASSY, HYDRAULIC - GEAR PUMP DRIVE, MODELS WITHOUT DOZER BLADE
08 -62	PUMP ASSY, HYDRAULIC - PISTON, MODELS WITH DOZER BLADE
08 -63	PUMP ASSY, HYDRAULIC - REGULATOR, MODELS WITH DOZER BLADE
08 -64	PUMP ASSY, HYDRAULIC - REGULATOR, MODELS WITH DOZER BLADE
08 -65	PUMP ASSY, HYDRAULIC - GEAR PUMP DRIVE, MODELS WITH DOZER BLADE
08 -66	MOUNTING - SWING MOTOR
08 -67	MOTOR ASSY - SWING
08 -68	MOTOR ASSY - SWING
08 -69	MOTOR ASSY - SWING
08 -70	JOINT, SWIVEL CENTER - MODELS WITHOUT DOZER BLADE
08 -71	JOINT, SWIVEL CENTER - MODELS WITH DOZER BLADE
08 -72	CONTROL VALVE - SUPPORT
08 -74	CONTROL VALVE - VALVE, PORT RELIEF
08 -75	CONTROL VALVE - VALVE, PORT RELIEF
08 -76	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -77	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -78	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -79	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -80	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -81	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -82	VALVE ASSY, CONTROL - MODELS WITHOUT DOZER BLADE
08 -83	VALVE ASSY, CONTROL - MODELS WITH DOZER BLADE

Order the manual at mid-west-tech.com >

MOTOR ASSY - PISTON

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		LJ00862		1	MOTOR, HYDRAULIC Incl. LH00291, 36 - 86, Also Includes Parts on Figure 06-04
		LH00291		1	FLANGE Incl. LH00292, 36 - 59
		LH00292		1	FLANGE Incl. 36 - 42
36		NSS		1	NOT SERVICED SEPARATELY Flange
37		NSS		1	NOT SERVICED SEPARATELY Spool
38		LK00298		3	PLUG
39		LK00296		8	PLUG
40		166821A1		1	FILTER
41		LPM0055		1	ORIFICE
42		161835A1		1	TYPE PLATE
		165264A1		1	SPOOL Incl. 44, 45
44		NSS		1	NOT SERVICED SEPARATELY Spool
45		NSS		1	NOT SERVICED SEPARATELY Stop
46		165235A1		2	PLUG
47		165248A1		2	RETAINER
48		165238A1		2	PLUG
49		165252A1		2	VALVE
50		165279A1		2	SPRING
51		165278A1		2	SPRING
52		154515A1		2	O-RING
53		154482A1		2	O-RING
54		154467A1		2	O-RING
55		165237A1		1	PLUG
56		165283A1		1	SPRING
57		160979A1		2	BALL
58		165236A1		2	PLUG
59		154487A1		1	O-RING
79		165237A1		1	PLUG
82		154487A1		3	O-RING
85		335B100T025		2	PIN
86		861-10030		8	SCREW M10 x 30

MidWestTech | Case CX135SR Excavator Parts Catalog | Publication 7-8960NA Order the manual at mid-west-tech.com >

HYDRAULICS - PILOT PRESSURE, RETURN LINES

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		157935A1		1	ELBOW Incl. 2
2		154487A1		1	O-RING
3		KHJ2553		1	HOSE ASSY.
4		157935A1		1	ELBOW Incl. 5
5		154487A1		1	O-RING
6		150913A1		3	ELBOW Incl. 7
7		154467A1		1	O-RING
9		KHJ2074		1	HOSE ASSY.
10		KHJ2078		1	HOSE ASSY.
11		KHJ2164		1	HOSE ASSY.
18		KHJ1474		1	MANIFOLD Incl. 19
19		KHJ1493		1	ELEMENT, FILTER
20		814-10100		2	SCREW M10 x 100; 10.9
21		150409A1		2	WASHER 10,5 x 21 x 3,2 mm
22		KMJ2966		1	BRACKET
23		166351A1		2	BOLT
24		151136A1		1	BUSHING Incl. 25
25		154467A1		1	O-RING
26		1541849C1		1	COUPLING Incl. 60, 61
27		KHJ0997		1	ACCUMULATOR
28		150916A1		1	ELBOW Incl. 29
29		154475A1		1	O-RING
31		KHJ2208		1	HOSE ASSY.
32		157584A1		1	ELBOW Incl. 33
33		154475A1		1	O-RING
34		KNJ2781		1	VALVE,ELECTRIC See Figure 08-93
37		150913A1		1	ELBOW Incl. 38
38		154467A1		1	O-RING
39		150933A1		1	ELBOW Incl. 40
40		154467A1		1	O-RING
44		KHJ2151		1	HOSE ASSY.
45		KHJ2062		1	HOSE ASSY..
46		KHJ2329		1	HOSE ASSY.
47		KHJ2169		1	HOSE ASSY.
48		150913A1		1	ELBOW Incl. 49
49		154467A1		1	O-RING

MidWestTech | Case CX135SR Excavator Parts Catalog | Publication 7-8960NA Order the manual at mid-west-tech.com >

CYLINDER ASSY - BUCKET

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		KMV2545		1	HYDRAULIC CYLINDER Incl. 1 - 43
1		LR00614		1	TUBE ASSY. Incl. 2, 3
2		NSS		1	NOT SERVICED SEPARATELY Tube, Cylinder
3		155400A1		1	RING
4		LB00640		1	ROD, PISTON Incl. 5, 6
5		NSS		1	NOT SERVICED SEPARATELY Rod, Piston
6		155413A1		1	RING
8		LU00080		1	CAP CYLINDER END
9		LB00512		1	BUSHING
10		155698A1		1	RING SNAP
11		LE00858		1	RING
12		155129A1		1	RING
13		155230A1		1	BACK-UP RING
14		LE00422		1	SEAL, SHAFT
15		154705A1		1	O-RING
16		160810A1		1	BACK-UP RING
17		861-14055		10	CAPSCREW M14 x 55; 12.9
18		LE00735		1	RING
19		160944A1		1	PISTON
20		160825A1		1	GASKET
21		160814A1		2	BACK-UP RING
22		LE00736		2	RING
23		160829A1		2	RING
24		155720A1		1	SHIM
25		LA00775		1	NUT
26		156222A1		1	SCREW
27		155976A1		1	BALL
28		LE00737		2	RING
29		164446A1		2	SEAL, SHAFT
30		LK00344		1	COUPLING FLANGE
31		LR00728		1	PIPE
32		154528A1		1	O-RING
33		861-10030		4	SCREW M10 x 30
34		154499A1		1	O-RING
35		861-8025		4	SCREW M8 x 25; 12.9
36		LD00037		1	BAND

MidWestTech | Case CX135SR Excavator Parts Catalog | Publication 7-8960NA Order the manual at mid-west-tech.com >