686G, 686GXR
TELESCOPIC HANDLER

Service Manual

7-89650

CASE CONSTRUCTION

MidWestTech | Case 686G, 686GXR Telescopic Handler Service Manual | Publication 7-89650

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SAFETY INFORMATION 3
Understanding Signal Words 3
General Safety Guidelines 3

ENGINE SAFETY 5

ELECTRICAL SAFETY 6

HYDRAULICS SAFETY 6


GENERAL SERVICE PRECAUTIONS 7
Service Cleanliness 7
Removal and Installation 7
Disassembly and Assembly 7
Hydraulic System and Component Service 8
Electrical System 8

686G/686G XR MAIN COMPONENT LOCATIONS 9

INTRODUCTION 10
General 10
Product Identification Number Plate (P.I.N.) 10
Location of Major Components 11

NOTE: Case Corporation reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

MidWestTech | Case 686G, 686GXR Telescopic Handler Service Manual | Publication 7-89... Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >